



Systems Reference Library

IBM 1130 Computing System Installation Manual-Physical Planning

This publication contains physical planning information for the installation of an 1130 system. Included are dimensions, weights, cable locations and lengths, service clearances, and other necessary physical information for each unit of the system. Environmental and electrical requirements are also included. Photographs and drawings are used throughout the text, and a summary table of physical planning specifications is provided.



Fourth Edition

This publication (Form A26-5914-3) supersedes and makes obsolete the previous edition (Form A26-5914-2).

Specifications contained herein are subject to change from time to time. Any such change will be reported in subsequent revisions or Technical Newsletters.

The illustrations in this manual have a code number in the lower corner. This is a publishing control number and is not related to the subject matter.

Copies of this and other IBM publications can be obtained through IBM Branch Offices

A form is provided at the back of this publication for your comments.

This manual was prepared by the IBM Systems Development Division, Product Publications, Dept. 455, Bldg. 014, San Jose, California 95114. Send comments concerning the contents of this manual to this address.

INSTALLATION REQUIREMENTS AND		Synchronous Communications Adapter	6
SCHEDULING	1	IBM Field Engineering Requirements	6
System Arrangement and Space		UNIT SPECIFICATIONS	7
Requirements	1	IBM 1131 Central Processing Unit, Models 1A,	
Scheduling	1	1B, 2A, and 2B	8
Six Months before Delivery	1	IBM 1131 Central Processing Unit, Models 2C,	
Four Months before Delivery	1	2D, 3B, 3C, and 3D	9
One Week before Machine Delivery	3	IBM 1132 Printer	10
Environmental Requirements	3	IBM 1133 Multiplex Control Enclosure	11
Ambient Air Conditions	3	IBM 1134 Paper Tape Reader	12
Dust and Dirt Control	3	IBM 1231 Optical Mark Page Reader, Model 1.	13
Fire Protection Equipment	3	IBM 1442 Card Punch, Model 5	14
Power Requirements	3	IBM 1442 Card Read Punch, Models 6 and 7	14
Power Supply	3	IBM 2310 Disk Storage, Models B1 and B2	15
Power Distribution	3	IBM 2501 Card Reader, Models A1 and A2	16
Phase Rotation	4	IBM 1055 Paper Tape Punch	17
Convenience Outlets	4	IBM 1403 Printer, Models 6 and 7	18
Grounding	4	IBM 1627 Plotter, Models 1 and 2	19
Lightning Protection	4	Auxiliary Table	20
Cables	4	APPENDIX A	21
Storage Access Channel	4	APPENDIX B	22
Storage Access Channel Cable	4	INDEX	23

An efficiently operated computer system depends largely on careful planning and preparation prior to actual installation of equipment. The purpose of this manual is to assist IBM customers in the period preceding delivery of new equipment.

The foremost requirement is to provide suitable space and environmental conditions for the components ordered. Consideration should be given not only to the requirements of the system and associated personnel, but also to other equipment, such as storage cabinets, work tables, chairs, and desks. IBM will provide consultation and assistance when requested to do so.

The following IBM publication is available to facilitate planning and installation:

1130 System Template (Form X26-5997)

SYSTEM ARRANGEMENT AND SPACE REQUIREMENTS

The physical location of the 1130 system components can be arranged to fit the individual needs of the user. Raised floors are not required but, when used, offer the following advantages:

- Provide increased flexibility in system layout by allowing cables to be run direct.
- 2. Can be used as an air plenum.
- Provide protection for inter-unit cabling and customer branch circuit wiring.

A compact arrangement of components provides for efficient and convenient operation by the system operator.

Consideration should be given to the possible future expansion of the system or installation. Additional machines or equipment can then be added to the initial installation without disruptive revisions to the original plans.

In summary, the following items should be considered in determining space requirements and location:

Cable routing.
Cable length.
Service clearance.

Work space.
Heat dissipation.
Desk space.
Aisle space.
Future expansion.
Weight and floor loading.
Electrical requirements.
Doorway sizes, elevator capacities, and loading facilities used to get the machines to their

Figure 1 illustrates the system component cabling and includes a list of the cables and cable lengths.

The appendix contains a summary of the physical specifications of the units of the 1130 system, including the required service clearance for proper servicing of the equipment by IBM Customer Engineers.

SCHEDULING

location.


The design and implementation of a physical planning schedule assures machine-room readiness when the system is delivered. Because each 1130 system installation differs in some respect from every other installation, it is not possible to provide a precise schedule. The following schedule may be modified to meet the specific needs of a given installation.

Six Months before Delivery

- 1. Review the order.
- 2. Determine the prospective location of the system, initiate design criteria for facilities, and make a preliminary layout of the proposed installation.

Four Months before Delivery

This is a critical point in the schedule. The final layout should be determined and approved by the customer and by the IBM Branch Manager. If building alterations, such as painting, plastering, or expansion of electrical service, are necessary, the drawings and specifications for them should be complete and ready for the work to begin.



Group No .	No. of Cables	From (Unit)	To (Unit)	Maximum Length	Standard* Length (Ft)	Notes
1	1	Recpt	1131	14	14	1,2
2	2	1442	1131	15	15	1,3
3	2	1132	1131	15	15	1,3
4	1	1134	1131	11	11	1,3
5	1	1055	1131	7	7	1,3
6	1	1627	1131	12	12	1,3
7	1	Cust Dev	1131	19	-	4,7,8,9
8	1	Cust Dev	1133	19	_	4,7,8,10
9	3	1133	1131	13	13	4
11	1	Recpt	1133	14	14	1
12	2	2310 B #1	1133	-	13	5
13	1	2310 B	1133	13	13	-
14	2	2310 B #2	2310B#1	-	5	5
15	3	1403	1133	21	21	-
16	1	1231	1131	25	25	6
17	2	2501	1131	25	20	6
18	1	Recpt	1231	8	8	1
19	1	Data Set	1131	40	25	-
20	1	2250	1131 1133	13	13	4,8
21	1	Recpt	2250	14	14	1

Notes:

- 1. Available only at length shown.
- The ac power cord (cable group 1) to the 1131 is not used when an 1133 is installed. When an 1133 is not installed, the ac power cord (cable group 1) must be ordered.
- 3. Cables shipped with from unit.
- 4. Only one device can be connected via the storage access channel. Thus, either an 1133 (cable group 9), the 2250 (cable group 20), or a customer device (cable group 7) can be connected to the 1131. Similarly, either the 2250 (cable group 20) or a customer device (cable group 8) can be connected to the 1133. Cable group 7 can be substituted for cable group 8 when adding an 1133 to an installed system.
- Maximum length of cable group 12 plus cable group 14 must be equal to or less than 21 feet.
- 6. Only one 1231 or one 2501 may be installed.
- 7. Customer purchase only.
- 8. Cable length is measured from cable floor entry at 1131 or 1133 to the connector at the end of the cable. Maximum length must be reduced by the wire circuit dimension from the mating receptacle to the circuit component in the customer device.
- 9. Used with feature code 7490.
- 10. Used with feature code 7492.
- * Standard cable lengths shown will be supplied for the system unless a cable order is received at least 120 days prior to scheduled system delivery.

• Figure 1. Cable Diagram and Cable Chart

No further changes that affect cable lengths should be made in the layout. A cable order form must be processed at this time.

One Week before Machine Delivery

All installation elements pertaining to environmental and power requirements should be reviewed and tested. Lighting, floor ramps, painting, plastering, decorating, etc., should also be completed at this time. Installation and testing of all early-delivery items should be completed.

ENVIRONMENTAL REQUIREMENTS

Ambient Air Conditions

All IBM 1130 Computing Systems use air for internal cooling. Cool air is introduced through the bottom or side of each unit, internally circulated by fans or natural convection, and exhausted to the room from the top. The following limits should be maintained for ambient air to ensure normal operation of the system:

Temperature: 60°F to 90°F Relative humidity: 10% to 80%

Maximum wet bulb temperature: 78°F

A summary of the specifications for the individual units is given in the appendix.

Dust and Dirt Control

The amount of contamination in the office atmosphere will not normally interfere with the operation of the 1130 system. Normal precautions should be taken, however, to keep dust, dirt, and other foreign matter away from the machine area.

Fire Protection Equipment

Portable carbon-dioxide fire extinguishers of suitable size should be provided in the computing system area, subject to local building-code and fire-insurance requirements. A nonwetting fire-extinguishing agent for electrical equipment (Class C hazard) is recommended.

POWER REQUIREMENTS

Power Supply

Electrical requirements for the IBM 1130 Computing System depend on the system configuration and auxiliary equipment used. See Unit Specifications for voltage requirements.

The voltage and frequency specifications for the 1130 system are:

- 1. $115 \text{vac}(\pm 10\%)$; $60 \text{Hz}(\pm 0.5 \text{Hz})$; single-phase; three-wire (one phase, one neutral, and one grounding conductor).
- 208 or 230vac(±10%); 60Hz(±0.5Hz); single-phase; three-wire (two phase and one grounding conductor).
- 3. 208 or 230vac($\pm 10\%$); 60Hz(± 0.5 Hz); three-phase; four-wire (three phase and one grounding con-
- 4.* 195, or 220, or 235 $vac(\pm 10\%)$; 50 $Hz(\pm 0.5Hz)$; single-phase; three-wire (one phase, one neutral, and one grounding conductor).
- 5.* 195, or 220, or 235 vac ($\pm 10\%$); 50 Hz(± 0.5 Hz); three-phase; four-wire (three phase and one grounding conductor).

Power Distribution

All power to the 1130 system should be supplied through a single feeder, protected by a mainline circuit breaker. Individual branch circuits from the distribution panel should be protected by circuit breakers suitable for motor load application and derated according to the manufacturer's specifications.

The distribution panel should be located in an unobstructed and well-lighted area within the computer room. As a safety precaution, a remote circuit breaker, which can remove all power from the computer system, should be provided in the machine room.

Any customer-supplied machine receiving power from the building distribution system should have a branch-circuit protection device. This protection device should be interconnected with the 1130 system mainline circuit breaker, so that all power to machines located in the same room or area can be interrupted from one location under emergency conditions.

^{*}Available for use in countries where 50-hertz power distribution systems are used.

Phase Rotation

The three-phase power receptacles for use with the system must be wired for correct phase rotation. Looking at the face of the receptacle, and running counterclockwise from the ground pin, the sequencing will be phase one, phase two, and phase three.

Convenience Outlets

A suitable number of convenience outlets should be installed in the computer room and CE room for use by building maintenance personnel, porter service, Customer Engineers, etc.

Grounding

A green-wire grounding conductor is supplied in each power cord. Each customer-supplied branch circuit should have an insulated wire conductor for the purpose of grounding equipment. All branch-circuit grounding wires can be tied to a common ground point at the distribution panel, and a single grounding wire run from the distribution panel to the nearest grounding station. Conduit must not be used as the only grounding means. Unless otherwise required by local codes, the grounded neutral conductor must be electrically isolated from the system grounding conductor except at the building grounding station.

Lightning Protection

It is recommended that the customer install lightning protection on his secondary power source when any of the following conditions exists:

- 1. The utility company installs lightning protectors on the primary.
- 2. Primary power is supplied by an overhead power service.
- 3. The area is subject to electrical storms or equivalent power surges.

CABLES

IBM provides the necessary inter-unit signal and power cables for proper connection to the 1130 system.

Cable length limitations and routing listed in Figure 1 are available to the customer at no extra charge, except for those cables listed as customer purchase only. Cable lengths longer than the maximum specified can be considered on an RPQ* basis.

Cable lengths are determined by measuring the distance along the cable route from the floor or other mounting surface point of entry of a unit to the corresponding point of entry of the connecting unit. When a raised floor or raceway floor is used, twice the height of the floor must be added to the measured length.

Exposed interconnecting cables should be protected so that they do not present a safety hazard and are not readily damaged. This protection can consist of ramps, raceways with removable covers, or a raised floor.

Storage Access Channel

The Storage Access Channel (SAC) feature provides a means for external devices or systems to communicate directly with the 1131 CPU core storage. Communication with core storage from an external device is on either a cycle-steal or an interrupt basis, and is initiated by the external device when the device is ready to communicate. For more information on SAC, refer to the SRL Publication "IBM 1131 OEMI" (Form A26-3645).

Storage Access Channel Cable

Cable assembly P/N 2243004 (includes a connector on each end) may be purchased from IBM for attachment of a customer device to the Storage Access Channel (cable group number 7).

The data, address, and control lines are brought out through a 160-pin receptacle in the 1131.

A detailed diagram of the plug and receptacle is shown in Figure 2.

Specifications of the Storage Access Channel cable are:

Number of conductors: 182 (91 twisted pairs)

Cable diameter: 1.20" nominal

Cover type: Polyvinyl chloride 5/64" nominal

thickness

Twist per foot: 1

Shielding: Tinned copper braid for 90%

minimum coverage

Cable lay-up: 1-6-12-18-24-30

^{*}Request price quotation from IBM.




Figure 2. Storage Access Channel Connector

Individual Conductor Characteristics:

Quantity: 182 (91 twisted pairs)
Maximum outside diameter: 0.054"

AWG size: 22

Conductor material: stranded copper Insulation material: semi-rigid polyvinyl

chloride

Insulation thickness: 0.009"nominal U. L. voltage rating: 300 volts

Temp. rating (insulation): 80°C (176°F)

The external shielding must be connected only to CPU ground through position L3 of the 160-pin receptacle for the SAC.

Coupled Noise

The maximum level for noise coupled onto any signal line must not exceed 300 millivolts.

Cable Resistance

Cable length is limited by cable resistance and contact resistance. The maximum cable resistance, including contact resistance, must not exceed 26 ohms.

Power Sequence for Storage Access Channel Devices

Customer devices attached to the storage access channel should not be turned on or off except when the CPU is off or in single step mode.

It is recommended that non-IBM devices connected to the 1130 system via the storage access

channel be powered from an ac source having the same voltage as the ac source for the 1130 system.

Synchronous Communications Adapter

The Synchronous Communications Adapter (SCA) special feature enables the IBM 1130 Computing System to function as a point-to-point data transmission terminal, using either private or commercial common-carrier line transmission facilities. The adapter sends data to or receives data from the line transmission facilities under control of the stored program in the 1130. It operates on an interrupt-request basis similar to that used by other input/output devices in the IBM 1130 Computing System.

The Synchronous Communications Adapter cable (cable 19) routing is shown in Figure 1.

For more information on the SCA, refer to the SRL "IBM 1131 Functional Characteristics" (Form A26-5881).

IBM FIELD ENGINEERING REQUIREMENTS

Proper servicing of the 1130 system requires adequate service clearances around each unit of the system. These clearances are listed under the Specifications list for the individual unit.

Space should be provided near the operating area for storage of test equipment and spare parts. At least one duplex 115/120 vac grounding type receptacle should be located in this area.


This section contains plan views for each of the units in the system.


The plan views illustrated for each unit use these symbols:

30046

Caster 0 Floor Leveler \boxtimes IBM Cable Entry Floor Level Cable Exit Usage Meter C.E. Panel

IBM 1131 CENTRAL PROCESSING UNIT, MODELS 1A, 1B, 2A, AND 2B





Dimensions	Width	Dep	th	Height
Inches:	58.25	29		46.5
Centimeters:	148	74		118
Service Clearance	Front	Rear	Left	Right
Inches:	42	36	_	30
Centimeters:	107	91	_	<i>7</i> 6

Maximum Weight--760 lb (34,5 kg)

Heat Output/hr. -- 3100 BTU (781 kcal)

Air Flow--720 cfm (21 m^3/m) maximum

(*2) Electrical Requirements--(115v)

Voltage: 115v±10% Service: 30 amp Frequency: 60±0.5 Hz Plug: Hubbell #9338

Phases: 1 Receptacle: Hubbell #9344

KVA: 1.1

(*1) Electrical Requirements--(208/230v)

Voltage: $208/230 \pm 10\%$ Service: 20 amp Frequency: 60 ± 0.5 Hz Plug: Russell and Stoll Phases: 1 #F.S. 3720

KVA: 1.1 Recen

Receptacle: Russell and Stoll

#F.S. 3743

Connector: Russell and Stoll

#F.S. 3913

Operating Environment--

Temperature: 60° to 90° F (15.6° to 32.2° C)

Rel. Humidity: 10% to 80% Max. Wet Bulb: 78° F (25.6° C)

Nonoperating Environment--

Temperature: 50° to 110° F (10° to 43° C)

Rel. Humidity: 8% to 80% Max. Wet Bulb: 80° F (26.7° C)

*Notes:


1. Power is supplied by the 1133 if installed.


2. Measure voltage at receptacle before connecting power

cord to be sure correct voltage exists.

30047 A

IBM 1131 CENTRAL PROCESSING UNIT, MODELS 2C, 2D, 3B, 3C, AND 3D





1	inches = C	entimeters
	9.0	22,8
	10.0	25,4
	21.5	54,6
	27.5	69,9
	28.0	71,1
ı	30.0	76,2
	30.5	88,9
ı	88.25	224,8

27070

Dimensions	Width	Dep	th	Height
Inches:	88.25	(*2) 29		46.50
Centimeters:	224	74		118
Service Clearance	Front	Rear	Left	Right
Inches:	42	36	30	30
Centimeters:	107	91	76	76

Maximum Weight--1050 lb (477 kg)

Heat Output/hr.--4200 BTU (1058 kcal)

Air Flow--1000 cfm (28,3 m³/m) maximum

(* 1) Electrical Requirements--(208/230v)

Voltage: 208/230±10% Service: 20 amp Frequency: 60±.5 Hz Plug: Russell and Stöll Phases: 1

#F.S. 3720

KVA: 1.5 Receptacle: Russell and Stoll #F.S. 3743

Connector: Russell and Stoll

#F.S. 3913

Operating Environment--

Temperature: 60° to 90° F (15.6° to 32.2° C)

Rel. Humidity: 10% to 80% Max. Wet Bulb: 78° F (25.6° C)

Nonoperating Environment--

Temperature: 50° to 110° F (10° to 43° C)

Rel. Humidity: 8% to 80% Max. Wet Bulb: 80° F (26.7° C)

*Notes:


1. Power is supplied by the 1133 if installed.

2. Shipped in two sections.

30048 A

IBM 1132 PRINTER





Dimensions	Width	Dep	oth	Height
Inches:	47	29.	50	42
Centimeters:	119	<i>7</i> 5		107
Service Clearance	Front	Rear	Left	Right
Inches:	36	30	30	30
Centimeters:	91	76	76	76

Maximum Weight--700 lb (318 kg)

Heat Output/hr. -- 1300 BTU (328 kcal)

Air Flow--80 cfm (2 m³/m) maximum

(*1) Electrical Requirements--

KVA: 0.5

Operating Environment--

Temperature: 60° to 90° F (15.6° to 32.2° C)

Rel. Humidity: 10% to 80% Max. Wet Bulb: 78° F (25.6° C)

Nonoperating Environment--


Temperature: 50° to 110° F (10° to 43° C)


Rel. Humidity: 8% to 80% Max. Wet Bulb: 80° F (26.7°C)

*Notes:

1. Power is supplied by the 1131.

IBM 1133 MULTIPLEX CONTROL ENCLOSURE





Dimensions	Width	Dep	oth	Height
Inches:	32	45.	50	60
Centimeters:	81	116		152
Service Clearance	Front	Rear	Left	Right
Inches:	30	30	42	30
Centimeters:	76	76	107	76

Maximum Weight--1100 lb (499 kg)

Heat Output/hr. --3400 BTU (857 kcal)

Air Flow--500 cfm (14,2 m³/m) maximum

Electrical Requirements -- (208/230v)

Voltage: 208/230 ± 10% Service: 30 amp

Frequency: 60± 0.5 Hz Plug: Russell and Stoll #F.S. 3760

Phases: 3

Receptacle: Russell and Stoll

KVA: 1.1

#F.S. 3754

Connector: Russell and Stoll

#F.S. 3934

Operating Environment--

Temperature: 60° to 90° F (15.6° to 32.2°C)


Rel. Humidity: 10% to 80% Max. Wet Bulb: 78° F (25.6° C)

Nonoperating Environment--

Temperature: 50° to 110° F (10° to 43° C)

Rel. Humidity: 8% to 80% Max. Wet Bulb: 80° F (26.7° C)

IBM 1134 PAPER TAPE READER



Inche	Inches = Centimeters				
8. 11. 19. 23.	00	22,0 29,2 48,0 59,7			

23.5"

Front

Take-up Reel

Supply Reel

11435 B

Dimensions	Width	Dep	oth	Height
Inches:	23.5	11.5	50	10
Centimeters:	59,7	29,	20	25,4
Service Clearance	Front	Rear	Left	Right
Inches:	30	12	6	6
Centimeters:	76	30	15	15

Maximum Weight--15 lb (7 kg)

Heat Output/hr.--150 BTU (38 kcal)

Air Flow--0 cfm (0 m³/m) maximum

(* 1) Electrical Requirements--

KVA: 0.06

Operating Environment--

Temperature: 60° to 90° F (15.6° to 32.2° C)

Rel. Humidity: 10% to 80% Max. Wet Bulb: 80° F (26.7° C)

Nonoperating Environment--

Temperature: 60° to 90° F (15.6° to 32.2° C)


Rel. Humidity: 10% to 80% Max. Wet Bulb: 80° F (26.7°C)


*Notes:

1. Power supplied by the 1131.

30051 B

IBM 1231 OPTICAL MARK PAGE READER, MODEL 1





Dimensions	Width	Dep	th	Height
Inches:	43.5	24		44.75
Centimeters:	113	61		114
Service Clearance	Front	Rear	Left	Right
Inches:	42	42	36	30
Centimeters:	107	107	91	76

Maximum Weight--620 lb (281 kg)

Heat Output/hr. -- 3700 BTU (932 kcal)

Air Flow--300 cfm (8 m^3/m) maximum

Electrical Requirements -(208/230v)

Voltage: 208/230±10%

Frequency: 60± 0.5 Hz

Phases: 1

KVA: 1.2

Service: 15 amp Plug: Russell and Stoll #F.S. 3720

Receptacle: Russell and Stoll

#F.S. 3743

Connector: Russell and Stoll

#F.S. 3913

Operating Environment--

Temperature: 50° to 110° F (10° to 43° C)


Rel. Humidity: 8% to 80% Max. Wet Bulb: 85° F (29.4° C)


Nonoperating Environment--

Temperature: 50° to 110° F (10° to 43° C)

Rel. Humidity: 8% to 80% Max. Wet Bulb: 85° F (29.4° C)

IBM 1442 CARD PUNCH, MODEL 5 IBM 1442 CARD READ PUNCH, MODELS 6 AND 7





Inches = Centimeters				
0.5	1,2			
0.75	1,9			
2.5	6,3			
5.0	12,7			
6.0	15,2			
8.0	20,3			
9.0	22,8			
10.0	25,4			
12.0	30,4			
15.0	38,1			
24.0	60,9			
43.0	109,2			

15708B

Dimensions	Width	Depti	h H	eight
Inches:	43	24	4	19
Centimeters:	109	61	12	24
Service Clearance	Front	Rear	Left (* 1)	Right
Inches:	36	30	18	6
Centimeters:	91	76	46	15

Maximum Weight--525 lb (238 kg)

Heat Output/hr. -- 1800 BTU (454 kcal)

Air Flow--50 cfm (1 m³/m) maximum

(*2) Electrical Requirements--

KVA: 0.7

Operating Environment--

Temperature: 60° to 90° F (15.6° to 32.2° C)

Rel. Humidity: 10% to 80% Max. Wet Bulb: 80° F (26.7° C)

Nonoperating Environment--


Temperature: 50° to 110°F (10° to 43° C)


Rel. Humidity: 0% to 80% Max. Wet Bulb: 80° F (26.7° C)

*Notes:

- 1. No service clearance is required from floor level to 30" (76 cm) above floor level. Service clearance is required for the upper portion of the machine only. The 1442 can be abutted to units which do not extend more than 30" (76 cm) from the floor.
- 2. Power is supplied by the 1131.

IBM 2250 DISPLAY UNIT, MODEL 4





Dimensions— Inches: Centimeters:	Width 58.5 149	Depth 64 .5 164	Height 50 127	
Service Clearance Inches: Centimeters:	Front 30 76	Rear O O	Left 40 102	Right 30 76
Maximum Weight	380 lb (1	72 kg)		
Heat Output/hr	3,000 BT	U (756 kcal)		
Air Flow	420 cfm ((11,9 m ³ /m)	maximum	

Electrical Requirements--

15 amp R&S #FS 3720 R&S #FS 3743 R&S #FS 3913 208/230 ± 10% Voltage: Service: Frequency: 60 ± 0.5 Hz Plug: Phases: Receptacle: KVA: 1.0 Connector:

Operating Environment—
Temperature: 60° to 90°F (15.6° to 32.2°C)

Rel Humidity: 8% to 80% Max Wet Bulb: 78°F (25.6°C)


Nonoperating Environment— Temperature: 50° to 110°F (10° to 43°C)

Rel Humidity: 8% to 80% Max Wet Bulb: 80°F (26.7°C)

Form A26-5914-3 Page Added 8/11/67 By TNL N26-0198

(This page intentionally left blank.)

IBM 2310 DISK STORAGE, MODELS B1 AND B2



Front

Dimensions	Width	Depth	. He	eight
Inches:	22	30	4	4
Centimeters:	56	76	11	2
Service Clearance	Front	Rear	Left (* 1)	Right (* 1)
Inches:	30	30	24	24
Centimeters:	76	76	61	61

Maximum Weight--365 lb (165 kg)

Heat Output/hr.--1800 BTU (454 kcal)

Air Flow--75 cfm (2 m³/m) maximum

(*2) Electrical Requirements--

Operating Environment--

Temperature: 60° to 90° F (15.6° to 32.2° C)

Rel. Humidity: 10% to 80% Max. Wet Bulb: 78° F (25.6° C)

Nonoperating Environment--

Temperature: 50° to 110° F (10° to 43° C)

Rel. Humidity: 8% to 80% Max. Wet Bulb: 85° F (29.4° C)


*Notes:

27074

- 1. Side clearance not required when abutted to units of like construction.
- 2. Power is supplied by the 1133.

IBM 2501 CARD READER, MODELS A1 AND A2





Dimensions	Width	Dep	oth	Height		
Inches:	30	24		45		
Centimeters:	76	61		114		
Service Clearance	Front	Rear	Left	Right		
Inches:	36	36	6	24		
Centimeters:	91	91	15	61		

Maximum Weight--340 lb (154 kg)

Heat Output/hr.--700 BTU (176 kcal)

Air Flow--0 cfm (0 m³/m) maximum

(* 1) Electrical Requirements--

KVA: 0.3

Operating Environment--

Temperature: 50° to 90° F (10° to 32.2° C)

Rel. Humidity: 20% to 80% Max. Wet Bulb: 78° F (25.6° C)

Nonoperating Environment--


Temperature: 50° to 110° F (10° to 43° C)


Rel. Humidity: 8% to 80% Max. Wet Bulb: 80° F (26.7° C)

*Notes:

1. Power is supplied by the 1131.

IBM 1055 PAPER TAPE PUNCH





8.0	20,3
11.0	27,9
15.37	39,0
17.12	43,4

15718A

Dimensions	(* 1)	Width	Depth	Height
Inches:		15.375	17.125	8.25
Centimeters:		39	44	21

Service Clearance	Front	Rear	Left	Right
Inches:	12	12	12	12
Centimeters:	30	30	30	30

Maximum Weight--26 lb (12 kg)

Heat Output/hr.--150 BTU (38 kcal)

Air Flow--0 cfm (0 m³/m) maximum

(*2) Electrical Requirements--

KVA: 0.06

Operating Environment--

Temperature: 50° to 110° F (10° to 43° C)

Rel. Humidity: 10% to 80% Max. Wet Bulb: 80° F (27° C)

Nonoperating Environment--


Temperature: 50° to 110° F (10° to 43° C)


Rel. Humidity: 10% to 80% Max. Wet Bulb: 80° F (27° C)

*Notes:

- 1. With tape reels.
- 2. Power is supplied by the 1131.

IBM 1403 PRINTER, MODELS 6 AND 7





Dimensions	Width	Dep	oth	Height
Inches:	47.75	28.	50	53.25
Centimeters:	121	72		135
Service Clearance	Front	Rear	Left	Right
Inches:	36	36	30	30
Centimeters:	91	91	<i>7</i> 6	76

Maximum Weight--750 lb (340 kg)

Heat Output/hr.--2500 BTU (630 kcal)

Air Flow--310 cfm (9 m³/m) maximum

(*1) Electrical Requirements--

KVA: 1.0

Operating Environment--

Temperature: 60° to 90° F (15.6° to 32.2° C)

Rel. Humidity: 20% to 80% Max. Wet Bulb: 78° F (25.6° C)

Nonoperating Environment--


Temperature: 50° to 110° F (10° to 43° C)


Rel. Humidity: 0% to 80% Max. Wet Bulb: 80° F (26.7° C)

*Notes:


1. Power is supplied by the 1133.

IBM 1627 PLOTTER, MODELS 1 AND 2





Inches = Centimeters					
15.0	38,1				
18.0	45,7				
40.0	101,6				



15706A

Dimensions	Width	Dep	oth	Height	
Inches:	18	15		10	Model 1
Centimeters:	46	38		25	Model
Inches:	40	15		10	Model 2
Centimeters:	102	38		25	Wodel 2
Service Clearance	Front	Rear	Left	Right	
Inches:	12	12	12	12	
Centimeters:	30	30	30	30	
	no II /15				

Maximum Weight--33 lb (15 kg) Model 1 Maximum Weight--55 lb (25 kg) Model 2

Heat Output/hr.--250 BTU (63 kcal)

Air Flow--0 cfm (0 m³/m) maximum

(*1) Electrical Requirements--

KVA: 0.1

Operating Environment--

Temperature: 60° to 90° F (15.6° to 32.2° C)

Rel. Humidity: 20% to 80% Max. Wet Bulb: 78° F (25.6° C)

Nonoperating Environment--


Temperature: 50° to 110° F (10° to 43° C)

Rel. Humidity: 0% to 80% Max. Wet Bulb: 85° F (29.4° C)

1. Power is supplied by the 1131.

AUXILIARY TABLE





Dimensions	Width	Dep	Depth (* 1)	
inches:	32	23		27
Centimeters:	81	58		69
Service Clearance	Front	Rear	Left	Right
Inches:	12	12	12	12
Centimeters:	30	30	30	30

Maximum Weight--30 lb (13.6 kg)

This table is available from IBM, but is not standard with the IBM 1130 System. It is for use with the 1134, 1055, and 1627 Model 1 units.

*Notes:

This dimension is decreased 3" (7,6 cm) when the lower shelf is repositioned to the rear.

• APPENDIX A. PHYSICAL PLANNING, SUMMARY OF SPECIFICATIONS

			Ele	ctrical	Enviror	mental			Dimensions			Service Clearances			
Туре	Model	Name	KVA	Conn.	BTU/Hr	CFM Weight			(inches)		(inches)			Notes	
				Туре*	010/11	Cim	(lbs.)	Width	Depth	Height	F	R	L	Rt	
1131	1A,1B 2A,2B	Central Processing Unit	1.1	A or D	3100	720	660	58.25	29	46.5	42	36	_	30	1,2
1131	2C,2D 3B,3C 3D	Central Processing Unit	1.5	А	4200	1000	1050	88.25	29	46.5	42	36	30	30	1,2
1055	-	Paper Tape Punch	0.06	-	150	-	26	15.375	17.125	8.25	12	12	12	12	3
1132	-	Printer	0.5	-	1300	80	<i>7</i> 00	47	29.50	42	36	30	30	30	3
1133	-	Multiplex Control Enclosure	1.1	С	3400	500	1100	32	45.50	60	30	30	42	30	
1134	1,2	Paper Tape Punch	0.06	-	150	-	15	19	8.75	8.75	30	12	6	6	3
1231	1	Optical Mark Page Reader	1.2	Α	3700	300	620	43.50	24	44.75	42	42	36	30	2
1403	6,7	Printer	1.0	-	2500	310	750	47.75	28.50	53.25	36	36	30	30	4
1442	5	Card Punch	0.7	-	1800	50	525	43	24	49	36	30	18	6	3
1442	6,7	Card Read Punch	0.6	-	1500	50	525	43	24	49	36	30	18	6	3
1627	1	Plotter	0.1	_	250	-	33	18	15	10	12	12	12	12	3
1627	2	Plotter	0.1	-	250	-	55	40	15	10	12	12	12	12	3
2310	B1,B2	Disk Storage	0.7	-	1800	75	365	22	30	44	30	30	24	24	4
2501	A1,A2	Card Reader	0.3	-	700	-	340	30	24	45	36	36	6	24	3
2250	4	Display Unit	1.0	Α	3000	420	380	58.5	64.5	50	30	0	40	30	

Notes:

- 1. The base of the Processor is 31.50 inches high, the console adds another 13.50 inches for a total height of 45 inches.
- 2. This unit is equipped with radio interference control circuitry and requires a good wired earth or building ground. Total resistance of the ground conductor, measured between the receptacle and the building grounding point, must not exceed 3 ohms. For proper operation, all components of the system or systems to which this unit is attached must have the same ground reference. Conduit is not a satisfactory means of grounding. When an 1133 is installed, an 1131 branch circuit is not required.
- Powered from 1131.
- 4. Powered from 1133.

* Type	Plug	Connector	Receptacle	Rating	Voltage
Α	Russell & Stoll, FS3720	FS3913	FS3743	20 amp, 1 phase, 3 wire	208/230
С	Russell & Stoll, FS3760	FS3934	FS3754	30 amp, 3 phase, 4 wire	208/230
D	Hubbell #9338		#9344	30 amp, 1 phase, 3 wire	115

23103H



• APPENDIX B. SUMMARY OF SPECIFICATIONS (METRIC)

					Environmental			Dimensions			Service				
Type Model	Model	Name	KVA	Conn Type	Kcal M ³ /N	3	Weight (Kg)	(Centimeters)			Clearances (Centimeters)				Notes
						M°/M		Width	Depth	Height	F	R	L	RT	
1131	1A,1B 2A,2B	Central Processing Unit	1.1	A or D	<i>7</i> 81	20,7	299	148	74	118	107	91	-	76	1,2
1131	2C,2D 3B,3C 3D	Central Processing Unit	1.5	A	1058	28,3	477	224	74	118	107	91	76	76	1,2
1055	-	Paper Tape Punch	0.06	_	37,8	-	16,3	40	44	21	30	30	30	30	3
1132	-	Printer	0.5	-	328	2,26	317 , 5	119	<i>7</i> 5	107	91	76	76	76	3
1133	-	Multiplex Control Enclosure	1.1	С	857	14,2	499	81	116	152	76	76	107	76	
1134	1,2	Paper Tape Punch	0.06	-	37,8	-	6,8	48	22	22	76	30	15	15	3
1231	ī	Optical Mark Page Reader	1.2	Α	932	8,49	281	110	61	114	107	107	91	76	2
1403	6,7	Printer	1.0	-	630	8,77	340	121	72	135	91	91	76	76	4
1442	5	Card Punch	0.7	-	454	1,42	238	109	61	124	91	76	46	15	3
1442	6,7	Card Read Punch	0.6	-	378	1,42	238	109	61	124	91	76	46	15	3
1627	1	Plotter	0.1	_	63	-	15	46	38	2,5	30	30	30	30	3
1627	2	Plotter	0.1	_	63	_	24,9	102	38	2,5	30	30	30	30	3
2310	B1,B2	Disk Storage	0.7		454	2,12	165	56	76	112	76	76	61	61	4
2501	A1,A2	Card Reader	0.3	-	17,6	-	154	76	61	114	91	91	15	61	3
2250	4	Display Unit	1.0	A	756	11,9	172	149	164	127	76	0	102	76	

Notes:

- 1. The base of the Processor is 80 centimeters high, the console adds another 34, 29 centimeters for a total height of 114,3 cm.
- 2. This unit is equipped with radio interference control circuitry and requires a good wired earth or building ground. Total resistance of the ground conductor, measured between the receptacle and the building grounding point, must not exceed 3 ohms. For proper operation, all components of the system or systems to which this unit is attached must have the same ground reference. Conduit is not a satisfactory means of grounding. When an 1133 is installed, an 1131 branch circuit is not required.
- 3. Powered from 1131.
- 4. Powered from 1133.

27077 C

Auxiliary Table 20 IBM 1442 Card Punch, Model 5 14 IBM 1442 Card Read Punch, Models 6 and 7 14 Cable Resistance 6 IBM 1627 Plotter, Models 1 and 2 19 Cables 4 IBM 2310 Disk Storage, Models B1 and B2 15 Convenience Outlets 4 IBM 2501 Card Reader, Models A1 and A2 16 Coupled Noise 6 Installation Requirements and Scheduling 1 Dust and Dirt Control 3 Lightning Protection 4 Environmental Requirements 3 One Week before Machine Delivery 3 Fire Protection Equipment 3 Phase Rotation 4 Four Months before Delivery 1 Power Distribution 3 Power Requirements 3 Grounding 4 Power Sequence for Storage Access Channel Devices 6 IBM Field Engineering Requirements 6 Power Supply 3 IBM 1055 Paper Tape Punch 17 IBM 1131 Central Processing Unit, Models Scheduling 1 1A, 1B, 2A and 2B 8 Six Months before Delivery 1 IBM 1131 Central Processing Unit, Models 2C, Storage Access Channel 4 2D, 3B, 3C, and 3D 9 Storage Access Channel Cable 4 IBM 1132 Printer 10 Synchronous Communications Adapter 6 IBM 1133 Multiplex Control Enclosure 11 System Arrangement and Space Requirements 1 IBM 1134 Paper Tape Reader 12

IBM 1403 Printer, Models 6 and 7 18

Unit Specifications 7

Ambient Air Conditions 3

IBM 1231 Optical Mark Page Reader, Model 1 13

Technical Newsletter

File Number 1130-15

Re: Form No. A26-5914-3

This Newsletter No. N26-0204

9/13/67 Date

Previous Newsletter Nos. N26-0195 Obsolete

N26-0197 Obsolete

N26-0198

This newsletter updates the SRL publication IBM 1130 Computing System Installation Manual - Physical Planning (Form A26-5914-3). Changes and additions to the text are indicated by a vertical bar in the margin to the left of the change. Figures that have been changed are indicated by a bullet (•) to the left of the figure title.

Replace these pages:

This newsletter covers changes made in electrical requirements in all models of the 1131 Central Processing Unit. All machines will be shipped with Russell & Stoll plug, FS 3720, unless RPQ #S50005 is ordered.

File this letter at the back of the publication. It will then serve as a record of changes received and incorporated.

READER'S COMMENT FORM

A26-5914-3

1130 Installation Manual -- Physical Planning

 Your comments, accompanied by answers to the publications for your use. If your answer to 	•	
please explain in the space provided below. Con IBM.	•	4 •
	Yes	No
Does this publication meet your needs?		
Did you find the material:		
Easy to read and understand?		
Organized for convenient use?		
Complete?		
Well illustrated?		
Written for your technical level?		
What is your occupation?		
How do you use this publication?		
As an introduction to the subject?		As an instructor in a class?
For advanced knowledge of the subject?		As a student in a class?
For information about operating procedures?		As a reference manual?
Other		
Please give specific page and line references v	vith your	comments when appropriate.

COMMENTS

• Thank you for your cooperation. No postage necessary if mailed in the U.S.A.

fold

fold

FIRST CLASS PERMIT NO. 2078 SAN JOSE, CALIF.

BUSINESS REPLY MAIL

NO POSTAGE STAMP NECESSARY IF MAILED IN U. S. A.

POSTAGE WILL BE PAID BY . . .

IBM Corporation Monterey & Cottle Rds. San Jose, California 95114

Attention: Product Publications, Dept. 455

fold

fold

IBM

International Business Machines Corporation Data Processing Division 112 East Post Road, White Plains, N.Y. 10601 [USA Only]

IBM World Trade Corporation 821 United Nations Plaza, New York, New York 10017 [International]

IBM

International Business Machines Corporation Data Processing Division 112 East Post Road, White Plains, N.Y. 10601 [USA Only]

IBM World Trade Corporation 821 United Nations Plaza, New York, New York 10017 [International]