

11-11-11

1

2

3

4

5

6

7

8

9

10

11

```
$SAVE
$NDLIST
```

```
/*
 * ASTLIB.H
```

```
 * This header describes the public entries in
 * the assembly language assist library, ASTLIB.
 */
```

```
D$XMITC:      PROCEDURE(C)      BYTE;      EXTERNAL;
DECLARE
END;
```

```
FLAGS:        PROCEDURE
END;          WORD EXTERNAL;
```

```
$
IF EXTENDED_MONITOR
OFB:          PROCEDURE(base, offset)
DECLARE      base      WORD,
             offset    WORD;
             WORD;
END;
ENDIF
```

```
INCB:         PROCEDURE(byte$ptr)
DECLARE      byte$ptr  POINTER;
END;          EXTERNAL;
```

```
$
IF EXTENDED_MONITOR
SFB:         PROCEDURE(val, base, offset)
DECLARE      val      BYTE,
             base     WORD,
             offset    WORD;
             WORD;
END;
ENDIF
```

```
$XMITC:       PROCEDURE(C)      BYTE;      EXTERNAL;
DECLARE
END;
```

```
VIDEO_INTR_A: PROCEDURE
END;          EXTERNAL;
```

```
XEC:          PROCEDURE(reg$pp)  POINTER;  EXTERNAL;
DECLARE      reg$pp
END;
```

```
INIT_ITV:     PROCEDURE(ivi, ivp)
DECLARE      ivi      BYTE,
             ivp      POINTER;
             EXTERNAL;
END;
```

```
$RESTORE
```

```
$SUBTITLE('Compiler Controls')
$OPTIMIZE(3)
$NOOVERFLOW
$COMPACT
$ROM
$XREF
$LARGE( MTR100 EXPORTS MTR_MON;
EXPORTS MTR_MON;
EXPORTS MTR_SWIM;
EXPORTS MTR_DCRT;
EXPORTS MTR_DCRD;
EXPORTS MTR_SCRT;
EXPORTS MTR_SKBD;
EXPORTS MTR_TTY_INTR;
EXPORTS MTR_TTY_POLL;
EXPORTS MTR_IRET)
$LARGE( VIDEOA EXPORTS MTR_DCI;
EXPORTS MTR_DFC;
EXPORTS MTR_EDC;
EXPORTS MTR_FONT;
EXPORTS MTR_MDC;
EXPORTS MTR_MDL;
EXPORTS MTR_PROMPT;
EXPORTS MTR_RDC;
EXPORTS MTR_UIES;
EXPORTS MTR_XCA)
$LARGE( FONT EXPORTS MTR_FONT)
$LARGE( ASTLIB EXPORTS VIDEO_INTR_A)
$RESET(EXTENDED_MONITOR)
```

```

DC DC CR_DSAL LT '0DH' /* Start Low */;
DC DC CR_CSAH LT '0EH' /* Cursor Start High */;
DC DC CR_CSAL LT '0FH' /* Cursor Start Low */;

/*
 * Cursor Start Register Fields
 */
DC DC CSR_CSD LT '00#1111B' /* Cursor Start Display */;
DC DC CSR_OFF LT '01#00000B' /* Disable Cursor Disp */;
DC DC CSR_BLINK16 LT '10#000000B' /* Blink at 1/16 Field */;
DC DC CSR_BLINK LT '11#000000B' /* Blink/Enable Field */;

```

#RESTORE

1\$SAVE
\$NOLIST

DECLARE HEX_DIGIT(*) BYTE EXTERNAL DATA;

ORLF: PROCEDURE
END;

EXTERNAL;

\$IF 1=2
ORW: PROCEDURE(base, offset)
DECLARE base WORD,
offset WORD;
END;
\$ENDIF

WORD EXTERNAL;

\$IF EXTENDED_MONITOR
HOTB: PROCEDURE(char)
DECLARE char BYTE;
END;
\$ENDIF

BYTE EXTERNAL;

\$IF EXTENDED_MONITOR
IHC: PROCEDURE(delim)
DECLARE delim BYTE;
END;
\$ENDIF

BYTE EXTERNAL;

\$IF EXTENDED_MONITOR
IHV: PROCEDURE(delim, val\$p, size)
DECLARE delim BYTE,
val\$p POINTER,
size BYTE;
END;
\$ENDIF

BYTE EXTERNAL;

MOU: PROCEDURE(char)
DECLARE char BYTE;
END;

BYTE EXTERNAL;

\$IF EXTENDED_MONITOR
OHB: PROCEDURE(dat)
DECLARE dat BYTE;
END;
\$ENDIF

EXTERNAL;

\$IF EXTENDED_MONITOR
OHC: PROCEDURE(dat)
DECLARE dat BYTE;
END;
\$ENDIF

EXTERNAL;

\$IF EXTENDED_MONITOR
OHM: PROCEDURE(dat)
DECLARE dat WORD;
END;

EXTERNAL;

!\$SAVE
!NOCLIST

GLOBAL.H

GLOBAL-DEF is an include file to define all of
the global values in the data segment. This
file should be included in only one source file
to avoid multiple definitions. To define all
of these variables as external to some other
module, include GLOBAL.H.

Monitor Parameters

```
DC CODE_SEG      LT      /* Code Segment      */  
DC MTR_VERSION  LT      /* Version 1.2     */  
DC MTR_ISSUE    LT      /* Issue #nn       */
```

```
DC WIR(S)       BYTE     /* Jump Far to Wild Interrupt Routine */  
DC VERSION      BYTE     /* BCD Version Identification for ROM */  
DC DS_SIZE      WORD     /* Data Segment Size in bytes        */
```

Boot Parameters

```
DC BOOT_PAR     STRUCTURE ( /* Device Index      */  
    INDEX        BYTE, /* Base Port Address */  
    PORT         BYTE, /* Parameter String Passed */  
    STRNG(S0)   BYTE, /* Unit of device booted */  
    UNIT        BYTE  
) EXTERNAL;
```

RAM Vectors for parametrized routines.

```
DC DCI          POINTER  /* Display Character Initialization    */  
DC DFC          POINTER  /* Display Font Character             */  
DC D_XMTC       POINTER  /* Dumb Keyboard Transmit Character   */  
DC EDC          POINTER  /* Erase Display Character            */  
DC EMDG         POINTER  /* Extended-Mode Escape Character    */  
DC FONT        POINTER  /* Character FONT Address              */  
DC MDC          POINTER  /* Move Display Characters             */  
DC              EXTERNAL;
```

```

) EXTERNAL;
DC CRT0_DISPLAY STRUCTURE (
  START WORD, /* CRT-C Display Start Address */
  UPDATE BOOL, /* True if Update is required */
) EXTERNAL;
DC ESCP STRUCTURE (
  COMMAND BYTE, /* Current Escape Command */
  FUNCTION WORD, /* Pointer to Escape Processor */
  MODE BYTE, /* Escape Emulation Mode */
  OPER_COUNT BYTE, /* Operand Count */
  OPER_INDEX BYTE, /* Operand Index */
  OPERAND(4) BYTE, /* Operands */
) EXTERNAL;
DC H19_MODE STRUCTURE (
  ALTERNATE BOOL, /* Alternate Key-Pad Mode */
  ANSI BOOL, /* ANSI-Mode */
  AUTO_CR BOOL, /* Auto Carriage-Return on LF */
  AUTO_LF BOOL, /* Auto Line-Feed on CR */
  AUTO_REPEAT BOOL, /* Auto-Repeat Keyboard */
  BMD BOOL, /* Black and White Optimization */
  CURSOR BYTE, /* Cursor Program Value */
  CURSOR_ON BOOL, /* Cursor Enabled */
  EXPAND BOOL, /* Expand Keyboard Characters */
  GRAPHIC BOOL, /* Graphic Character Mode */
  INSERT BOOL, /* Insert Character Mode */
  KEY_EN BOOL, /* Key-Board Enabled */
  REVERSE WORD, /* Reverse Video */
  /* @0000H for normal video
  /* @FFFFH for reverse video
  SHIFTED BOOL, /* Shifted Key-Pad Mode */
  STATUS BOOL, /* Status Line Enabled */
  UPDN BOOL, /* Key-Board Up/Down Mode */
  WRAP BOOL, /* Wrap Line at End-of-Line */
) EXTERNAL;
DC H19_PAR STRUCTURE (
  CPL BYTE, /* Characters Per Line */
  DSC BYTE, /* Displayed Scan Lines/Char */
  LPS BYTE, /* Lines Per Screen */
  PPOVRAM BYTE, /* Lines Per Screen */
  SLI BYTE, /* Lines Per Screen */
  SPC BYTE, /* Status Line Index */
  SW401 BYTE, /* Scan Line per Character */
  SW402 BYTE, /* H-19 Switch 401 */
  VRAM_SIZE BYTE, /* H-19 Switch 402 */
  /* @-32KBytes, 1-64KBytes
) EXTERNAL;
DC XMT STRUCTURE (
  BURST BYTE, /* Char. to XMT per VSYNC */
  BURST_COUNT INTEGER, /* Remaining Char. in Burst */
  COUNT WORD, /* Characters to Transmit */
  COL BYTE, /* Horizontal Column to XMT */
  ROW BYTE, /* Vertical Row to XMT */
  COLOR BYTE, /* State of COLOR XMT'd */
  GRAPHIC BOOL, /* State of GRAPHIC XMT'd */
  REVERSE BOOL, /* State of REVERSE XMT'd */
) EXTERNAL;

```

\$RESTORE

\$SAVE
\$NOLIST

/*
*
* I3085.H

I3085.H defines hardware attributes of the
Intel 8085 micro-processor.

*/

DC	F86_OF	LT	'1000#0000#0000B';	/* Overflow	*/
DC	F86_DF	LT	'0100#0000#0000B';	/* Direction	*/
DC	F86_IF	LT	'0010#0000#0000B';	/* Interrupt En	*/
DC	F86_TF	LT	'0001#0000#0000B';	/* Trap	*/
DC	F86_SF	LT	'0000#1000#0000B';	/* Sign	*/
DC	F86_ZF	LT	'0000#0100#0000B';	/* Zero	*/
DC	F86_AF	LT	'0000#0001#0000B';	/* Aux. Carry	*/
DC	F86_PF	LT	'0000#0000#0100B';	/* Parity	*/
DC	F86_CF	LT	'0000#0000#0001B';	/* Carry	*/

\$RESTORE

SSAVE
\$NOLIST

/*
INIT.H

INIT.H defines the global initialization
routines in INIT.PLM
#

*/

! IF EXTENDED_MONITOR
INIT_8259_85: PROCEDURE EXTERNAL;
END;
! ENDIF

INIT_8259_89: PROCEDURE EXTERNAL;
END;

\$RESTORE

\$SAVE
\$NDLIST

\$ IF EXTENDED_MONITOR

I2661: PROCEDURE(base) EXTERNAL;
 DECLARE base WORD;
END;

RCHAR: PROCEDURE(base) BYTE EXTERNAL;
 DECLARE base WORD;
END;

TCHAR: PROCEDURE(base) BOOL EXTERNAL;
 DECLARE base WORD;
END;

WCHAR: PROCEDURE(base, char) EXTERNAL;
 DECLARE base WORD,
 char BYTE;
END;

\$ ENDIF
\$RESTORE

```

DC      ICM4_AE01      LT      '0000$0010B'      /* Auto. End Of Int.      /*;
DC      ICM4_86      LT      '0000$0001B'      /* MCS-86 Operation      /*;

/*
*/
*/      Output Control Words

DC      OCM1_M7      LT      '1000$0000B'      /* Mask Level 7      /*;
DC      OCM1_M6      LT      '0100$0000B'      /* Mask Level 6      /*;
DC      OCM1_M5      LT      '0010$0000B'      /* Mask Level 5      /*;
DC      OCM1_M4      LT      '0001$0000B'      /* Mask Level 4      /*;
DC      OCM1_M3      LT      '0000$1000B'      /* Mask Level 3      /*;
DC      OCM1_M2      LT      '0000$0100B'      /* Mask Level 2      /*;
DC      OCM1_M1      LT      '0000$0010B'      /* Mask Level 1      /*;
DC      OCM1_M0      LT      '0000$0001B'      /* Mask Level 0      /*;
DC      OCM1_ALL     LT      '1111$1111B'      /* Mask ALL Levels      /*;

DC      OCM2_ROT     LT      '1000$0000B'      /* Rotate      /*;
DC      OCM2_SEOI    LT      '0100$0000B'      /* Specific EOI      /*;
DC      OCM2_EOI     LT      '0010$0000B'      /* End Of Interrupt      /*;
DC      OCM2_OCM2    LT      '0000$0000B'      /* OCM2 Identifier      /*;
DC      OCM2_L2      LT      '0000$0100B'      /* SEOI Interrupt Level /*;
DC      OCM2_L1      LT      '0000$0010B'      /* SEOI Interrupt Level /*;
DC      OCM2_L0      LT      '0000$0001B'      /* SEOI Interrupt Level /*;

DC      OCM3_ESMM    LT      '0100$0000B'      /* Enable Special Mask /*;
DC      OCM3_SMM     LT      '0010$0000B'      /* Special Mask Mode   /*;
DC      OCM3_OCM3    LT      '0000$1000B'      /* OCM3 Identifier     /*;
DC      OCM3_POLL    LT      '0000$0100B'      /* Enable Polling      /*;
DC      OCM3_SRIS    LT      '0000$0010B'      /* */;

$RESTORE

```

!SAVE
\$NOLIST

/*
*
* KEYDEF.H

This header file defines the bits and offsets pertinent to the key-board processor.

*/

/*
* Port Definitions

DC KEY_CMND LT 'IO_KEYBRD+1' /* Command **/
DC KEY_DATA LT 'IO_KEYBRD+0' /* Data **/
DC KEY_STAT LT 'IO_KEYBRD+1' /* Status **/
*/

/*
* Status Bit Definitions

DC KS_CXRDY LT '001B' /* Character is ready **/
DC KG_RXRDY LT '010B' /* Receiver Ready **/
*/

/*
* Command Definitions

DC KC_ARE LT '02H' /* Auto-Repeat OFF **/
DC KC_ARO LT '01H' /* Auto-Repeat ON **/
DC KC_BEP LT '07H' /* Beep **/
DC KC_DI LT '0DH' /* Disable Interrupts **/
DC KC_EI LT '0CH' /* Enable Interrupts **/
DC KC_KCF LT '04H' /* Key Click OFF **/
DC KC_KCO LT '03H' /* Key Click ON **/
DC KC_CFI LT '05H' /* Clear FIFO **/
DC KC_CLK LT '06H' /* Click **/
DC KC_KBD LT '09H' /* Key-Board DISABLE **/
DC KC_KBE LT '08H' /* Key-Board ENABLE **/
DC KC_MNS LT '0BH' /* Normal Scan Mode **/
DC KC_MUD LT '0AH' /* Key Up/Down Mode **/
DC KC_RES LT '00H' /* Reset **/
*/

/*
* Key Code Definitions

DC KY_ENTER LT '08DH' /* Enter **/
DC KY_HELP LT '075H' /* HELP **/
DC KY_F0 LT '076H' /* F0 **/
DC KY_F12 LT '0A2H' /* F12 **/
DC KY_ID_CHAR LT '0A3H' /* Insert/Delete Char. **/
DC KY_ID_LINE LT '0A4H' /* Insert/Delete Line **/
DC KY_UP LT '0A5H' /* Arrow Up **/
DC KY_DOWN LT '0A6H' /* Arrow Down **/
DC KY_RIGHT LT '0A7H' /* Arrow Right **/
DC KY_LEFT LT '0A8H' /* Arrow Left **/
DC KY_HOME LT '0A9H' /* Home **/
*/

\$SAVE
\$NOLIST

/*
* LEXCAL.H

LEXCAL.H defines a number of standard lexical
headers.

*/

DECLARE DC LITERALLY 'DECLARE';
DECLARE LT LITERALLY 'LITERALLY';

DC BOOL LT 'BYTE' /* Boolean Variables */;

DC FALSE LT '000H' /* Boolean False */;

DC TRUE LT '0FFH' /* Boolean True */;

\$RESTORE

\$SAVE
\$NDLIST

/*
* MTR100.H
*
* MTR100.H is the file defining the globals to
* be found in MTR100.A86.
*
*/

MTR_SORT: PROCEDURE EXTERNAL;
END;

MTR_SKED: PROCEDURE EXTERNAL;
END;

MTR_TTY_INTR: PROCEDURE EXTERNAL;
END;

MTR_TTY_POLL: PROCEDURE BOOL EXTERNAL;
END;

MTR_IRET: PROCEDURE EXTERNAL;
END;

\$ IF EXTENDED_MONITOR
R3085: PROCEDURE EXTERNAL;
END;
\$ ENDIF

SOS: PROCEDURE EXTERNAL;
END;

\$RESTORE

\$SAVE
\$NOLIST

/*
* SSWDEF.H

* SSWDEF.H defines the H-17 compatible software
* switch settings.
*/

DC

SM_401_BLOCK_CURSOR LT /* Block Cursor */
SM_401_KEY_CLICK LT /* Key Click */
SM_401_WRAP_LINE LT /* Wrap Line at Right-Hand Margin*/
SM_401_AUTO_LF LT /* Auto Line-Feed on Carriage-Return*/
SM_401_AUTO_CR LT /* Auto Carriage-Return on Line-Feed*/
SM_401_ANSI LT /* ANSI Escape Processing Mode */
SM_401_SHIFTED LT /* Key-Pad shifted Mode */
SM_401_50HZ LT /* 50-Hertz CRT Refresh */

DC

SM_402_BAUD_RATE LT /* Baud Rate */
SM_402_PARITY_ENABLE LT /* Parity Enable */
SM_402_ODD_PARITY LT /* Odd Parity */
SM_402_STICK_PARITY LT /* Stick Parity */
SM_402_FULL_DUPLEX LT /* Full Duplex */

\$RESTORE


```

$SAVE
$NDLIST

/*
 *      SURLIB.H
 *
 *      This file describes the global Subroutine Library
 *      entry points.
 *
 */

$ IF EXTENDED_MONITOR
IHA:      PROCEDURE(delim,addr$p)          BYTE EXTERNAL;
DECLARE   delim      BYTE,
          addr$p     POINTER;
END;
$ ENDIF

$ IF 1=2
IHA:      PROCEDURE(base$p,offset$p)      EXTERNAL;
DECLARE   base$p     POINTER,
          offset$p   POINTER;
END;
$ ENDIF

$ IF EXTENDED_MONITOR
IRI:      PROCEDURE
END;
$ ENDIF          BYTE EXTERNAL;

$ IF EXTENDED_MONITOR
OHA:      PROCEDURE(addr$p)              EXTERNAL;
DECLARE   addr$p     POINTER;
END;
$ ENDIF          EXTERNAL;

$ IF EXTENDED_MONITOR
RNC:      PROCEDURE(delim)              BYTE EXTERNAL;
DECLARE   delim      BYTE;
END;
$ ENDIF          EXTERNAL;

$ IF EXTENDED_MONITOR
RUBOUT:   PROCEDURE
END;
$ ENDIF          EXTERNAL;

$RESTORE

```

```
XMTSC:
DECLARE
PROCEDURE (row, col, count)
row
col
count
BYTE,
BYTE,
WORDS;

END;

$RESTORE

EXTERNAL;
```

\$RESTORE

;; E2661 - EPCI 2661

;; The following definitions are for the Signetics
;; 2661 EPCI (Enhanced Programmable Communications
;; Interface).
;;

```
SR RECORD DSR:1,DCD:1,FE_SYN:1,OVNR:1,PE_DLE:1,TEMT_DSCHG:1,RXRDY:1, TXRDY:1
EP_RHR EQU 0 ; Receiver Holding Register
EP_THR EQU 0 ; Transmitter Holding Register
EP_STA EQU 1 ; Status Register
EP_SYN1 EQU 1 ; SYN1
EP_SYN2 EQU 1 ; SYN2
EP_DLE EQU 1 ; DLE
EP_MR1 EQU 2 ; Mode Register 1
EP_MR2 EQU 2 ; Mode Register 2
EP_CR EQU 3 ; Command Register
CONSOL EQU 0ESH ; Console 2661
```

```

EXTRN   CR-LF:NEAR          ; PL/M-86 CR-LF
EXTRN   INIT:NEAR         ; PL/M-86 Initialize Hardware
EXTRN   WRITEC:NEAR      ; PL/M-86 Write Character
ENDS
)FI

```

```

%IF(%NES(DATA,%SEGMENT_LABEL)) THEN (
DATA
  SEGMENT WORD PUBLIC 'DATA'
  EXTRN   HORZ_CHAR:BYTE   ; Column Index
  EXTRN   VERT_LINE:BYTE  ; Row Index
  EXTRN   REGP:DWORD      ; Pointer to Saved Processor Registers
  EXTRN   RESETF:BYTE     ; Hardware Reset Flag

  EXTRN   DCI:DWORD       ; Display Character Initialization
  EXTRN   DFC:DWORD       ; Display Font Character
  EXTRN   D_XMTC:DWORD    ; Dumb Terminal Transmit Character
  EXTRN   EDC:DWORD       ; Erase Display Character
  EXTRN   EMEC:DWORD      ; Extend-Mode Escape Character
  EXTRN   FONT:DWORD      ; Pointer to Font Table
  EXTRN   MDC:DWORD       ; Move Display Character
  EXTRN   MDL:DWORD       ; Move Display Line
  EXTRN   PROMPT:DWORD    ; Display Monitor Prompt
  EXTRN   RDC:DWORD       ; Read Display Character
  EXTRN   S_XMTC:DWORD    ; Smart Terminal Transmit Character
  EXTRN   UIES:DWORD      ; Un-Implemented Escape Sequence
  EXTRN   XCA:DWORD       ; Transmit Character Attributes

```

```

  EXTRN   BOOT_PAR:BOOT_PAR_STRUC
  EXTRN   COLOR:COLOR_STRUC
  EXTRN   CRTC_CURSOR:CRTC_STRUC
  EXTRN   CRTC_DISPLAY:CRTC_STRUC
  EXTRN   ESCP:ESCP_STRUC
  EXTRN   H19_MODE:H19_MODE_STRUC
  EXTRN   H19_PAR:H19_PAR_STRUC
  EXTRN   XMT:XMT_STRUC
ENDS
DATA
)FI

```

```

%IF(%NES(VIDEQA,%SEGMENT_LABEL)) THEN (
VIDEQA
  SEGMENT BYTE PUBLIC 'CODE'
  ENDS
)FI

```

```

GROUP   GROUP   MTR100, CODE, ASTLIB, VIDEQA

```

```

#RESTORE

```

```
;$EJECT
; Interrupt Usage
```

```
;
; This common deck defines the MTR-100 Interrupt
; usage. Note that the interrupt vector for int-
; erupt 255 is used to store a global data seg-
; ment value. This is somewhat undesirable to
; reserve such a location, however, since all
; other values are indexed off of it, it seems
; alright. The offset must be zero so that any
; spurious interrupts will jump to the first addr-
; ess of the data segment. If these interrupts
; are to be handled, the data segment vector may
; be patched.
;
```

```
INTVEC SEGMENT PARA AT PAR_INT
```

```
ITV_DBZ DD 1 DUP(?) ; Divide by zero Interrupt
ITV_SST DD 1 DUP(?) ; Single Step
ITV_NMI DD 1 DUP(?) ; Non-Maskable Interrupt
ITV_OBI DD 1 DUP(?) ; One Byte Instruction
ITV_I0V DD 1 DUP(?) ; Interrupt On Overflow
```

```
ITV_5 DD 1 DUP(?) ; Interrupt 5
DD (32-6) DUP(?) ; Reserved Interrupts
ITV_32 DD 1 DUP(?) ; Interrupt 32
DD (255-33) DUP(?) ; Allocate space for available user interrupts
ITV_255 DD 1 DUP(?) ; Interrupt 255 is used for MTR-100 DS
```

```
MTR_DS_0 EQU WORD PTR ITV_255+0 ; MTR-100 Data Segment Offset
MTR_DS_S EQU WORD PTR ITV_255+2 ; (must be 0)
; MTR-100 Data Segment
```

```
INTVEC ENDS
```

\$SAVE
\$NOGEN

Global Structure Definitions

```
;;  
;  
BOOT__PAR_STRUC STRUC  
  INDEX DB ? ; Device Index  
  PORT DB ? ; Base Port Address  
  STRING DB 80 DUP(?) ; Parameter String Passed  
  UNIT DB ? ; Unit of Device Booted  
ENDS  
BOOT__PAR_STRUC
```

```
COLOR_STRUC STRUC  
  FORE DB ? ; Foreground Color  
  BACK DB ? ; Background Color  
  MCK DB ? ; SHL(Back,3) OR Fore  
  CLEAR DB ? ; Color to Clear  
  PRINTED DB ? ; Color to Fully Paint  
  P-ONT DB ? ; Color to set to Font Pattern  
  COMP_FONT DB ? ; Color to set to Complement of Font Pattern  
  COLOR_STRUC ENDS
```

```
CRTC_STRUC STRUC  
  START DW ? ; CRT-C..... Start Address  
  UPDATE DB ? ; True if update is required  
CRTC_STRUC ENDS
```

```
ESCP_STRUC STRUC  
  COMMAND DB ? ; Current Escape Command  
  FUNCTION DW ? ; Pointer to Escape Processor  
  MODE DB ? ; Escape Emulation Mode  
  OPER_COUNT DB ? ; Operand Count  
  OPER_INDEX DB ? ; Operand Index  
  OPERAND DB ? ; Operands  
  ESCP_STRUC ENDS
```

```
HI?_MODE_STRUC STRUC  
  ALTERNATE DB ? ; Alternate Key-pad Mode  
  ANSI DB ? ; ANSI Mode  
  AUTO_CR DB ? ; Auto Carriage-Return on Line-Feed  
  AUTO_LF DB ? ; Auto Line-Feed on Carriage-Return  
  AUTO_REPEAT DB ? ; Auto-Repeat Keyboard  
  BMO DB ? ; Black and White Optimization  
  CURSOR DB ? ; Programmed Cursor Value  
  CURSOR_ON DB ? ; Cursor Enabled  
  EXPAND DB ? ; Expand Key-Board Characters  
  GRAPHIC DB ? ; Graphic Character Mode  
  INSERT DB ? ; Insert Character Mode  
  KEY_EN DB ? ; Key-Board Enable  
  REVERSE DB ? ; Key-Board Enable  
  SHIFTED DB ? ; Reverse Video  
  STATUS DB ? ; Shifted Key-Pad Mode  
  UPDN DB ? ; Status-Line Enabled  
  WRAP DB ? ; Key-Board Up/Down Mode  
  WRAP DB ? ; Whap at End-of-Line  
ENDS  
HI?_MODE_STRUC
```

```
HI?_PAR_STRUC STRUC  
  CPL DB ? ; Characters Per Line  
  DSC DB ? ; Displayed Scan Lines per Character  
  LPS DB ? ; Lines Per Screen  
  PVRAM DB ? ; Planes of Video RAM  
  SLI DB ? ; Status Line Index  
  SPC DB ? ; Scan Lines per Character
```

SERIES-III 8086/3087/8088 MACRO ASSEMBLER V1.0 ASSEMBLY OF MODULE GLOBAL
OBJECT MODULE PLACED IN :F2:GLOBAL.OBJ
INVOCATION LINE CONTROLS: PRINT(:TO:) XREF ERRORPRINT(:TO:)

LOC OBJ LINE SOURCE

LOC	OBJ	LINE	SOURCE
		14	;%*DEFINE(SEGMENT_LABEL)(DATA)
		15	\$ INCLUDE (:F2:EXTERN.COM)
		16	\$SAVE
		17	\$NOGEN
		18	
		19	;%*DEFINE(EXTENDED_MONITOR)(0) ;% EXTENDED_MODE is FALSE
00FF		20	PLM_TRUE EQU OFFH ; PL/M-86 Boolean TRUE
		21	
		22	; Structure Definitions
		23	;
		24	\$ INCLUDE (:F2:STRDEF.COM')
		25	\$SAVE
		26	\$NOGEN
		27	
		28	; Global Structure Definitions
		29	;
		30	
		31	BOOT_PAR_STRUC STRUC
		32	INDEX DB ?
		33	PORT DB ?
		34	STRING DB 80 DUP(?)
		35	UNIT DB ?
		36	BOOT_PAR_STRUC ENDS
		37	
		38	COLOR_STRUC STRUC
		39	FGRE DB ?
		40	BACK DB ?
		41	MSK DB ?
		42	CLEAR DB ?
		43	PAINTED DB ?
		44	PFONT DB ?
		45	COMP_FONT DB ?
		46	COLOR_STRUC ENDS
		47	
		48	CRTC_STRUC STRUC
		49	START DW ?
		50	UPDATE DB ?
		51	CRTC_STRUC ENDS
		52	
		53	ESCP_STRUC STRUC
		54	COMMAND DB ?
		55	FUNCTION DW ?
		56	MODE DB ?
		57	OPER_COUNT DB ?
		58	OPER_INDEX DB ?
		59	OPERAND DB ?
		60	ESCP_STRUC ENDS
		61	
		62	HI9_MODE_STRUC STRUC
		63	ALTERNATE DB ?
		64	ANSI DB ?
		65	AUTO_CR DB ?
		66	AUTO_LF DB ?
		67	AUTO_REPEAT DB ?

```

; Device Index
; Base Port Address
; Parameter String Passed
; Unit of Device Booted

; Foreground Color
; Background Color
; SHL(Back,3) OR Fore
; Color to Clear
; Color to Fully Paint
; Color to set to Font Pattern
; Color to set to Complement of Font Pattern

; CRT-C ..... Start Address
; True if update is required

; Current Escape Command
; Pointer to Escape Processor
; Escape Emulation Mode
; Operand Count
; Operand Index
; Operands

; Alternate Key-pad Mode
; ANSI Mode
; Auto Carriage-Return on Line-Feed
; Auto Line-Feed on Carriage-Return
; Auto-Repeat Keyboard
    
```

```

LOC OBJ          LINE          SOURCE
=====
=1 123             %IF(ZNES(MTR100,%SEGMENT_LABEL)) THEN (
=1 124             ; INTVEC
=1                SEGMENT PUBLIC 'DATA'
=1                EXTRN ITV.SET:DWORD
=1                EXTRN ITV_ORI:DWORD
=1                EXTRN DS_PTR_0:WORD
=1                EXTRN DS_PTR_1:WORD
=1                ;
=1                ; INTVEC
=1                ENDS
=1                SEGMENT PARA PUBLIC
=1                MTR.RES: FAR
=1                EXTRN MTR_MON: FAR
=1                EXTRN MTR_SWIM: FAR
=1                EXTRN MTR_DCRT: FAR
=1                EXTRN MTR_SCRT: FAR
=1                EXTRN MTR_DKBD: FAR
=1                EXTRN MTR_SKBD: FAR
=1                ENDS
=1                MONENT
=1                MTR100
=1                SEGMENT PARA PUBLIC 'CODE'
=1                %IF(%EXTENDED_MONITOR) THEN(
=1                EXTRN R3085: NEAR
=1                )FI
=1                )FI
=1                SDS: NEAR
=1                EXTRN
=1                ENDS
=1                ; Set Data Segment
=1                MTR100
=1                )FI
=1                ENDS
=1 145             %IF(ZNES(MTR101,%SEGMENT_LABEL)) THEN (
=1 146             ; CODE
=1 147             SEGMENT BYTE PUBLIC 'CODE'
=1                EXTRN MTR101: NEAR
=1                EXTRN VIDEO_INTR: NEAR
=1                EXTRN D_CRT: NEAR
=1                EXTRN D_KBD: NEAR
=1                EXTRN S_CRT: NEAR
=1                EXTRN S_KBD: NEAR
=1                EXTRN TXMT: NEAR
=1                EXTRN TTY_INTR: NEAR
=1                EXTRN TTY_POLL: NEAR
=1                ; PL/M-86 Monitor Loop
=1                ; PL/M-86 Video Interrupt
=1                ; PL/M-86 Dumb Terminal
=1                ; PL/M-86 Dumb Key-Board
=1                ; PL/M-86 Smart Terminal
=1                ; PL/M-86 Smart Key-Board
=1                ; PL/M-86 Transmit Screen Character
=1                ; PL/M-86 Terminal Interrupt
=1                ; PL/M-86 Interrupt Poll
=1                CRLF: NEAR
=1                EXTRN
=1                INIT: NEAR
=1                WRITTEC: NEAR
=1                ENDS
=1                ; PL/M-86 CR-LF
=1                ; PL/M-86 Initialize Hardware
=1                ; PL/M-86 Write Character
=1                CODE
=1                )FI
=1                ENDS
=1 164             %IF(ZNES(DATA,%SEGMENT_LABEL)) THEN (
=1 165             DATA
=1 166             SEGMENT WORD PUBLIC 'DATA'
=1                EXTRN HORZ_CHAR: BYTE
=1                EXTRN VERT_LINE: BYTE
=1                EXTRN REGP: DWORD
=1                EXTRN RESETF: BYTE
=1                ; Column Index
=1                ; Row Index
=1                ; Pointer to Saved Processor Registers
=1                ; Hardware Reset Flag
=1                DCI: DWORD
=1                EXTRN
=1                DFC: DWORD
=1                EXTRN
=1                D_XMTC: DWORD
=1                ; Display Character Initialization
=1                ; Display Font Character
=1                ; Dumb Terminal Transmit Character

```

LOC	OBJ	LINE	SOURCE
		181	%DEFINE(DPB(name, count))(%name DB %count DUP(?)
		182	PUBLIC %name)
		183	%DEFINE(DPD(name))(%name DD 1 DUP(?)
		184	PUBLIC %name)
		185	%DEFINE(DPS(name, sname))(%name DB SIZE(%sname) DUP(?)
		186	PUBLIC %name)
		187	%DEFINE(DPW(name, count))(%name DW %count DUP(?)
		188	PUBLIC %name)
		189	
		190	
		191	%EJECT

```

LOC   OBJ      LINE      SOURCE
291   not to move.
292   ;;;
293   ;;;
294   ;;;
295   ;;;
296   ;;;
297   ;;;
298   ;;;
299   ;;;
300   ;;;
301   ;;;
302   ;;;
303   ;;;
304   ;;;
305   ;;;
306   ;;;
307   ;;;
308   ;;;
309   ;;;
310   ;;;
311   ;;;
312   ;;;
313   ;;;
314   ;;;
315   ;;;
316   ;;;
317   ;;;
318   ;;;
319   ;;;
320   ;;;
321   ;;;
322   ;;;
323   ;;;
324   ;;;
325   ;;;
326   ;;;
327   ;;;
328   ;;;
329   ;;;
330   ;;;
331   ;;;
332   ;;;
333   ;;;
334   ;;;
335   ;;;
336   ;;;
337   ;;;
338   ;;;
339   ;;;
340   ;;;
341   ;;;
342   ;;;
343   ;;;
344   ;;;
345   ;;;
346   ;;;

;
; Miscellaneous Hardware Latch Values
;
; Base Internal Interrupt Level
; Base S-100 Interrupt Level
; Processor Swap Port
; Pointer to Saved Processor Registers
; Reset Flag
;
; Terminal Emulator Variables
;
; Color Structure
; Cursor Start Address Structure
; Display Start Address Structure
; Escape Processing Structure
; H-19 Mode Definitions
; H-19 Parameters
; Transmit Character Structure

DATA   ENDS
END

```

NAME	TYPE	VALUE	ATTRIBUTES, XREFS
H19_MODE_STRUC.	V BYTE	02B2H	DATA PUBLIC 332# 333
H19_PAR_STRUC.	V BYTE	02C4H	DATA PUBLIC 335# 336
H19_PAR_STRUC.	STRUC		SIZE=0009H #FIELDS=9
HORZ_CHAR.	V BYTE	0291H	DATA PUBLIC 270# 271
INDEX.	V BYTE	0000H	S FIELD 32#
INIT.	L NEAR	0000H	EXTRN 160#
INSERT.	V BYTE	000AH	S FIELD 73#
ITV_OBI.	V DWORD	0000H	EXTRN 127#
ITV_SST.	V DWORD	0000H	EXTRN 126#
KEY_EN.	V BYTE	000BH	S FIELD 74#
KMAP.	V BYTE	0091H	DATA PUBLIC 264# 265
LPS.	V DWORD	0002H	S FIELD 85#
MDC.	V DWORD	0073H	DATA PUBLIC 237# 238
MDL.	V DWORD	0077H	DATA PUBLIC 240# 241
MODE.	V BYTE	0003H	S FIELD 56#
MONENT.	SEGMENT		SIZE=0000H PARA PUBLIC 131# 139
MSK.	V BYTE	0002H	S FIELD 41#
MTR_DCRT.	L FAR	0000H	EXTRN 135#
MTR_DKBD.	L FAR	0000H	EXTRN 137#
MTR_FONT.	V BYTE	0000H	EXTRN 119#
MTR_MON.	L FAR	0000H	EXTRN 133#
MTR_RES.	L FAR	0000H	EXTRN 132#
MTR_SCR.	L FAR	0000H	EXTRN 136#
MTR_SKBD.	L FAR	0000H	EXTRN 138#
MTR_SWIM.	L FAR	0000H	EXTRN 134#
MTR100.	SEGMENT		SIZE=0000H PARA PUBLIC 'CODE' 140# 143 175
MTR101.	L NEAR	0000H	EXTRN 149#
OPER_COUNT.	V BYTE	0004H	S FIELD 57#
OPER_INDEX.	V BYTE	0005H	S FIELD 58#
OPERAND.	V BYTE	0006H	S FIELD 59#
PAINTED.	V BYTE	0004H	S FIELD 43#
POINT.	V BYTE	0005H	S FIELD 44#
PLM_TRUE.	NUMBER	00FFH	20#
PORT.	V BYTE	0001H	S FIELD 33#
POVRAM.	V DWORD	0003H	S FIELD 86#
PROMPT.	V DWORD	007BH	DATA PUBLIC 243# 244
PSP.	V BYTE	0295H	DATA PUBLIC 308# 309
RDC.	V DWORD	007FH	DATA PUBLIC 246# 247
REGP.	V DWORD	0296H	DATA PUBLIC 311# 312
RESETF.	V BYTE	029AH	DATA PUBLIC 314# 315
REVERSE.	V WORD	000CH	S FIELD 75#
ROM.	V BYTE	0006H	S FIELD 99#
S_CRT.	L NEAR	0000H	EXTRN 153#
S_KBD.	L NEAR	0000H	EXTRN 154#
S_XMTC.	V DWORD	0083H	DATA PUBLIC 249# 250
SXS.	L NEAR	0000H	EXTRN 142#
SHIFTED.	V BYTE	000EH	S FIELD 76#
SLI.	V BYTE	0004H	S FIELD 87#
SPC.	V BYTE	0005H	S FIELD 88#
START.	V WORD	0000H	S FIELD 49#
STATUS.	V BYTE	000FH	S FIELD 77#
STRING.	V BYTE	0002H	S FIELD 34#
SW401.	V BYTE	0006H	S FIELD 89#
SW402.	V BYTE	0007H	S FIELD 90#

SERIES-111 8086/8087/80386 MACRO ASSEMBLER V1.0 ASSEMBLY OF MODULE MAIN
OBJECT MODULE PLACED IN : F2:MTR100.OBJ
INVOCATION LINE CONTROLS: PRINT(:TD:) XREF ERRPRPRINT(:TD:)

LOC OBJ LINE SOURCE

```

LOC   OBJ          LINE   SOURCE
=1    00F3          27 +1  $ INCLUDE (:F2:ISDEF.COM)
=1    00F3          28    ;;          IS5.DEF - Intel 8085/8080 Instruction Definitions
=1    00F3          29    ;
=1    00F3          30    ;          addr      - 16-bit Address
=1    00F3          31    ;          data       - 8-bit Data
=1    00F3          32    ;          port       - 8-bit Port Address
=1    00F3          33    ;
=1    00F3          34    ;
=1    00F3          35    185_DI      EQU      3630      ; DI          - Disable Interrupts
=1    00F3          36    185_EI      EQU      3730      ; EI          - Enable Interrupts
=1    00C3          37    185_JMP      EQU      3030      ; JMP      addr      - Jump to Address
=1    002A          38    185_LHLD     EQU      0520      ; LHLD     addr      - Load HL Direct
=1    003E          39    185_MVIA    EQU      0760      ; MVI      A,data    - Set A to data
=1    00D3          40    185_OUT     EQU      3230      ; OUT      port      - Output A to port
=1    00F1          41    185_POP_AF   EQU      3610      ; POP      PSM       - Pop Processor Status Word
=1    00C1          42    185_POP_BC   EQU      3010      ; POP      BC        - Pop BC Register Pair
=1    00D1          43    185_POP_DE   EQU      3210      ; POP      DE        - Pop DE Register Pair
=1    00E1          44    185_POP_HL   EQU      3410      ; POP      HL        - Pop HL Register Pair
=1    00F5          45    185_PUSH_AF  EQU      3650      ; PUSH     PSM       - Push Processor Status Word
=1    00C9          46    185_RET      EQU      3110      ; RET          - Return from Procedure
=1    0022          47    185_SHLD     EQU      0420      ; SHLD     addr      - Store HL Direct
=1    00F9          48    185_SPHL    EQU      3710      ; SPHL          - Sp = HL
=1    00F9          49 +1  $ INCLUDE (:F2:IODEF.COM)
=1    00F9          50    ;;          IODEF.COM
=1    00F9          51    ;
=1    00F9          52    ;          'IODEF.COM' contains the few I/O constants required
=1    00F9          53    ;          by assembly language routines.
=1    00F9          54    ;
=1    00FF          55    10_DIP       EQU      00FFH      ; DIP-Switch Port
=1    00FF          56    10_DIAG      EQU      00F6H      ; Diagnostic Board Switch
=1    00F6          57    10_SWAP      EQU      00FEH      ; SWAP Port
=1    00FE          58    ;
=1    00FE          59    ;          Misc.
=1    0008          60    ;
=1    0008          61    ;
=1    0008          62    DIP_AUTO_BOOT EQU      00001000B ; Auto-Boot Dip Switch
=1    0008          63 +1  $ INCLUDE (:F2:PARDEF.COM)
=1    0008          64 +1  $EJECT

```

LOC	OBJ	LINE	SOURCE
		=1 107	:: Interrupt Usage
		=1 108	;
		=1 109	;
		=1 110	;
		=1 111	;
		=1 112	;
		=1 113	;
		=1 114	;
		=1 115	;
		=1 116	;
		=1 117	;
		=1 118	;
		=1 119	;
		=1 120	;
		=1 121	;
		=1 122	INTVEC SEGMENT PARA AT PAR_INT
		=1 123	;
		=1 124	ITV_DBZ DD 1 DUP(?) ; Divide by zero interrupt
0000	(1))	=1 125	ITV_SST DD 1 DUP(?) ; Single Step
0004	(1))	=1 126	ITV_NMI DD 1 DUP(?) ; Non-Maskable Interrupt
0008	(1))	=1 127	ITV_OBI DD 1 DUP(?) ; One Byte Instruction
000C	(1))	=1 128	ITV_OV DD 1 DUP(?) ; Interrupt On Overflow
0010	(1))	=1 129	ITV_S DD 1 DUP(?) ; Interrupt S
0014	(1))	=1 130	(32-6) DUP(?) ; Reserved Interrupts
0018	(26))	=1 131	ITV_32 DD 1 DUP(?) ; Interrupt 32
0080	(1))	=1 132	(255-33) DUP(?) ; Allocate space for available user interrupts
0084	(222))	=1 133	ITV_255 DD 1 DUP(?) ; Interrupt 255 is used for MTR-100 DS
03FC	(1))	=1 134	MTR_DS_0 EQU WORD PTR ITV_255+0 ; MTR-100 Data Segment Offset (must be 0)
03FE	(1))	=1 135	MTR_DS_S EQU WORD PTR ITV_255+2 ; MTR-100 Data Segment
		=1 136	INTVEC ENDS
		=1 137	PUBLIC ITV_SST ; Single Step
		=1 138	
		=1 139	
		=1 140	
		=1 141	

LOC	OBJ	LINE	SOURCE
		150	%DEFINE(SEGMENT_LABEL)(MTR100)
		151 +1	\$INCLUDE(:F2:EXTERN.COM)
		152 +1	\$SAVE
		153 +1	\$NOGEN
		154	
		155	%DEFINE(EXTENDED_MONITOR)(0) %' EXTENDED_MODE is FALSE
00FF		=1	
		=1	PLM_TRUE EQU 0FFH ; PL/M-86 Boolean TRUE
		=1	
		=1	Structure Definitions
		=1	\$ INCLUDE (:F2:STRDEF.COM')
		=1	\$SAVE
		=2	\$NOGEN
		=2	
		=2	164
		=2	165
		=2	166
		=2	167
0000		=2	BOOT_PAR_STRUC STRUC
0001		=2	INDEX DB
0002		=2	PORT DB
0052		=2	STRING DB
		=2	UNIT DB
		=2	BOOT_PAR_STRUC ENDS
		=2	173
		=2	174
0000		=2	COLOR_STRUC STRUC
0001		=2	FORE DB
0002		=2	BACK DB
0003		=2	MSK DB
0004		=2	CLEAR DB
0005		=2	PAINTED DB
0006		=2	PRINT DB
		=2	COMP_FONT DB
		=2	COLOR_STRUC ENDS
		=2	183
		=2	184
0000		=2	CRTC_STRUC STRUC
0002		=2	START DB
		=2	UPDATE DB
		=2	CRTC_STRUC ENDS
		=2	187
		=2	188
		=2	189
0000		=2	ESCP_STRUC STRUC
0001		=2	COMMAND DB
0003		=2	FUNCTION DB
0004		=2	MODE DB
0005		=2	OPER_COUNT DB
0006		=2	OPER_INDEX DB
		=2	OPERAND DB
		=2	ESCP_STRUC ENDS
		=2	196
		=2	197
		=2	198
0000		=2	H19_MODE_STRUC STRUC
0001		=2	ALTERNATE DB
0002		=2	ANSI DB
0003		=2	AUTO_CR DB
0004		=2	AUTO_LF DB
		=2	AUTO_REPEAT DB
		=2	203

```

; Device Index
; Base Port Address
; Parameter String Passed
; Unit of Device Booted

Global Structure Definitions

;
;
; Foreground Color
; Background Color
; SHL(Back,3) OR Fore
; Color to Clear
; Color to Fully Paint
; Color to set to Font Pattern
; Color to set to Complement of Font Pattern

; CRT-C ..... Start Address
; True if update is required

; Current Escape Command
; Pointer to Escape Processor
; Escape Emulation Mode
; Operand Count
; Operand Index
; Operands
4 DUP(?);

; Alternate Key-pad Mode
; ANSI Mode
; Auto Carriage-Return on Line-Feed
; Auto Line-Feed on Carriage-Return
; Auto-Repeat Keyboard
    
```

LOC ORJ

LINE

SOURCE

```

=1 259      %IF(ZNES(MTR100,%SEGMENT_LABEL)) THEN (
=1          ; INTVEC
=1          SEGMENT PUBLIC 'DATA'
=1          EXTRN ITV_SST:DWORD
=1          EXTRN ITV_ORI:DWORD
=1          EXTRN DS_PTR_0:WORD
=1          EXTRN DS_PTR_S:WORD
=1          ;
=1          ; INTVEC
=1          ENDS
=1          SEGMENT PARA PUBLIC
=1          MTR_RES:FAR
=1          EXTRN MTR_MON:FAR
=1          EXTRN MTR_SWIM:FAR
=1          EXTRN MTR_DCRT:FAR
=1          EXTRN MTR_SCRT:FAR
=1          EXTRN MTR_DKBD:FAR
=1          EXTRN MTR_SKBD:FAR
=1          ENDS
=1          SEGMENT PARA PUBLIC 'CODE'
=1          %IF(ZEXTENDED_MONITOR) THEN (
=1              EXTRN R8085:NEAR
=1              ; Restore 8085
=1              )FI
=1          ; Set Data Segment
=1          ENDS
=1          MTR100
=1          )FI
=1
=1 261      %IF(ZNES(MTR101,%SEGMENT_LABEL)) THEN (
=1          CODE
=1          SEGMENT BYTE PUBLIC 'CODE'
=1          EXTRN MTR101:NEAR
=1          EXTRN VIDEO_INTR:NEAR
=1          EXTRN D_CRT:NEAR
=1          EXTRN D_KBD:NEAR
=1          EXTRN S_CRT:NEAR
=1          EXTRN S_KBD:NEAR
=1          EXTRN TXM1:NEAR
=1          EXTRN TTY_INTR:NEAR
=1          EXTRN TTY_POLL:NEAR
=1          ; PL/M-86 Monitor Loop
=1          ; PL/M-86 Video Interrupt
=1          ; PL/M-86 Dumb Terminal
=1          ; PL/M-86 Dumb Key-Board
=1          ; PL/M-86 Smart Terminal
=1          ; PL/M-86 Smart Key-Board
=1          ; PL/M-86 Transmit Screen Character
=1          ; PL/M-86 Terminal Interrupt
=1          ; PL/M-86 Interrupt Poll
=1          CRLF:NEAR
=1          EXTRN INIT:NEAR
=1          EXTRN WRITEC:NEAR
=1          ; PL/M-86 CR-LF
=1          ; PL/M-86 Initialize Hardware
=1          ; PL/M-86 Write Character
=1          ENDS
=1          CODE
=1          )FI
=1
=1 280      %IF(ZNES(DATA,%SEGMENT_LABEL)) THEN (
=1          DATA
=1          SEGMENT WORD PUBLIC 'DATA'
=1          EXTRN HORZ_CHAR:BYTE
=1          EXTRN VERT_LINE:BYTE
=1          EXTRN REGP:DWORD
=1          EXTRN RESETF:BYTE
=1          ; Column Index
=1          ; Row Index
=1          ; Pointer to Saved Processor Registers
=1          ; Hardware Reset Flag
=1          DCI:DWORD
=1          EXTRN DFC:DWORD
=1          EXTRN D_XMTC:DWORD
=1          ; Display Character Initialization
=1          ; Display Font Character
=1          ; Dumb Terminal Transmit Character

```

```

LOC OBJ          LINE  SOURCE
-----
326              ;;;      Initial 8085 Boot Code
327              ;
328              ; This code is initially invoked after reset. Since
329              ; the first processor to run is the 8085, this code
330              ; switches to the 8086 processor.
331              ;
332              ; Initially, the 8K-byte MTR-100 ROM is replicated
333              ; throughout the memory space. Since the 8085 resets
334              ; location zero, this code must be the first in the
335              ; ROM. It promptly switches to the 8086, which it is
336              ; assumed will turn off the ROM mapping. The 8085 is
337              ; left with the instruction pointer at 0.
338              ;
339              ;
340              ;
341              ;
342              ;
343              ;
344              ;
345              ;
346              ;
347              ;
348 +1            $ EJECT

B8085            SEGMENT BYTE AT PAR_B85 ; Start the segment at base of ROM
                DB      185_MVIA,80H    ; MVI  A,80H
                DB      185_JMP         ; JMP  0FFFEH
                DW      0FFFEH
                ENDS

B8085            ENDS

```

0000 3E
 0001 80
 0002 C3
 0003 FFFF

LOC	OBJ	LINE	SOURCE
0000	EA0000	373	;;; MTR_ENT - Monitor Entry Points
0000	EA0000	374	;;
0000	EA0000	375	;; These vectors are provided as alternate entry points
0000	EA0000	376	;; into the monitor routines.
0000	EA0000	377	;;
0000	EA0000	378	;
0000	EA0000	379	MOMENT SEGMENT PARA PUBLIC
0000	EA0000	380	ASSUME NOTHING
0000	EA0000	381	
0000	EA0000	382	
0000	EA0000	383	MTR_RES LABEL FAR
0000	EA0000	384	PUBLIC MTR_RES
0000	EA0000	385	JMP FAR PTR MTR
0000	EA0000	386	
0005	EA9C00	387	MTR_MON LABEL FAR
0005	EA9C00	388	PUBLIC MTR_MON
0005	EA9C00	389	JMP FAR PTR MON
0005	EA9C00	390	
000A	EA2B00	391	MTR_SWIM LABEL FAR
000A	EA2B00	392	PUBLIC MTR_SWIM
000A	EA2B00	393	JMP FAR PTR SWIM
000A	EA2B00	394	
000F	EAB300	395	MTR_DCRT LABEL FAR
000F	EAB300	396	PUBLIC MTR_DCRT
000F	EAB300	397	JMP FAR PTR DCRT
000F	EAB300	398	
0014	EA9200	399	MTR_DKBD LABEL FAR
0014	EA9200	400	PUBLIC MTR_DKBD
0014	EA9200	401	JMP FAR PTR DKBD
0014	EA9200	402	
0019	EAB800	403	MTR_SCRT LABEL FAR
0019	EAB800	404	PUBLIC MTR_SCRT
0019	EAB800	405	JMP FAR PTR SCRT
0019	EAB800	406	
001E	EAAE00	407	MTR_SKBD LABEL FAR
001E	EAAE00	408	PUBLIC MTR_SKBD
001E	EAAE00	409	JMP FAR PTR SKBD
001E	EAAE00	410	
0023	EAC200	411	MTR_TTY_INTR LABEL FAR
0023	EAC200	412	PUBLIC MTR_TTY_INTR
0023	EAC200	413	JMP FAR PTR TTYINTR
0023	EAC200	414	
0028	EAE700	415	MTR_TTY_POLL LABEL FAR
0028	EAE700	416	PUBLIC MTR_TTY_POLL
0028	EAE700	417	JMP FAR PTR TTYPOLL
0028	EAE700	418	
002D	EACB00	419	MTR_IHRET LABEL FAR
002D	EACB00	420	PUBLIC MTR_IHRET
002D	EACB00	421	JMP FAR PTR IHRET
002D	EACB00	422	
002D	EACB00	423	
002D	EACB00	424	MOMENT ENDS
002D	EACB00	424	+1 \$ EJECT

;;; MTR_ENT - Monitor Entry Points
 ;;
 ;; These vectors are provided as alternate entry points
 ;; into the monitor routines.
 ;;

; Monitor Entry Point Segment

; Reset the monitor entry point

; Monitor Entry Point

; Monitor Software Interrupt Entry

; Dumb Terminal Processor

; Dumb Key-Board Processor

; Smart Terminal Processor

; Smart Keyboard Processor

; Terminal Interrupt Handler

; Terminal Poll Function

; Interrupt Return

```

LOC  OBJ  LINE  SOURCE
467      ; SWIM      Software Interrupt Monitor
468      ;
469      ; SWIM is the software interrupt monitor entry point. It
470      ; is presumed that both the flags and return address are
471      ; on the top of the stack. Furthermore, it is assumed that
472      ; the return address is a far return, i.e. that both the code
473      ; segment and instruction pointer are on the stack.
474      ;
475      ; Entry: (SP+4) = Original Flags
476      ;         (SP+2) = Original Code Segment
477      ;         (SP+0) = Original Instruction Pointer
478      ;         All other registers as initialized
479      ;
480      SWIM:  PUSH  AX
481            PUSH  BX
482            PUSH  CX
483            PUSH  DX
484            MOV   AX,SP
485            ADD  AX,(4+3)*2      ; Account for all parameters on stack
0034 50      AX
486            PUSH BP
487            PUSH SI
488            PUSH DI
489            PUSH DI
490
491            ; CS is at bottom of stack
0038 1E      CS
492            PUSH DS
0039 16      DS
493            PUSH SS
003A 06      SS
494            PUSH ES
495
003B E86400  CALL  SDS      ; Set Data Segment
003E 89260000 MOV  WORD PTR DS:REGP,SP      ; Save Pointer to Registers
0042 8C160200 MOV  WORD PTR DS:REGP+2,SS
496
0046 E30000  SWIMI: CALL  MTR101      ; CALL MTR101
500            JMP   SWIMI      ; Continue processing monitor commands
0049 EBF8      $ EJECT
502 +1

```

LOC	OBJ	LINE	SOURCE
		547	::
		548	;; EDIAG -- Boot Diagnostics
		549	;;
		550	;; EDIAG is performs any power-on diagnostics.
		551	;;
0087		552	BDIAG PROC NEAR
		553	
		554	RET
0087	C3	555	
		556	BDIAG ENDP
		557	+1 \$ EJECT

LOC	OBJ	LINE	SOURCE
		583	:: DKBD ... Dumb Key-Board
		584	::
		585	:: DKBD is the assembly language entry point to read
		586	:: and translate a character from the keyboard. This
		587	:: entry point is for 'dumb', ie. naive processing.
		588	:: Each keyboard character returns a unique entry.
		589	::
		590	:: Entry: NONE
		591	::
		592	:: Exit: AL = Key-Board Value for character
		593	::
		594	:: Uses: ???
		595	::
		596	::
0072		597	DKBD PROC FAR
0072 1E		598	PUSH DS
0073 E80C00		599	CALL SDS ; Set Data Segment
		600	
0074 50		601	PUSH AX
0077 E80000	E	602	CALL D_KBD
		603	
007A 1F		604	POP DS
007B CB		605	RET
		606	
		607	DKBD ENDP
		608	+1 \$EJECT

LOC	OBJ	LINE	SOURCE
		661	;; TTYPOLL -- Terminal Poll
		662	;;
		663	;; TTYPOLL is a far call to the TTY_POLL routine.
		664	;;
		665	;; Entry: NONE
		666	;;
		667	;; Exit: AX = TRUE if updates will occur
		668	;; = at the next vertical retrace
		669	;; = FALSE otherwise
		670	;;
009E		671	TTYPOLL PROC NEAR
		672	PUBLIC TTYPOLL
009E E30000	E	673	CALL TTY_POLL
00A1 C3		674	RET
		675	TTYPOLL ENDP
		676	
		677	;; +1 \$ EJECT

LDC	OBJ	LINE	SOURCE
		733 +1	* EJECT

LOC	OBJ	LINE	SOURCE
		816	
		817	
		818	
		819	
		820	
		821	;; TTYINTR - Terminal Interrupt
		822	;;
		823	;; TTYINTR is the global entry vector for the Terminal Interrupt
		824	;; processor. This routine saves all registers, sets the correct
		825	;; Data Segment, and invokes TTY_INTR for the interrupt processing
		826	;;
		827	;; Entry: NONE
		828	;;
		829	;; Exit: NONE
		830	;;
		831	;; Uses: NONE
		832	;;
00C2		833	TTYINTR PROC FAR
		834	
		835	XIF(ZEXTENDED_MONITOR
		836	0)THEN(
		837	PUSH AX
		838	PUSH BX
		839	PUSH CX
		840	PUSH DX
		841	; PUSH SP
		842	PUSH BP
		843	PUSH SI
		844	PUSH DI
		845	PUSHF
		846	; PUSH CS
		847	; PUSH DS
		848	PUSH SS
		849	PUSH ES
		850)FI
		851	+1
		852	
00C2 1E		853	PUSH DS
00C3 E8DCFF		854	CALL SDS
00C6 E80000	E	855	CALL TTY_INTR
00C9 1F		856	POP DS
		857	
		858	XIF(ZEXTENDED_MONITOR
		859	0)THEN(
		860	POP ES
		861	POP SS
		862	; POP DS
		863	; POP CS
		864	POPF
		865	POP DI
		866	POP SI
		867	POP BP
		868	; POP SP
		869	POP DX
		870	POP CX

; Set the Data Segment

LOC	OBJ	LINE	SOURCE
		884	
		885	
		886	
		887	
		888	; MIRET -- Monitor Interrupt Return
		889	;
		890	; MIRET is simply a vector pointing to an Interrupt
		891	; Return instruction.
		892	;
		893	; Entry: Stack clean except for Interrupt Data, ie.
		894	; flags, CS, and IP.
		895	;
		896	; Exit: From interrupt
		897	;
		898	
00CB		899	MIRET PROC FAR
		900	
		901	IRET
		902	
00CB CF		903	MIRET ENDP ; Return from interrupt
		904	
		905	
		906	
		907	
		908	MTR100 ENDS
		909	
		910	
		911	
		912	
		913	END

NAME	TYPE	VALUE	ATTRIBUTES, XREFS
TTY_POLL	L NEAR	0000H	EXTRN 273# 674
TTYINTR	L FAR	00C2H	MTR100 413 833# 873
TTYROLL	L NEAR	009EH	MTR100 PUBLIC 417 672# 673 676
TXMT	L NEAR	0000H	EXTRN 271#
UIES	V DWORD	0000H	EXTRN 300#
UNIT	V BYTE	0052H	S FIELD 171#
UPDATE	V BYTE	0002H	S FIELD 186#
UPDN	V BYTE	0010H	S FIELD 214#
VERT_LINE	V BYTE	0000H	EXTRN 285#
VIDEO_INTR	L NEAR	0000H	EXTRN 266#
VIDEO_INTR_A . . .	L FAR	0000H	EXTRN 248#
VIDEQA	SEGMENT		SIZE=0000H BYTE PUBLIC 'CODE' 316# 317 321
VRAM_SIZE	V BYTE	0008H	S FIELD 227#
WRAP	V BYTE	0011H	S FIELD 215#
WRITEC	L NEAR	0000H	EXTRN 277#
XCA	V DWORD	0000H	EXTRN 301#
XMT	V TBYTE	0000H	EXTRN 310#
XMT_COLOR	V BYTE	0007H	S FIELD 236#
XMT_GRAPHIC . . .	V BYTE	0008H	S FIELD 237#
XMT_REVERSE . . .	V BYTE	0009H	S FIELD 238#
XMT_STRUC	STRUC		SIZE=000AH #FIELDS=8 230 239# 310

ASSEMBLY COMPLETE, NO ERRORS FOUND

SERIES-III 8086/8087/8088 MACRO ASSEMBLER V1.0 ASSEMBLY OF MODULE ASTLIB
 OBJECT MODULE PLACED IN :F2:ASTLIB.OBJ
 INVOCATION LINE CONTROLS: PRINT(:TO:) XREF ERRORPRINT(:TO:)

```

LOC OBJ          LINE  SOURCE
-----
      1 +1 $TITLE('MTR100 Z-Machine Monitor ROM: Assist Library')
      2 +1 $GEN
      3 +1 $SYMBOLS
      4 +1 $XREF
      5    ;;
      6    MTR-100 Assembly Language Assist Library
      7    ;
      8    ; This library provides the assembly language assistance
      9    ; required by the PL/M-86 code in MTR-101. These routines
     10    ; are meant to be called from PL/M-86, and assume that the
     11    ; model of computation is COMPACT.
     12    ;
     13    ; By      Gregg Chandler
     14    ; Date   1-Jan-1982
     15    ;
     16    ; Copyright(C) 1982, Heath Co.
     17
     18 %*DEFINE(SEGMENT_LABEL)(ASTLIB)
     19 +1 $INCLUDE(:F2:EXTERN.COM)
     20 +1 $SAVE
     21 +1 $NOGEN
     22
     23 %*DEFINE(EXTENDED_MONITOR)(0) %' EXTENDED_MODE is FALSE
     24
     25 PLM_TRUE EQU 0FFH ; PL/M-86 Boolean TRUE
     26
     27 ; Structure Definitions
     28
     29 $ $SAVE
     30 $ $NOGEN
     31
     32 ;; Global Structure Definitions
     33 ;
     34
     35 BOOT_PAR_STRUC STRUC
     36     INDEX DB ? ; Device Index
     37     PORT DB ? ; Base Port Address
     38     STRNG DB 80 DUP(?) ; Parameter String Passed
     39     UNIT DB ? ; Unit of Device Booted
     40     BOOT_PAR_STRUC ENDS
     41
     42 COLOR_STRUC STRUC
     43     FORE DB ? ; Foreground Color
     44     BACK DB ? ; Background Color
     45     MSK DB ? ; SHL(Back,3) OR Fore
     46     CLEAR DB ? ; Color to Clear
     47     PAINTED DB ? ; Color to Fully Paint
     48     P_FONT DB ? ; Color to set to Font Pattern
     49     COMP_FONT DB ? ; Color to set to Complement of Font Pattern
     50
     51
     52
     53
     54
     55
     56
     57
     58
     59
     60
     61
     62
     63
     64
     65
     66
     67
     68
     69
     70
     71
     72
     73
     74
     75
     76
     77
     78
     79
     80
     81
     82
     83
     84
     85
     86
     87
     88
     89
     90
     91
     92
     93
     94
     95
     96
     97
     98
     99
    100
    
```

LOC	OBJ	LINE	SOURCE
0008		=2	XMT_GRAPHIC DB
0009		=2	XMT_REVERSE DB
		=2	XMT_STRUC ENDS
		=2	#RESTORE
		=2	Global's Definitions
		=1	%IF (%NES(ASLIB, %SEGMENT_LABEL)) THEN (
		=1	ASLIB
		=1	SEGMENT BYTE PUBLIC 'CODE'
		=1	EXTRN VIDEO_INTR_A: FAR
		=1	ENDS
		=1	ASTLIB
		=1	FI
		=1	115
		=1	116
		=1	117
		=1	%IF (%NES(FONTAB, %SEGMENT_LABEL)) THEN (
		=1	FONTAB
		=1	SEGMENT BYTE PUBLIC 'DATA'
		=1	EXTRN MTR_FONT: BYTE
		=1	ENDS
		=1	FONTAB
		=1	FI
		=1	122
		=1	123
		=1	124
		=1	%IF (%NES(MTR100, %SEGMENT_LABEL)) THEN (
		=1	INTVEC
		=1	SEGMENT PUBLIC 'DATA'
		=1	EXTRN ITV_SST: DWORD
		=1	EXTRN ITV_OBI: DWORD
		=1	EXTRN DS_PTR_0: WORD
		=1	EXTRN DS_PTR_S: WORD
		=1	ENDS
		=1	INTVEC
		=1	MONENT
		=1	SEGMENT PARA PUBLIC
		=1	EXTRN MTR_RES: FAR
		=1	EXTRN MTR_MON: FAR
		=1	EXTRN MTR_SWIM: FAR
		=1	EXTRN MTR_DCRT: FAR
		=1	EXTRN MTR_SCRT: FAR
		=1	EXTRN MTR_DKBD: FAR
		=1	EXTRN MTR_SKBD: FAR
		=1	ENDS
		=1	MONENT
		=1	SEGMENT PARA PUBLIC 'CODE'
		=1	EXTRN %IF (%EXTENDED_MONITOR) THEN (
		=1	EXTRN R3085: NEAR
		=1	FI
		=1	MONENT
		=1	FI
		=1	145
		=1	146
		=1	147
		=1	%IF (%NES(MTR101, %SEGMENT_LABEL)) THEN (
		=1	CODE
		=1	SEGMENT BYTE PUBLIC 'CODE'
		=1	EXTRN MTR101: NEAR
		=1	EXTRN VIDEO_INTR: NEAR
		=1	EXTRN D_CRT: NEAR
		=1	EXTRN D_KBD: NEAR
		=1	EXTRN S_CRT: NEAR
		=1	PL/M-86 Monitor Loop
		=1	PL/M-86 Video Interrupt
		=1	PL/M-86 Dumb Terminal
		=1	PL/M-86 Dumb Key-Board
		=1	PL/M-86 Smart Keyboard Emulator

LOC	OBJ	LINE	SOURCE
0000		209	
0002		210	; INCLUDE ('F2:PARDEF.COM')
0004		211	; INCLUDE ('F2:INTDEF.COM')
0006		212	
0008		213	
000A		214	REG STRUC
000C		215	
0010		216	ES_ DW ? ; Extra Segment
0012		217	SS_ DW ? ; Stack Segment
0014		218	DS_ DW ? ; Data Segment
0016		219	DI_ DW ? ; Destination Index
0018		220	SI_ DW ? ; Source Pointer
001A		221	BP_ DW ? ; Base Pointer
001C		222	SP_ DW ? ; Stack Pointer
001E		223	DX_ DW ? ; Data
0020		224	CX_ DW ? ; Count
0022		225	BX_ DW ? ; Base
0024		226	AX_ DW ? ; Accumulator
0026		227	IP_ DW ? ; Instruction Pointer
0028		228	CS_ DW ? ; Code Segment
002A		229	FLAG_ DW ? ; Flags
002C		230	
002E		231	REG ENDS
0030		232	
0032		233	
0034		234	NAME ASTLIB ; Name the module
0036		235	
0038		236	ASTLIB SEGMENT BYTE PUBLIC 'CODE' ; Concatenate with the Code Segment
003A		237	ASSUME CS:COROUP,DS:DATA ; Assume MTR-100 Segments
003C		238	+1 \$EJECT

LOC	OBJ	LINE	SOURCE
000E		281	;;
		282	;;
		283	;;
		284	;;
		285	;;
		286	;;
		287	;;
		288	;;
		289	;;
		290	;;
		291	;;
		292	;;
		293	;;
		294	;;
		295	;;
		296	;;
		297	;;

LOC	OBJ	LINE	SOURCE
000E		291	;;
000E	9C	292	;;
000F	58	293	;;
0010	C3	294	;;
		295	;;
		296	;;
		297	;;

Return 0086 Flags
 FLAGS returns the current 0086 flag settings
 as a WORD.

Entry: NONE
 Exit: AX = Entry flags

PROC NEAR
 PUBLIC FLAGS

PUSHF
 POP AX ; AX = Flags
 RET

FLAGS
 EJECT

LOC	OBJ	LINE	SOURCE
		341	;; INCB -- Increment Byte
		342	;;
		343	;; INCB increments the specified byte. The primary
		344	;; use for this routine is to force a value to be
		345	;; updated, rather than letting the compiler optimize
		346	;; variable references to said variable.
		347	;;
		348	;;
		349	;;
		350	;;
		351	;;
		352	;; USAGE: CALL INCB(byte#ptr);
		353	;;
		354	;; Entry: byte#ptr -- Address of byte to increment
		355	;;
		356	;;
0000		357	INCB_P STRUC
0002		358	DW ?
0004		359	DW ?
		360	INCB_BYTEPTR DD ?
		361	INCB_P ENDS
		362	
0011		363	
		364	INCB PROC NEAR
0011 55		365	PUBLIC INCB
0012 8BEC		366	PUSH BP
		367	MOV BP,SP
		368	
0014 C47E04		369	LES DI,[BP],INCB_BYTEPTR
0017 26FE05		370	INC BYTE PTR ES:[DI]
		371	
001A 5D		372	POP BP
001B C20400		373	RET 4
		374	INCB ENDP
		375	+1 \$EJECT

LOC	OBJ	LINE	SOURCE
		423	;;
		424	SXMTIC ... Smart Terminal Transmit Character
		425	;;
		426	'SXMTIC' Is invoked by the smart keyboard/terminal to
		427	transmit generated characters. This routine merely
		428	transforms the PL/M-86 calling convention into a more
		429	conventional assembly language one by moving the sup-
		430	plied byte from the stack to the AL register, and
		431	then invokes the routine pointed to by 'S_XMTIC'.
		432	;;
		433	;;
		434	;;
		435	;;
		436	Usage: CALL \$SXMTIC(c);
		437	;;
		438	Parameters:
		439	c - Character generated by the emulator
		440	;;
		441	Exit: NONE
		442	;;
		443	SXMTCP STRUC
0000		444	DW ?
0002		445	DW ?
0004		446	DB ?
0005		447	DB ?
		448	ENDS
		449	SXMTCP
001E		450	PROC NEAR
001E 55		451	PUBLIC SXMTIC
001F 8BEC		452	PUSH BP
		453	MOV BP,SP
		454	MOV AL,BP1.SXMTIC_C
0021 8A4604		455	CALL DS:S_XMTIC
0024 FF1E0000	E	456	; Invoke vectored routine
		457	POP BP
0028 5D		458	RET 2
0029 C20200		459	ENDP
		460	SXMTIC
		461	\$EJECT
		462	+1

LOC	OBJ	LINE	SOURCE
		661	
		662	
		663	
		664	
		665	
		666	;; @MOVE -- Move
		667	;;
		668	;; @MOVE moves the specified bytes from one location to
		669	;; another. Though the 8086 has instructions tuned for
		670	;; this operation, it is necessary to first compute the
		671	;; direction of the move---whether from high to low, or
		672	;; low to high. Since the true 20-bit addresses must be
		673	;; used for comparison, this takes a little work.
		674	;;
		675	;;
		676	;; NOTE: This routine will not wrap out of
		677	;; any of the segment boundaries,
		678	;; rather, it wraps around within
		679	;; them.
		680	;;
		681	;; Entry: DS = Source Segment
		682	;; SI = Source Offset
		683	;; ES = Destination Segment
		684	;; DI = Destination Offset
		685	;; CX = Byte Count
		686	;;
		687	;; Exit: Byte moved, SI and DI advanced, CX=0
		688	;;
		689	;;
		690	;; Uses: ALL
		691	;;
		692	;;
		693	;;
		694	;;
		695	;;
		696	;;
		697	;;
		698	;;
		699	;;
		700	;;
		701	;;
		702	;;
		703	;;
		704	;; Compute Absolute Source Address
		705	MOV AX,DS
		706	MOV DL,AH
		707	MOV CL,4
		708	SHL AX,CL
		709	SHR DL,CL
		710	ADD AX,SI
		711	ADD DL,0 ; DL,AH,AL = Source Address
		712	
		713	;; Compute Absolute Destination Address
		714	
		715	MOV BX,ES

XREF SYMBOL TABLE LISTING

NAME	TYPE	VALUE	ATTRIBUTES, XREFS
?3SEG	SEGMENT	0000H	SIZE=0000H PARA PUBLIC
ALTERNATE	V BYTE	0000H	S FIELD 67#
ANSI	V BYTE	0001H	S FIELD 68#
ASTLIB	SEGMENT	0002H	SIZE=0082H BYTE PUBLIC 'CODE' 205# 236 756
AUTO_CR	V BYTE	0003H	S FIELD 69#
AUTO_LF	V BYTE	0004H	S FIELD 70#
AUTO_REPEAT	V BYTE	0004H	S FIELD 71#
AX	V WORD	0014H	S FIELD 226#
BACK	V BYTE	0001H	S FIELD 44#
BASE	V WORD	0006H	S FIELD 316#
BBCOUNT	V WORD	0001H	S FIELD 100#
BOOT_PAR	V 83	0000H	EXTRN 187#
BOOT_PAR_STRUC	STRUC		SIZE=0053H #FIELDS=4 35 40# 187
BP	V WORD	000AH	S FIELD 221#
BURST	V BYTE	0000H	S FIELD 99#
BWD	V BYTE	0005H	S FIELD 72#
BX	V WORD	0012H	S FIELD 225#
CORGRP	GROUP		MTR100 CODE ASTLIB VIDEQA 205# 237
CLEAR	V BYTE	0003H	S FIELD 46#
CODE	SEGMENT		SIZE=0000H BYTE PUBLIC 'CODE' 148# 162 205
COL	V BYTE	0005H	S FIELD 102#
COLOR	V 7	0000H	EXTRN 188#
COLOR_STRUC	STRUC		SIZE=0007H #FIELDS=7 42 50# 188
COMMAND	V BYTE	0000H	S FIELD 58#
COMP_FONT	V BYTE	0006H	S FIELD 49#
COUNT	V WORD	0003H	S FIELD 101#
CPL	V BYTE	0000H	S FIELD 87#
CRLF	L NEAR	0000H	EXTRN 159#
CRTC_CURSOR	V 3	0000H	EXTRN 189#
CRTC_DISPLAY	V 3	0000H	EXTRN 190#
CRTC_STRUC	STRUC		SIZE=0003H #FIELDS=2 52 55# 189 190
CS	V WORD	0018H	S FIELD 228#
CURSQR	V BYTE	0006H	S FIELD 73#
CURSQR_ON	V BYTE	0007H	S FIELD 74#
CX	V WORD	0010H	S FIELD 224#
D_CRT	L NEAR	0000H	EXTRN 151#
D_KBD	L NEAR	0000H	EXTRN 152#
D_XMTC	V DWORD	0000H	EXTRN 175# 274
DATA	SEGMENT		SIZE=0000H WORD PUBLIC 'DATA' 167# 195 237
DCI	V DWORD	0000H	EXTRN 173#
DHC	V DWORD	0000H	EXTRN 174#
DI	V WORD	0006H	S FIELD 219#
DS	V WORD	0004H	S FIELD 218#
DSC	V BYTE	0001H	S FIELD 88#
DX	V WORD	000EH	S FIELD 223#
DXMTC	L NEAR	0000H	ASTLIB PUBLIC 268# 269 278
DXMTC_C	V BYTE	0004H	S FIELD 263# 273
DXMTCF	STRUC		SIZE=0006H #FIELDS=4 260 265#
EDC	V DWORD	0000H	EXTRN 176#
EMEC	V DWORD	0000H	EXTRN 177#
ES	V WORD	0000H	S FIELD 216#

NAME	TYPE	VALUE	ATTRIBUTES, XREFS
PROMPT.	V DWORD	00000H	EXTRN 181#
RDC	V DWORD	00000H	EXTRN 182#
REG	STRUC		SIZE=001CH #FIELDS=14 214 231# 578
REGP	V DWORD	00000H	EXTRN 170#
RESETF	V BYTE	00000H	EXTRN 171#
REVERSE	V WORD	0000CH	S FIELD 79#
ROW	V BYTE	00006H	S FIELD 103#
S_CRT	L NEAR	00000H	EXTRN 153#
S_KBD	L NEAR	00000H	EXTRN 154#
S_XMTC	V DWORD	00000H	EXTRN 183# 457
SYS	L NEAR	00000H	EXTRN 142#
SHIFTED	V BYTE	0000EH	S FIELD 80#
S1	V WORD	00003H	S FIELD 220#
SLI	V BYTE	00004H	S FIELD 91#
SP	V WORD	0000CH	S FIELD 222# 577
SPC	V BYTE	00005H	S FIELD 92#
SS	V WORD	0002H	S FIELD 217# 576
START	V WORD	00000H	S FIELD 53#
STATUS	V BYTE	000FH	S FIELD 81#
STRNG	V BYTE	0002H	S FIELD 38#
SW401	V BYTE	0006H	S FIELD 93#
SW402	V BYTE	0007H	S FIELD 94#
SXMT C	L NEAR	001EH	ASTLIB PUBLIC 451# 452 461
SXMT C	V BYTE	0004H	S FIELD 446# 456
SXMTCP	STRUC		SIZE=0064H #FIELDS=4 443 448#
TTY_INTR	L NEAR	0000H	EXTRN 156#
TTY_POLL	L NEAR	0000H	EXTRN 157#
TXMT	L NEAR	0000H	EXTRN 155#
UIES	V DWORD	0000H	EXTRN 184#
UNIT	V BYTE	0052H	S FIELD 39#
UPDATE	V BYTE	0002H	S FIELD 54#
UPDN	V BYTE	0010H	S FIELD 82#
VAL	V WORD	0008H	S FIELD 317#
VERT_LINE	V BYTE	0000H	EXTRN 169#
VIDEO_INTR	L NEAR	0000H	EXTRN 150# 492
VIDEO_INTR_A	L FAR	002CH	ASTLIB PUBLIC 474# 475 509
VIDEOA	SEGMENT		SIZE=0000H BYTE PUBLIC 'CODE' 200# 201 205
VRAM_SIZE	V BYTE	0008H	S FIELD 95#
WRAP	V BYTE	0011H	S FIELD 83#
WRITEC	L NEAR	0000H	EXTRN 161#
XCA	V DWORD	0000H	EXTRN 185#
XEC	L NEAR	0042H	ASTLIB PUBLIC 540# 541 598
XECP	STRUC		SIZE=0008H #FIELDS=3 533 537#
XECP_REGP	V DWORD	0004H	S FIELD 536# 562
XMT	V TBYTE	0000H	EXTRN 174#
XMT_COLOR	V BYTE	0007H	S FIELD 104#
XMT_GRAPHIC	V BYTE	0008H	S FIELD 105#
XMT_REVERSE	V BYTE	0009H	S FIELD 106#
XMT_STRUC	STRUC		SIZE=000AH #FIELDS=8 98 107# 194

ASSEMBLY COMPLETE, NO ERRORS FOUND

SERIES-III 3086/3087/3088 MACRO ASSEMBLER V1.0 ASSEMBLY OF MODULE VIDEOA
 OBJECT MODULE PLACED IN :F2:VIDEOA.OBU
 INVOCATION LINE CONTROLS: PRINT(:TO:) XREF ERRORPRINT(:TO:)

LOC	OBU	LINE	SOURCE
		1 +1	\$TITLE('MTR100 Z-Machine Monitor ROM: Assembly Video Library')
		2 +1	\$GEN
		3 +1	\$SYMBOLS
		4 +1	\$XREF
		5	;;
		6	MTR100 Video Library Assembly Procedures
		7	;
		7	Copyright(C) 1982, by:
		8	;
		9	Heath Co.
		10	Benton Harbor, MI
		11	47022
		12	;
		13	;
		14	;
		15	This library implements the critical assembly language
		16	routines necessary for the video library. These routines
		17	assume the PL/M-86 calling convention and the COMPACT
		18	model of computation, however, they are invoked via "far"
		19	calls.
		20	;
		21	These routines assumes that the CRT-C is programmed for 9
		22	scan lines per character, and that the current VRMM par-
		23	ameters are valid. The video address is computed as:
		24	vert*16+128+char = vert*8*256+char
		25	;
		26	;
		27	;
		28	By: G. Chandler
		29	Date: 7-Jan-1982
		30	;
		31 +1	\$ EJECT

LOC	OBJ	LINE	SOURCE
00000		144	H19_PAR_STRUC STRUC
00001		145	CPL DB
00002		146	DISC DB
00003		147	LPS DB
00004		148	POVRAM DB
00005		149	SLI DB
00006		150	SPC DB
00007		151	SM401 DB
00008		152	SM402 DB
		153	VRAM_SIZE DB
		154	H19_PAR_STRUC ENDS
		155	
		156	XMT_STRUC STRUC
00001		157	BURST DB
00003		158	BCCOUNT DW
00005		159	COUNT DW
00006		160	COL DB
00007		161	ROW DB
00008		162	XMT_COLOR DB
00009		163	XMT_GRAPHIC DB
		164	XMT_REVERSE DB
		165	XMT_STRUC ENDS
		166	
		167	
		168	#RESTORE
		169	
		170	
		171	
		172	
			; Global's Definitions
			;
			XIF(%NES(ASTLIB,%SEGMENT_LABEL)) THEN (
			ASTLIB SEGMENT BYTE PUBLIC 'CODE'
			EXTRN VIDEO_INTR_A:FAR
			ENDS
			ASTLIB
			FI
);
			XIF(%NES(FONTAB,%SEGMENT_LABEL)) THEN (
			FONTAB SEGMENT BYTE PUBLIC 'DATA'
			EXTRN MTR_FONT:BYTE
			ENDS
			FONTAB
			FI
);
			XIF(%NES(MTR100,%SEGMENT_LABEL)) THEN (
			; INTVEC SEGMENT PUBLIC 'DATA'
			EXTRN ITV_SST:DWORD
			EXTRN ITV_OBI:DWORD
			EXTRN DS_PTR_O:WORD
			EXTRN DS_PTR_S:WORD
			ENDS
			; INTVEC
);
			; INTVEC
			MONENT
			SEGMENT PARA PUBLIC
			EXTRN MTR_RES:FAR
			EXTRN MTR_MON:FAR
			EXTRN MTR_SWIM:FAR
			EXTRN MTR_DCRT:FAR
			EXTRN MTR_SCRT:FAR
			; Monitor Reset
			; Monitor CALL Entry
			; Monitor Software Interrupt Entry
			; Monitor Dumb Terminal Emulator
			; Monitor Smart Terminal Emulator

LOC	OBJ	LINE	SOURCE
		=1	EXTRN CRIC_DISPLAY:CRIC_STRUC
		=1	EXTRN ESCP:ESCP_STRUC
		=1	EXTRN H19_MODE:H19_MODE_STRUC
		=1	EXTRN H19_PAR:H19_PAR_STRUC
		=1	EXTRN XMT:XMT_STRUC
		=1	ENDS
		259	DATA
		=1)FI
		=1	%IF(ZNES(VIDEOA,YSEGMENT_LABEL)) THEN (
		=1	VIDEOA SEGMENT_BYTE_PUBLIC 'CODE'
		=1	VIDEOA SEGMENT_BYTE_PUBLIC 'CODE'
		=1	ENDS
		=1)FI
		262	CGROUP GROUP MTR100, CODE, ASTLIB, VIDEOA
		=1	
		=1	
		=1	
		=1	
		264	\$RESTORE
		=1	
		=1	
		266	
		=1	
		267	
		=1	
		268	
		269	
		270	
		271	VIDEOA SEGMENT_BYTE_PUBLIC 'CODE' ; Concatenate with the Code Segment
		272	ASSUME CS:CGROUP, DS:DATA
		273	
		274	
		275	SLPC EQU 9+2 ; Scan Lines Per Character, 9 for char. + 2 for attrib.
		276	
		277	VID_CMD EQU 0D8H ; Video Command Port
		278	
		279	
		280	
		281	
		282	CB_BLK EQU 000B ; Black
		283	CB_BLU EQU 100B ; Blue
		284	CB_RED EQU 001B ; Red
		285	CB_GRN EQU 010B ; Green
		286	
		287	CB_MAG EQU CB_RED+CB_BLU ; Magenta
		288	CB_CYN EQU CB_GRN+CB_BLU ; Cyan
		289	CB_YEL EQU CB_GRN+CB_RED ; Yellow
		290	CB_WHT EQU CB_GRN+CB_RED+CB_BLU ; White
		291	
		292	
		293	
		294	CL_BLK EQU 000B ; Black
		295	CL_BLU EQU 001B ; Blue
		296	CL_RED EQU 010B ; Red
		297	CL_MAG EQU CL_RED+CL_BLU ; Magenta
		298	CL_GRN EQU 100B ; Green
		299	CL_CYN EQU CL_GRN+CL_BLU ; Cyan
		300	CL_YEL EQU CL_GRN+CL_RED ; Yellow
		301	CL_WHT EQU CL_GRN+CL_RED+CL_BLU ; White
		302 +1	\$EJECT

LOC	OBJ	LINE	SOURCE
		317	;; MTR_DFC -- Display Font Character
		318	;;
		319	MTR_DFC displays the indexed font character at the specified
		320	screen address. The value of compf is XOR'd with each of
		321	the bytes displayed, thus, the character will be displayed
		322	straight if compf is 0, or it will be displayed in reverse
		323	video if compf is 0FFFFH.
		324	;;
		325	Usage: CALL MTR_DFC(horz,vert,findx,compf)
		326	;;
		327	Entry:
		328	horz = Horizontal character index within line [0,79] BYTE
		329	vert = Vertical character index within screen [0,24] BYTE
		330	findx = Index into Font ROM for the character [0,127] BYTE
		331	compf = Mask to be XOR'd with display bytes WORD
		332	;;
		333	Globals:
		334	Color structure initialized
		335	;;
		336	Exit: NONE
		337	;;
		338	;;
		339	P_DFC
0000		340	STRUC
0002		341	DW ? ;
0004		342	DW ? ;
0006		343	DW ? ; A real WORD
0008		344	DDB ? ; Font Character Index
0009		345	DDB ? ;
000A		346	DDB ? ; Vertical Character Line
000B		347	DDB ? ;
000C		348	DDB ? ; Horizontal Character Column
000D		349	DDB ? ;
		350	P_DFC ENDS
		351	;;
		352	;;
0001		353	MTR_DFC PROC FAR
0001	55	354	PUBLIC MTR_DFC
0002	8BEC	355	PUSH BP
		356	MOV BP,SP
0004	1E	357	PUSH DS
0005	E4D8	358	IN AL,VID_CMD
0007	50	359	PUSH AX
		360	;; Save current parameters
		361	;;
		362	Compute offset of character in Video RAM
		363	;;
0008	8A5E0C	364	MOV BL,[BP].DFC_HORZ ; BL = Horizontal Character Index
000B	8A7E0A	365	MOV BH,[BP].DFC_VERT ; BH = Vertical Line Index
000E	E80C03	366	CALL CCA ; Compute Character Address
		367	;;
		368	Compute offset of character in Font ROM
0011	8A4E08	369	MOV CL,[BP].DFC_FINDX ; CL = Font ROM Character Index
0014	B500	370	MOV CH,0
		371	;;

LOC	OBJ	LINE	SOURCE
006A	5B	427	
006B	EBB602	428	POP BX ; BL = COLOR.FRONT
006E	7403	429	CALL SWP ; Set Write Parameters
0070	EB3700	430	JZ DF04 ; No Foreground Color
0073	B307	431	CALL DF05 ; Display the character
0075	EBAC02	432	CALL LABEL NEAR
0078	EB13	433	MOV BL,CL_MHT
		434	CALL SWP ; Write to all planes of VRAM
		435	JMP SHORT DF04_6
007A	A00200	436	DF04_3: MOV AL,COLOR_MSK
007D	50	437	PUSH AX ; Save Color Mask
007E	8B4E06	438	MOV CX,[BP].DFC_COMPF ; CX = Complement Flag
0081	C5060000	439	LDS AX,Font ; DS:SI = Pointer to Font Character
0085	03F0	440	ADD SI,AX ; Set Write Parameters to all Green
0087	EB1602	441	CALL SWPG
008A	EB1D00	442	CALL DF05
008D		443	CALL LABEL NEAR
		444	DF04_6: LABEL
		445	
		446	
		447	
		448	
		449	Save Character Attributes
008D	8A4608	449	MOV AL,[BP].DFC_FINDX ; Save font Index
0070	26385804	450	MOV ES:BYTE PTR EDI+9*1281,AL
		451	
0095	58	452	POP AX ; AL = COLOR_MSK
0096	243F	453	AND AL,00111111B ; Set Color Mask
0098	80E580	454	CH,080H
009B	0AC5	455	OR AL,CH ; Set Reverse Video Flag
009D	263858005	456	MOV ES:BYTE PTR EDI+10*1281,AL ; Save Character Attributes
		457	
00A2	58	458	POP AX
00A3	E6D8	459	VID_CMD,AL ; Restore original video register
00A5	1F	460	DS
		461	
00A6	5D	462	POP BP
00A7	CA0800	463	RET 8
		464	
		465	
		466	
		467	
		468	
00AA	56	469	DF05: PROC NEAR
		470	PUSH SI
		471	
00AB	AD	472	LODSW ; AX = Font character (0,1)
00AC	33C1	473	XOR AX,CX ; Complement bits for reverse video
00AE	263805	474	ES:BYTE PTR EDI+0*1281,AL
00B1	2638A58000	475	MOV ES:BYTE PTR EDI+1*1281,AH
00B6	AD	476	LODSW ; AX = Font character (2,3)
00B7	33C1	477	XOR AX,CX
00B9	2638350001	478	ES:BYTE PTR EDI+2*1281,AL
00BE	2638A58001	479	MOV ES:BYTE PTR EDI+3*1281,AH
00C3	AD	480	LODSW ; AX = Font character (4,5)
00C4	33C1	481	XOR AX,CX

LOC	OBJ	LINE	SOURCE
		519	;; MTR_EDC -- Erase Display Character
		520	;;
		521	MTR_EDC erases the specified character from the screen.
		522	In this case, it merely zeroes out video RAM.
		523	;;
		524	NOTE: This routine assumes that all of the char-
		525	acters are on the same line! If they are
		526	not, bad video RAM may be smashed due to
		527	the memory mapping scheme (in a 32KB system).
		528	;;
		529	Usage: CALL MTR_EDC(line, char, count);
		530	;;
		531	Parameters:
		532	;;
		533	line -- Line of character to erase, BYTE, [0-24]
		534	char -- First Character to erase, BYTE, [0-79]
		535	count -- Number of characters to erase, BYTE, [0-79]
		536	;;
		537	Exit: NONE
		538	;;
		539	;;
0000		540	P_EDC STRUC
0002		541	DW ?
0004		542	DW ?
0006		543	DW ?
0007		544	DB ? ; Count
0008		545	DB ? ; Character
0009		546	DB ? ; Line
000A		547	DB ?
000B		548	DB ?
		549	DB ?
		550	ENDS
		551	;;
010E		552	MTR_EDC PROC FAR
010E	55	553	PUBLIC MTR_EDC
010F	8BEC	554	PUSH BP
		555	MOV BP, SP
		556	;;
		557	IN AL, VID_CMD
0111	E4D8	558	PUSH AX
0113	50	559	;; Save Video Parameters
		560	;;
		561	Fetch Parameters
		562	;;
0114	8A7E0A	563	MOV BH, [BP+1.EDC_LINE]; BH = Row
0117	8A5E08	564	MOV BL, [BP+1.EDC_CHAR]; BL = Column
011A	E80102	565	CALL CCA_
011D	8A5606	566	MOV DI, [BP+1.EDC_COUNT]
0120	B600	567	DI, 0
0122	B90900	568	MOV CX, SLP0-2 ; DX = Character Count
		569	;; CX = Scan Lines per Character
		570	;; Zero the characters one scan line at a time
0125	HC	571	CLD ; Auto-Increment
0126	51	572	PUSH CX ; Save Scan Line Count
		573	EDC1: ;

LOC	OBJ	LINE	SOURCE
		628 +1	\$EJECT

LOC	OBJ	LINE	SOURCE
018A	8BF3	684	MOV SI,BX ; SI = Source Character Address
018C	8A5606	685	MOV DL,(BP),MDC_COUNT ; DX = Move Count
018F	B600	686	MOV DH,0 ; CX = Scan Lines per Character
0191	B90B00	687	MOV CX,SLPC
0194	33FA00	688	CMP DX,0
0197	744E	689	JE MDC4 ; No characters to move
0199	FC	690	CLD ; Assume Auto-Increment
019A	B80000	691	MOV AX,0 ; Assume no negative word adjust
019D	3BFE	692	CMP DI,SI
019F	7213	693	JB MDC1
		694	
		695	
		696	
		697	Destination >= Source
01A1	FD	698	STD ; Auto-Decrement
01A2	B3FFFF	699	MOV AX,-1 ; Back each address up one byte before movsw
01A5	03FA	700	ADD DI,DX
01A7	4F	701	DEC DI
01A8	03F2	702	ADD SI,DX
01AA	4E	703	DEC SI ; Advance Pointers to the end of strings
		704	
01AB	8A1E0500	705	MOV BL,H19_MODE_BMO
01AF	30FFFF	706	CMP BL,PLM_TRUE ; Optimize Black & White
01B2	741D	707	JZ MDC2
		708	
		709	
		710	Move Color Characters
01B4	51	711	
01B5	B304	712	PUSH CX ; MDC1:
01B7	E83500	713	MOV BL,CL_GRN ; BL,CL_GRN
01BA	B302	714	CALL MDC5 ; Move Green Plane
01BC	E83000	715	MOV BL,CL_RED ; BL,CL_RED
01BF	B301	716	CALL MDC5 ; Move Red Plane
01C1	E82E00	717	MOV BL,CL_BLU ; BL,CL_BLU
01C4	59	718	CALL MDC5 ; Move Blue Plane
		719	POP CX
01C5	81C78000	720	ADD DI,128
01C9	81C68000	721	ADD SI,128
01CD	E2E5	722	LOOP MDC1
01CF	EB16	723	JMP SHORT MDC4
		724	
		725	
		726	Optimized Black & White Character Move
01D1	50	727	
01D2	E88E01	728	PUSH AX ; MDC2:
01D5	8ED8	729	CALL SWPG ; Set Multiple Write for all planes
01D7	58	730	MOV DS,AX ; Source Plane = Destination Plane
		731	POP AX
01D8	51	732	PUSH CX ; MDC3:
01D9	E81A00	733	CALL MDC6 ; MDC6
01DD	59	734	POP CX
01DD	81C78000	735	ADD DI,128
01E1	81C68000	736	ADD SI,128
01E5	E2F1	737	LOOP MDC3
		738	

LOC	OBJ	LINE	SOURCE
776			;;
777			MTR_MD_L ... Move Display Line
778			;
779			MTR_MD_L moves the line of characters to the spec-
780			ified destination line.
781			;
782			Usage: CALL MTR_MD_L(line_src,line_dst);
783			Parameters:
784			line_src -- Source Line
785			line_dst -- Destination Line
786			Exit: NONE
787			;
788			;
789			;
790			;
791			;
792			;
793			;
794			;
795			P_MD_L STRUC
796			DW ?
797			DW ?
798			DW ?
799			DB ? ; Destination Line
800			DB ?
801			DB ? ; Source Line
802			DB ?
803			P_MD_L ENDS
804			;
805			;
806			MTR_MD_L PROC FAR
807			PUBLIC MTR_MD_L
808			PUSH BP
809			MOV BP,SP
810			PUSH DS
811			IN AL,VID_CMD
812			PUSH AX
813			;
814			;
815			Initialize from Parameters
816			MOV BH,[BP].MDL_DST
817			MOV BL,0
818			CALL CCA_0
819			MOV BH,[BP].MDL_SRC
820			CALL CCA
821			MOV SI,BX
822			;
823			MOV DH,0
824			MOV DL,H19_PAR.CPL
825			MOV CX,SLPC
826			CLD
827			;
828			MOV BL,H19_MODE.BMO
829			CMP BL,PLM_TRUE
830			JL MDL2
			; Optimize this line move
020F	8A7E06		
0212	B300		
0214	E80701		
0217	8A7E08		
021A	ESFA00		
021D	8BF3		
021F	B600		
0221	8A160000	E	
0225	B90B00		
0228	FC		
0229	8A1E0500	E	
022D	80FEFF		
0230	741D		

LOC	OBJ	LINE	SOURCE
027D	C3	885	RET
		886	
		887	MDL5
		888	ENDP
		889	
		890	
		891	
		892	+1 \$EJECT

LOC	OBJ	LINE	SOURCE		
02BE	00				
02BF	00				
02C0	00				
02C1	C0	948		DB	11000000B,00111111B,11111111B,11111100B
02C2	3F				
02C3	FF				
02C4	FC	949		DB	01111100B,11000000B,01000000B,00000010B
02C5	7C				
02C6	C0				
02C7	40				
02C8	02				
02C9	47	950		DB	01000111B,00000000B,00111111B,11111100B
02CA	00				
02CB	3F				
02CC	FC	951		DB	01000100B,00001100B,00100010B,00000000B
02CD	44				
02CE	0E				
02CF	22				
02D0	00				
02D1	47	952		DB	01000111B,00000001B,11111100B,00000000B
02D2	01				
02D3	FC				
02D4	00				
02D5	7C	953		DB	01111100B,11000001B,00000100B,00000000B
02D6	C1				
02D7	04				
02D8	00				
02D9	C0	954		DB	11000000B,00111111B,11111000B,00000000B
02DA	3F				
02DB	F8				
02DC	00				
02DD	00	955		DB	00000000B,00000000B,00000000B,00000000B
02DE	00				
02DF	00				
02E0	00				

956
 957 MTR_FRMPT ENDP
 958
 959
 960
 961
 962 +1 \$EJECT

LOC	OBJ	LINE	SOURCE
		1018	MTR_RDC ENDP
		1019	
		1020	
		1021	
		1022	
		1023 +1	\$EJECT

LOC	OBJ	LINE	SOURCE
		1065	;;
		1066	;;
		1067	;;
		1068	;;
		1069	;;
		1070	;;
		1071	;;
		1072	CCA returns the character offset in BX based
		1073	on the character Row and Column.
		1074	;;
		1075	Entry: BH -- Character Row
		1076	;;
		1077	;;
		1078	Exit: BX -- Character Offset within Video Plane
		1079	;;
		1080	;;
		1081	;;
0317	D0E7	1082	CCA
0317	D0E7	1083	PROC
0319	D0E7	1084	SHL
031B	D0E7	1085	SHL
031D	C3	1086	RET
		1087	ENDP
		1088	;;
		1089	;;
031E	E9F6FF	1090	CCA_
0321	8BFB	1091	PROC
0323	C3	1092	CALL
		1093	MOV
		1094	RET
		1095	ENDP
		+1	CCA_
			\$EJECT

LOC	OBJ	LINE	SOURCE				
0350	0000	1151	SWPB	DM	00000H		; Black
0352	00C0	1152		DM	PAR_BLU		; Blue
0354	00D0	1153		DM	PAR_RED		; Red
0356	00D0	1154		DM	PAR_RED		; Magenta
0358	00E0	1155		DM	PAR_GRN		; Green
035A	00E0	1156		DM	PAR_GRN		; Cyan
035C	00E0	1157		DM	PAR_GRN		; Yellow
035E	00E0	1158		DM	PAR_GRN		; White
		1159					
		1160	SWP	ENDP			
		1161					
		1162					
		1163					
		1164					
0360		1165	SWPG	PROC	NEAR		
0360	E4D8	1166		IN	AL,VID_CMD		
0362	240F	1167		AND	AL,00001111B		
0364	E6D8	1168		OUT	VID_CMD,AL		
0366	B800E0	1169		MOV	AX,FAR_GRN		
0369	23C0	1170		AND	AX,AX		
036B	8ECC	1171		MOV	ES,AX		
036D	C3	1172		RET			; FLAGS = NZ
		1173					
		1174	SWPG	ENDP			
		1175					
		1176					
		1177					
		1178					
		1179	VIDEQA	ENDS			
		1180					
		1181		END			

NAME	TYPE	VALUE	ATTRIBUTES, XREFS
DCI	V DWORD	0000H	EXTRN 235#
DFC	V DWORD	0000H	EXTRN 236#
DFC_COMPF	V WORD	0006H	S FIELD 343# 413 439
DFC_FINDX	V BYTE	0008H	S FIELD 344# 370 449
DFC_HORZ	V BYTE	000CH	S FIELD 348# 364
DFC_VERT	V BYTE	000AH	S FIELD 346# 365
DFC1	L NEAR	003AH	VIDEOA 392 395#
DFC2	L NEAR	0048H	VIDEOA 401 404#
DFC3	L NEAR	006AH	VIDEOA 420 424#
DFC4	L NEAR	0073H	VIDEOA 430 432#
DFC4_3	L NEAR	007AH	VIDEOA 386 437#
DFC4_6	L NEAR	008DH	VIDEOA 435 444#
DFC5	L NEAR	00AAH	VIDEOA 422 431 443 469# 495
DFC6	L NEAR	00E7H	VIDEOA 394 403 500# 517
DS_SIZE	NUMBER	0040H	63#
DSC	V BYTE	0001H	S FIELD 146#
EDC	V DWORD	0000H	EXTRN 238#
EDC_CHAR	V BYTE	0008H	S FIELD 546# 564
EDC_COUNT	V BYTE	0005H	S FIELD 544# 566
EDC_LINE	V BYTE	000AH	S FIELD 548# 563
EDC1	L NEAR	0126H	VIDEOA 573# 593
EDC2	L NEAR	013AH	VIDEOA 579 582#
EDC3	L NEAR	0146H	VIDEOA 586 589#
EDC4	L NEAR	016BH	VIDEOA 581 588 600 604 616# 627
EDC5	L NEAR	0173H	VIDEOA 621 623#
EMEC	V DWORD	0000H	EXTRN 239#
ESCP	V TBYTE	0000H	EXTRN 253# 1038
ESCP_STRUC	STRUC		SIZE=000AH #FIELDS=6 115 122# 253
EXPAND	V BYTE	0008H	S FIELD 133#
FONT	V DWORD	0000H	EXTRN 240# 414 440
FONTAB	SEGMENT		SIZE=0000H BYTE 'PUBLIC 'DATA' 180# 182
FORE	V BYTE	0000H	S FIELD 101#
FUNCTION	V WORD	0001H	S FIELD 117#
GRAPHIC	V BYTE	0009H	S FIELD 134#
H19_MODE	V 18	0000H	EXTRN 254# 384 705 828 1037
H19_MODE_STRUC	STRUC		SIZE=0012H #FIELDS=17 124 142# 254
H19_PAR	V 9	0000H	EXTRN 255# 824
H19_PAR_STRUC	STRUC		SIZE=0009H #FIELDS=9 144 154# 255
HORIZ_CHAR	V BYTE	0000H	EXTRN 230# 911
INDEX	V BYTE	0000H	S FIELD 74#
INIT	L NEAR	0000H	EXTRN 222#
INSERT	V BYTE	000AH	S FIELD 135#
ITV_OBI	V DWORD	0000H	EXTRN 189#
ITV_SST	V DWORD	0000H	EXTRN 188#
KEY_EN	V BYTE	0008H	S FIELD 136#
LFS	V BYTE	0002H	S FIELD 147#
MDC	V DWORD	0000H	EXTRN 241#
MDC_COUNT	V DWORD	0006H	S FIELD 659# 685
MDC_DST	V BYTE	0003H	S FIELD 661# 681
MDC_LINE	V BYTE	000CH	S FIELD 665# 680
MDC_SRC	V BYTE	000AH	S FIELD 663# 683
MDC1	L NEAR	0184H	VIDEOA 674 711# 722
MDC2	L NEAR	01D1H	VIDEOA 707 727#
MDC3	L NEAR	01D8H	VIDEOA 732# 737
MDC4	L NEAR	01E7H	VIDEOA 690 723 739#

NAME	TYPE	VALUE	ATTRIBUTES, XREFS
PAR_VID	NUMBER	C000H	67#
PFRONT	V BYTE	0005H	S FIELD 106# 410 928
PLM_TRUE	NUMBER	00F7H	S2# 385 706 829
PORT	V BYTE	0001H	S FIELD 95#
POVRAM	V BYTE	0003H	S FIELD 148#
PROMPT	V DWORD	0000H	EXTRN 243#
RDC	V DWORD	0000H	EXTRN 244#
RDC_HORZ	V BYTE	0006H	S FIELD 939# 1006
RDC_VERT	V BYTE	0008H	S FIELD 991# 1007
RDC_XC_PTR	V DWORD	0004H	S FIELD 993# 1011
REG	V DWORD	0000H	EXTRN 232#
RESETF	V BYTE	0000H	EXTRN 233#
REVERSE	V WORD	000CH	S FIELD 137#
ROW	V BYTE	0006H	S FIELD 161#
S_CRT	L NEAR	0000H	EXTRN 215#
S_KBD	L NEAR	0000H	EXTRN 216#
S_XMTC	L DWORD	0000H	EXTRN 245#
SDS	L NEAR	0000H	EXTRN 204#
SHIFTED	V BYTE	000EH	S FIELD 138#
S_LI	V BYTE	0004H	S FIELD 149#
S_LPC	NUMBER	0003H	275# 568 687 825 930
SPC	V BYTE	0005H	S FIELD 150#
SS_SIZE	NUMBER	0020H	62#
START	V WORD	0000H	S FIELD 111#
STATUS	V BYTE	000FH	S FIELD 139#
STRNG	V BYTE	0002H	S FIELD 96#
SW401	V BYTE	0005H	S FIELD 151#
SW402	V BYTE	0007H	S FIELD 152#
SWP	L NEAR	0324H	VIDEOA 391 400 419 429 434 578 585 598 752 872 929 1119# 1160
SWP1	L NEAR	032AH	VIDEOA 1121 1124#
SWPA	V BYTE	0348H	VIDEOA 1128 1140#
SWPB	V WORD	0350H	VIDEOA 1133 1151#
SWPG	L NEAR	0360H	VIDEOA 442 728 850 1004 1165# 1174
TTY_INTR	L NEAR	0000H	EXTRN 218#
TTY_POLL	L NEAR	0000H	EXTRN 219#
TXMT	L NEAR	0000H	EXTRN 217# 1056
UIES	V DWORD	0000H	EXTRN 246#
UNIT	V BYTE	0052H	S FIELD 97#
UPDATE	V BYTE	0002H	S FIELD 112#
UPDN	V BYTE	0010H	S FIELD 140#
VERT_LINE	V BYTE	0000H	EXTRN 231# 910
VID_CMD	NUMBER	00D8H	277# 359 459 558 607 675 741 811 862 905 941 1001 1015 1126 1131 1166 1168
VIDEO_INTR	L NEAR	0000H	EXTRN 212#
VIDEO_INTR_A	L FAR	0000H	EXTRN 174#
VIDEOA	SEGMENT		SIZE=036EH BYTE PUBLIC 'CODE' 264# 271 1179
VRAM_SIZE	V BYTE	0008H	S FIELD 153#
WRAP	V BYTE	0011H	S FIELD 141#
WRITEC	L NEAR	0000H	EXTRN 223# 921
XCA	V DWORD	0000H	EXTRN 247#
XMT	V TBYTE	0000H	EXTRN 256#
XMT_COLOR	V BYTE	0007H	S FIELD 162#
XMT_GRAPHIC	V BYTE	0008H	S FIELD 163#
XMT_REVERSE	V BYTE	0009H	S FIELD 164#
XMT_STRUC	STRUC		SIZE=000AH #FIELDS=8 156 165# 256

SERIES-III 8086/8087/8088 MACRO ASSEMBLER V1.0 ASSEMBLY OF MODULE B207A
OBJECT MODULE PLACED IN : F2:B207A.OBJ
INVOCATION LINE CONTROLS: PRINT(::TO:) XREF ERRORPRINT(::TO:)

LOC OBJ LINE SOURCE

LOC	OBJ	LINE	SOURCE	DB	?	;	;
0002		50	MSK	DB	?	;	SHL(Back,3) OR Fore
0003		51	CLEAR	DB	?	;	Color to Clear
0004		52	PAINTED	DB	?	;	Color to Fully Paint
0005		53	PFONT	DB	?	;	Color to set to Font Pattern
0006		54	COMP_FONT	DB	?	;	Color to set to Complement of Font Pattern
		55	COLOR_STRUC	ENDS			
		56					
		57	CRTC_STRUC	STRUC		;	CRT-C..... Start Address
0000		58	START	DW	?	;	True if update is required
0002		59	UPDATE	DB			
		60	CRTC_STRUC	ENDS			
		61					
		62	ESCP_STRUC	STRUC		;	Current Escape Command
0000		63	COMMAND	DB	?	;	Pointer to Escape Processor
0001		64	FUNCTION	DW	?	;	Escape Emulation Mode
0003		65	MODE	DB	?	;	Operand Count
0004		66	OPER_COUNT	DB	?	;	Operand Index
0005		67	OPER_INDEX	DB	?	;	Operands
0006		68	OPERAND	DB	4	DUP(?)	
		69	ESCP_STRUC	ENDS			
		70					
		71	H19_MODE_STRUC	STRUC		;	Alternate Key-pad Mode
0000		72	ALTERNATE	DB	?	;	ANSI Mode
0001		73	ANSI	DB	?	;	Auto Carriage-Return on Line-Feed
0002		74	AUTO_CR	DB	?	;	Auto Line-Feed on Carriage-Return
0003		75	AUTO_LF	DB	?	;	Auto-Repeat Keyboard
0004		76	AUTO_REPEAT	DB	?	;	Black and White Optimization
0005		77	BWD	DB	?	;	Programmed Cursor Value
0006		78	CURSOR	DB	?	;	Cursor Enabled
0007		79	CURSOR_ON	DB	?	;	Expand Key-Board Characters
0008		80	EXPAND	DB	?	;	Graphic Character Mode
0009		81	GRAPHIC	DB	?	;	Insert Character Mode
000A		82	INSERT	DB	?	;	Key-Board Enable
000B		83	KEY_EN	DB	?	;	Reverse Video
000C		84	REVERSE	DW	?	;	Shifted Key-Pad Mode
000E		85	SHIFTED	DB	?	;	Status-Line Enabled
000F		86	STATUS	DB	?	;	Key-Board Up/Down Mode
0010		87	UPDN	DB	?	;	Wrap at End-of-Line
0011		88	WRAP	DB	?	;	
		89	H19_MODE_STRUC	ENDS			
		90					
		91	H19_PAR_STRUC	STRUC		;	Characters Per Line
0000		92	CPL	DB	?	;	Displayed Scan Lines per Character
0001		93	DSC	DB	?	;	Lines Per Screen
0002		94	LPS	DB	?	;	Planes of Video RAM
0003		95	FOVRAM	DB	?	;	Status Line Index
0004		96	SLI	DB	?	;	Scan Lines per Character
0005		97	SPC	DB	?	;	H19-Switch 401
0006		98	SW401	DB	?	;	H19-Switch 402
0007		99	SW402	DB	?	;	0-32KBytes, 1-64KBytes
0008		100	VRAM_SIZE	DB	?	;	
		101	H19_PAR_STRUC	ENDS			
		102					
		103	XMT_STRUC	STRUC		;	Characters to Transmit per VSYNC
0000		104	BURST	DB	?	;	

LOC	OBJ	LINE	SOURCE
=1			EXTRN MTR101:NEAR ; PL/M-86 Monitor Loop
=1			EXTRN VIDED_INTR:NEAR ; PL/M-86 Video Interrupt
=1			EXTRN D_CRTI:NEAR ; PL/M-86 Dumb Terminal
=1			EXTRN D_KBD:NEAR ; PL/M-86 Dumb Key-Board
=1			EXTRN S_CRTI:NEAR ; PL/M-86 Smart Terminal
=1			EXTRN S_KBD:NEAR ; PL/M-86 Smart Key-Board
=1			EXTRN TXMT:NEAR ; PL/M-86 Transmit Screen Character
=1			EXTRN TTY_INTR:NEAR ; PL/M-86 Terminal Interrupt
=1			EXTRN TTY_POLL:NEAR ; PL/M-86 Interrupt Poll
=1			EXTRN CRLE:NEAR ; PL/M-86 CR-LF
=1			EXTRN INIT:NEAR ; PL/M-86 Initialize Hardware
=1			EXTRN WRITEC:NEAR ; PL/M-86 Write Character
=1			ENDS
=1			CODE
=1)FI
=1		169	
=1		170	
=1		171	
=1			DATA
=1			SEGMENT WORD PUBLIC 'DATA'
=1			EXTRN HORIZ_CHAR:BYTE ; Column Index
=1			EXTRN VERT_LINE:BYTE ; Row Index
=1			EXTRN RESETF:BYTE ; Hardware Reset Flag
=1			EXTRN DCI:DWORD ; Display Character Initialization
=1			EXTRN DFC:DWORD ; Display Font Character
=1			EXTRN D_XMTC:DWORD ; Dumb Terminal Transmit Character
=1			EXTRN EDC:DWORD ; Erase Display Character
=1			EXTRN EMEC:DWORD ; Extend-Mode Escape Character
=1			EXTRN FONT:DWORD ; Pointer to Font Table
=1			EXTRN MDC:DWORD ; Move Display Character
=1			EXTRN MDL:DWORD ; Move Display Line
=1			EXTRN PROMPT:DWORD ; Display Monitor Prompt
=1			EXTRN RDC:DWORD ; Read Display Character
=1			EXTRN S_XMTC:DWORD ; Smart Terminal Transmit Character
=1			EXTRN UIES:DWORD ; Un-Implemented Escape Sequence
=1			EXTRN XCA:DWORD ; Transmit Character Attributes
=1			EXTRN BOOT_PAR:BOOT_PAR_STRUC
=1			EXTRN COLOR:COLOR_STRUC
=1			EXTRN CURSOR:CRTC_STRUC
=1			EXTRN CRIC_DISPLAY:CRTC_STRUC
=1			EXTRN ESCP:ESCP_STRUC
=1			EXTRN H19_MODE:H19_MODE_STRUC
=1			EXTRN H19_PAR:H19_PAR_STRUC
=1			EXTRN XMT:XMT_STRUC
=1			ENDS
=1			DATA
=1)FI
=1		202	
=1		203	
=1		204	
=1			IF(%NES(VIDEA,%SEGMENT_LABEL)) THEN (
=1			VIDEA SEGMENT BYTE PUBLIC 'CODE'
=1			VIDEA
=1)FI
=1			ENDS
=1		208	

LOC	OBJ	LINE	SOURCE
		242	; ; CSP - Controller Status Port
		243	; ; CSP returns the value for the controller status port
		244	; ;
		245	; ; Entry: NONE
		246	; ;
		247	; ; Exit: AL = Controller Status Port Value
		248	; ;
		249	; ;
		250	; ; Uses: AL, DH
		251	; ;
		252	; ;
0000		253	CSP PROC NEAR
		254	PUBLIC CSP
		255	
0000	0A160100	256	MOV DL,BOOT_PAK,PORT
0004	B600	257	MOV DH,0 ; DX = Device Port
0005	EC	258	IN AL,DX
0007	C3	259	RET
		260	
		261	CSP ENDP
		262	+1 \$EJECT

LOC	OBJ	LINE	SOURCE
		300	;;
		301	RDTRACKA -- Read Track
		302	;;
		303	RDTRACKA is the assembly language assist routine
		304	for RDTRACK. This routine is required to perform
		305	the actual disk transfer, as the code may be opt-
		306	imized.
		307	;;
		308	Usage: CALL RDTRACKA(base_port,cmd,cnt,ptr\$data)
		309	;;
		310	Entry: base_port = Base Port Address for device
		311	cmd = command
		312	cnt = Byte Count
		313	ptr\$data = Address to save data at
		314	;;
		315	Exit: AX = Byte Count
		316	;;
		317	Uses: ???
		318	;;
		319	;;
		320	RDTRACKA STRUC
		321	DW ?
		322	DW ?
		323	DD ? ; Address to save data at
		324	CNT ? ; Byte Count
		325	CMD ? ; Command
		326	BASE_PORT ? ; Base Port Address for device
		327	RDTRACKA ENDS
		328	;;
		329	;;
		330	RDTRACKA PROC NEAR
0019		331	PUBLIC RDTRACKA
		332	;;
		333	PUSH BP
001A	8BEC	334	MOV BP,SP
		335	;;
		336	MOV DX,[BP],BASE_PORT
001C	8B560C	337	MOV AX,[BP],CMD
001F	8B460A	338	MOV DX,AL
0022	EE	339	OUT
		340	;;
		341	CLD
0023	FC	342	XOR BX,BX ; Set auto-increment
0024	33DB	343	MOV CX,[BP],CNT ; BX = 0
0026	8B4E08	344	LES DI,[BP],PTR_DATA ; CX = Byte Count
0029	C47E04	345	ADD DX,[DI],PTR_DATA ; ES:DI = Address to store data at
002C	83C203	346	IN AL,DX ; DX = Data Port Address
002F	EC	347	STOSB ; Input Data Byte
0030	AA	348	INC RDI ; Read another sector
0031	43	349	LOOP RDI ;
0032	E2FB	350	MOV AX,BX ; AX = Actual read count
0034	8BC3	351	POP BP ; Discard the parameters
0036	5D	352	RET 10 ;
0037	C20A00	353	;;
		354	RDTRACKA ENDP

LOC	OBJ	LINE	SOURCE
003A	BR581B70	360	MDR - Wait for Drive Ready
003E	B9041E	361	MDR waits until the selected drive is ready by waiting
0041	E81600	362	for at least 7 index hole transitions.
0044	720D	363	Entry: NONE
0046	75F9	364	Exit: TIME_OUT = results of loop time-out.
0048	E80F00	365	Uses: NONE
004B	7206	366	
004D	74F9	367	
004F	FEC9	368	
0051	75EE	369	
0053	0ADD	370	
0055	891E0000	371	
0057	C3	372	
1B58		373	
005A		374	
005A	4B	375	
005B	7507	376	
005D	FEC0	377	
005F	7414	378	
0061	BR581B	379	
0064	53	380	
0065	51	381	
0066	E80000	382	
0067	59	383	
0069	59	384	
006A		385	
006B		386	
006C		387	
006D		388	
006E		389	
006F		390	
0070		391	
0071		392	
0072		393	
0073		394	
0074		395	
0075		396	
0076		397	
0077		398	
0078		399	
0079		400	
0080		401	
0081		402	
0082		403	
0083		404	
0084		405	
0085		406	
0086		407	
0087		408	
0088		409	
0089		410	
0090		411	
0091		412	
0092		413	
0093		414	

LOC	OBJ	LINE	SOURCE
		432	WNB ; Wait for NOT Busy
		433	;
		434	;
		435	WNB waits for the controller to deassert busy. This is
		436	necessary before any valid commands are sent. The only
		437	exception is the force interrupt command, which naturally
		438	is sent when the device is busy.
		439	;
		440	Entry: NONE
		441	;
		442	Exit: NONE
		443	;
		444	Uses: ???---(because CBA may use a11)
		445	;
0077		446	WNB PROC NEAR
		447	PUBLIC WNB
		448	;
0077	ESG8FF	449	CALL CSP
007A	A801	450	TEST AL, JNS, BSY
007C	7407	451	JZ WNB1 ; Busy is de-asserted
		452	;
007E	E80000	453	CALL CBA
0081	D0D8	454	ROR AL, 1
0083	73F2	455	WNB ; The user has not aborted yet
		456	;
0085	C3	457	WNB1: RET
		458	;
		459	WNB ENDP
		460	;
		461	;
		462	;
		463	;
		464	ASTLIB ENDS
		465	;
		466	END

NAME	TYPE	VALUE	ATTRIBUTES, XREFS
EXPAND.	V BYTE	0000H	S FIELD 80#
FD_CNND	NUMBER	0000H	225#
FD_DATA	NUMBER	0003H	228# 344
FD_SECT	NUMBER	0002H	227#
FD_STAT	NUMBER	0000H	224#
FD_TRACK	NUMBER	0001H	226#
FONT.	V DWORD	0000H	EXTRN 183#
FONTAR.	SEGMENT		SIZE=0000H BYTE PUBLIC 'DATA' 123# 125
FORE.	V BYTE	0000H	S FIELD 48#
FUNCTION.	V WORD	0001H	S FIELD 64#
GRAPHIC.	V BYTE	0009H	S FIELD 81#
H19_MODE.	V 18	0000H	EXTRN 177#
H19_MODE_STRUC.	STRUC		SIZE=0012H #FIELDS=17 71 89# 197
H19_PAR.	V	0000H	EXTRN 178#
H19_PAR_STRUC.	STRUC		SIZE=0009H #FIELDS=9 91 101# 193
HORZ_CHAR	V BYTE	0000H	EXTRN 173#
INDEX.	V BYTE	0000H	S FIELD 41#
INIT.	L NEAR	0000H	EXTRN 165#
INSERT.	V BYTE	000AH	S FIELD 82#
ITV_ORI	V DWORD	0000H	EXTRN 132#
ITV_SST	V DWORD	0000H	EXTRN 131#
KEY_EN.	V BYTE	000BH	S FIELD 83#
LPS.	V BYTE	0002H	S FIELD 94#
MUC.	V DWORD	0000H	EXTRN 184#
MDL.	V DWORD	0000H	EXTRN 185#
MODE.	V BYTE	0003H	S FIELD 65#
MONENT.	SEGMENT		SIZE=0000H PARA PUBLIC 136# 144
MSK.	V BYTE	0002H	S FIELD 50#
MTR_DGRT.	L FAR	0000H	EXTRN 140#
MTR_DKBD.	L FAR	0000H	EXTRN 142#
MTR_FONT.	V BYTE	0000H	EXTRN 124#
MTR_MON.	L FAR	0000H	EXTRN 138#
MTR_RES.	L FAR	0000H	EXTRN 137#
MTR_SCR.	L FAR	0000H	EXTRN 141#
MTR_SKBD.	L FAR	0000H	EXTRN 143#
MTR_SWIM.	L FAR	0000H	EXTRN 139#
MTR100.	SEGMENT		SIZE=0000H PARA PUBLIC 'CODE' 145# 143 210
MTR101.	L NEAR	0000H	EXTRN 154#
OPER_COUNT.	V BYTE	0004H	S FIELD 66#
OPER_INDEX.	V BYTE	0005H	S FIELD 67#
OPERAND	V BYTE	0006H	S FIELD 68#
PAINTED	V BYTE	0004H	S FIELD 52#
PRINT.	V BYTE	0005H	S FIELD 53#
PLM_THUE.	NUMBER	00FH	29#
PORT.	V BYTE	0001H	S FIELD 42# 256
POVRAM.	V BYTE	0003H	S FIELD 95#
PROMPT.	V DWORD	0000H	EXTRN 186#
PTR_DATA.	V DWORD	0004H	S FIELD 323# 343
RDC.	V DWORD	0000H	EXTRN 187#
RDT1.	L NEAR	002FH	ASTLIB 345# 348
RDTA.	STRUC		SIZE=000EH #FIELDS=6 320 327#
RDTTRACKA.	L NEAR	0019H	ASTLIB PUBLIC 330# 331 334
RECP.	V DWORD	0000H	EXTRN 175#
RESETF.	V BYTE	0000H	EXTRN 176#
REVERSE	V WORD	000CH	S FIELD 84#

SERIES-III 8086/3087/3088 MACRO ASSEMBLER V1.0 ASSEMBLY OF MODULE FONT
OBJECT MODULE PLACED IN : F2:FONT2.OBJ
INVOCATION LINE CONTROLS: PRINT(:TO:) XREF ERRORPRINT(:TO:)

LOC OBJ LINE SOURCE

LOC OBJ LINE SOURCE

```

51 ; *****
52 ; *****
53 ; *****
54 ; *****
55 ; *****
56 ; *****
57 ; *****
58 ; *****
59 ; *****
60 ; *****
61 ; *****
62 ; *****
63 ; *****
64 ; *****
65 ; *****
66 ; *****
67 ; *****
68 ; *****
69 ; *****
70 ; *****
71 ; *****
72 ; *****
73 ; *****
74 ; *****
75 ; *****
76 ; *****
77 ; *****
78 ; *****
79 ; *****
80 ; *****
81 ; *****
82 ; *****
83 ; *****
84 ; *****
85 ; *****
86 +1 $EJECT

```

Basically, each of the characters consists of a ten element array which is to be displayed on the screen. Most of the work here was done by Steve Parker for the CP/M 8086 assembler. Some of the descenders have been modified ('p', 'q', and 'g'). The format has been modified for Intel Assembler compatibility.

G. Chandler

```

%*DEFINE(GRAPHIC)(0) %' No Graphic Characters
%*DEFINE(LOWER)(1) %' Lower Case

```

FONTAB SEGMENT BYTE PUBLIC 'DATA'

NAME FONT

```

MTR_FONT LABEL BYTE ; Base Address of Font ROM
PUBLIC MTR_FONT ; Font ROM is a global

```

```

00000
86 +1 $EJECT

```

LOC	OBJ	LINE	SOURCE
0030	04	142	DB 00000100B
0031	08	143	DB 00001000B
0032	10	144	DB 00010000B
0033	26	145	DB 00100100B
0034	06	146	DB 00000110B
0035	00	147	DB 00000000B
		148	;"
0036	00	149	DB 00000000B
0037	08	150	DB 00001000B
0038	14	151	DB 00010100B
0039	14	152	DB 00010100B
003A	18	153	DB 00011000B
003B	2A	154	DB 00101010B
003C	24	155	DB 00100100B
003D	1A	156	DB 00011010B
003E	00	157	DB 00000000B
		158	;"
003F	00	159	DB 00000000B
0040	0C	160	DB 00001100B
0041	03	161	DB 00001000B
0042	10	162	DB 00010000B
0043	00	163	DB 00000000B
0044	00	164	DB 00000000B
0045	00	165	DB 00000000B
0046	00	166	DB 00000000B
0047	00	167	DB 00000000B
		168	;"
0048	00	169	DB 00000000B
0049	04	170	DB 00001000B
004A	08	171	DB 00001000B
004B	10	172	DB 00010000B
004C	10	173	DB 00010000B
004D	10	174	DB 00010000B
004E	03	175	DB 00001000B
004F	04	176	DB 00001000B
0050	00	177	DB 00000000B
		178	;"
0051	00	179	DB 00000000B
0052	10	180	DB 00010000B
0053	08	181	DB 00001000B
0054	04	182	DB 00000100B
0055	04	183	DB 00000100B
0056	04	184	DB 00000100B
0057	03	185	DB 00001000B
0058	10	186	DB 00010000B
0059	00	187	DB 00000000B
		188	;"
005A	00	189	DB 00000000B
005B	00	190	DB 00000000B
005C	08	191	DB 00001000B
005D	2A	192	DB 00101010B
005E	1C	193	DB 00011100B
005F	2A	194	DB 00101010B
0060	08	195	DB 00001000B
0061	00	196	DB 00000000B

LOC	OBJ	LINE	SOURCE
0093	26	252	DB 00100110B
0094	2A	253	DB 00101010B
0095	32	254	DB 00110010B
0096	22	255	DB 00100010B
0097	1C	256	DB 00011100B
0098	00	257	DB 00000000B
0099	00	258	DB "1"
009A	08	259	DB 00000000B
009B	18	260	DB 00001000B
009C	08	261	DB 00011000B
009D	08	262	DB 00001000B
009E	08	263	DB 00001000B
009F	08	264	DB 00001000B
00A0	1C	265	DB 00001000B
00A1	00	266	DB 00011100B
00A2	00	267	DB 00000000B
00A3	1C	268	DB "2"
00A4	22	269	DB 00000000B
00A5	02	270	DB 00011100B
00A6	04	271	DB 00100010B
00A7	08	272	DB 00000010B
00A8	10	273	DB 00000100B
00A9	3E	274	DB 00001000B
00AA	00	275	DB 00010000B
00AB	00	276	DB 00111110B
00AC	3E	277	DB 00000000B
00AD	04	278	DB "3"
00AE	08	279	DB 00000000B
00AF	04	280	DB 00111110B
00B0	02	281	DB 00000100B
00B1	22	282	DB 00001000B
00B2	1C	283	DB 00000100B
00B3	00	284	DB 00000010B
00B4	00	285	DB 00100010B
00B5	04	286	DB 00011100B
00B6	0C	287	DB 00000000B
00B7	14	288	DB "4"
00B8	24	289	DB 00000000B
00B9	3E	290	DB 00000100B
00BA	04	291	DB 00001100B
00BB	04	292	DB 00010100B
00BC	00	293	DB 00100100B
00BD	00	294	DB 00111110B
00BE	3E	295	DB 00000100B
00BF	20	296	DB 00000100B
00C0	3C	297	DB 00000000B
00C1	02	298	DB "5"
00C2	02	299	DB 00000000B
00C3	22	300	DB 00111110B
00C4	1C	301	DB 00100000B
		302	DB 00100000B
		303	DB 00111100B
		304	DB 00000010B
		305	DB 00000010B
		306	DB 00100010B
			DB 00011100B

LOC	OBJ	LINE	SOURCE
00F6	18	362	DB 00011000B
00F7	00	363	DB 00000000B
00F8	18	364	DB 00011000B
00F9	18	365	DB 00011000B
00FA	08	366	DB 00001000B
00FB	10	367	DB 00010000B
00FC	00	368	DB "<"
00FD	02	369	DB 00000000B
00FE	04	370	DB 00000010B
00FF	08	371	DB 00000100B
0100	10	372	DB 00001000B
0101	08	373	DB 00010000B
0102	04	374	DB 00001000B
0103	02	375	DB 00000100B
0104	00	376	DB 00000010B
0105	00	377	DB 00000000B
0106	00	378	DB "="
0107	00	379	DB 00000000B
0108	00	380	DB 00000000B
0109	00	381	DB 00000000B
010A	00	382	DB 00000000B
010B	00	383	DB 00111110B
010C	00	384	DB 00000000B
010D	00	385	DB 00111110B
010E	00	386	DB 00000000B
010F	20	387	DB 00000000B
0110	10	388	DB ">"
0111	08	389	DB 00000000B
0112	04	390	DB 00100000B
0113	08	391	DB 00010000B
0114	10	392	DB 00001000B
0115	20	393	DB 00000100B
0116	00	394	DB 00001000B
0117	00	395	DB 00010000B
0118	1C	396	DB 00100000B
0119	22	397	DB 00000000B
011A	02	398	DB "?"
011B	04	399	DB 00000000B
011C	08	400	DB 00011100B
011D	00	401	DB 00100010B
011E	08	402	DB 00000010B
011F	00	403	DB 00000100B
0120	00	404	DB 00001000B
0121	0C	405	DB 00000000B
0122	12	406	DB 00001000B
0123	26	407	DB 00000000B
0124	2A	408	DB "e"
0125	2E	409	DB 00000000B
0126	20	410	DB 00001100B
0127	1E	411	DB 00010010B
		412	DB 00100110B
		413	DB 00401010B
		414	DB 00101110B
		415	DB 00100000B
		416	DB 00011110B

LOC	OBJ	LINE	SOURCE
0159	20	472	DB 00100000B
015A	3C	473	DB 00111100B
015B	20	474	DB 00100000B
015C	20	475	DB 00100000B
015D	20	476	DB 00100000B
015E	00	477	DB 00000000B
		478	DB "G"
015F	00	479	DB 00000000B
0160	1C	480	DB 00011100B
0161	22	481	DB 00100010B
0162	20	482	DB 00100000B
0163	26	483	DB 00100110B
0164	22	484	DB 00100010B
0165	22	485	DB 00100010B
0166	1E	486	DB 00011110B
0167	00	487	DB 00000000B
		488	DB "H"
0168	00	489	DB 00000000B
0169	22	490	DB 00100010B
016A	22	491	DB 00100010B
016B	22	492	DB 00100010B
016C	3E	493	DB 00111110B
016D	22	494	DB 00100010B
016E	22	495	DB 00100010B
016F	22	496	DB 00100010B
0170	00	497	DB 00000000B
		498	DB "I"
		499	DB 00000000B
0171	00	500	DB 00011100B
0172	1C	501	DB 00001000B
0173	08	502	DB 00001000B
0174	08	503	DB 00001000B
0175	08	504	DB 00001000B
0176	08	505	DB 00001000B
0177	08	506	DB 00011100B
0178	1C	507	DB 00000000B
0179	00	508	DB "J"
		509	DB 00000000B
017A	00	510	DB 00001100B
017B	0E	511	DB 00000100B
017C	04	512	DB 00000100B
017D	04	513	DB 00000100B
017E	04	514	DB 00000100B
017F	04	515	DB 00000100B
0180	24	516	DB 00011000B
0181	18	517	DB 00000000B
0182	00	518	DB "K"
		519	DB 00000000B
0183	00	520	DB 00100010B
0184	22	521	DB 00100100B
0185	24	522	DB 00101000B
0186	28	523	DB 00110000B
0187	30	524	DB 00101000B
0188	28	525	DB 00100100B
0189	24	526	DB 00100010B
018A	22		

LDC OBJ	LINE	SOURCE
01BC 22	582	DB 00100010B
01BD 22	583	DB 00100010B
01BE 2A	584	DB 00101010B
01BF 24	585	DB 00100100B
01C0 1A	586	DB 00011010B
01C1 00	587	DB 00000000B
	588	DB "R"
01C2 00	589	DB 00000000B
01C3 3C	590	DB 00111100B
01C4 22	591	DB 00100010B
01C5 22	592	DB 00100010B
01C6 3C	593	DB 00111100B
01C7 28	594	DB 00101000B
01C8 24	595	DB 00100100B
01C9 22	596	DB 00100010B
01CA 00	597	DB 00000000B
	598	DB "S"
01CB 00	599	DB 00000000B
01CC 1C	600	DB 00011100B
01CD 22	601	DB 00100010B
01CE 20	602	DB 00100000B
01CF 1C	603	DB 00011100B
01D0 02	604	DB 00000010B
01D1 22	605	DB 00100010B
01D2 1C	606	DB 00011100B
01D3 00	607	DB 00000000B
	608	DB "T"
01D4 00	609	DB 00000000B
01D5 3E	610	DB 00111110B
01D6 08	611	DB 00001000B
01D7 08	612	DB 00001000B
01D8 08	613	DB 00001000B
01D9 08	614	DB 00001000B
01DA 08	615	DB 00001000B
01DB 08	616	DB 00001000B
01DC 00	617	DB 00000000B
	618	DB "U"
01DD 00	619	DB 00000000B
01DE 22	620	DB 00100010B
01DF 22	621	DB 00100010B
01E0 22	622	DB 00100010B
01E1 22	623	DB 00100010B
01E2 22	624	DB 00100010B
01E3 22	625	DB 00100010B
01E4 1C	626	DB 00011100B
01E5 00	627	DB 00000000B
	628	DB "V"
01E6 00	629	DB 00000000B
01E7 22	630	DB 00100010B
01E8 22	631	DB 00100010B
01E9 22	632	DB 00100010B
01EA 14	633	DB 00010100B
01EB 14	634	DB 00010100B
01EC 08	635	DB 00001000B
01ED 08	636	DB 00001000B

LOC	OBJ	LINE	SOURCE
021F	10	692	DB 00010000B
0220	08	693	DB 00001000B
0221	04	694	DB 00000100B
0222	02	695	DB 00000010B
0223	01	696	DB 00000001B
0224	00	697	DB 00000000B
0225	00	698	DB "J"
0226	38	699	DB 00000000B
0227	08	700	DB 00111000B
0228	08	701	DB 00001000B
0229	08	702	DB 00001000B
022A	08	703	DB 00001000B
022B	08	704	DB 00001000B
022C	38	705	DB 00001000B
022D	00	706	DB 00111000B
022E	00	707	DB 00000000B
022F	08	708	DB "A"
0230	14	709	DB 00000000B
0231	22	710	DB 00001000B
0232	00	711	DB 00010100B
0233	00	712	DB 00100010B
0234	00	713	DB 00000000B
0235	00	714	DB 00000000B
0236	00	715	DB 00000000B
0237	00	716	DB 00000000B
0238	00	717	DB " "
0239	00	718	DB " "
023A	00	719	DB 00000000B
023B	00	720	DB 00000000B
023C	00	721	DB 00000000B
023D	00	722	DB 00000000B
023E	00	723	DB 00000000B
023F	00	724	DB 00000000B
0240	00	725	DB 00000000B
0241	18	726	DB 01111111B
0242	08	727	DB 00000000B
0243	04	728	DB " "
0244	00	729	DB 00000000B
0245	00	730	DB 00011000B
0246	00	731	DB 00001000B
0247	00	732	DB 00000100B
0248	00	733	DB 00000000B
0249	00	734	DB 00000000B
024A	00	735	DB 00000000B
024B	00	736	DB 00000000B
024C	00	737	DB 00000000B
024D	00	738	DB 00000000B
024E	00	739	DB 00011000B
024F	00	740	DB 00001000B
0250	00	741	DB 00000100B
0251	00	742	DB 00000000B
0252	00	743	DB 00000000B
0253	00	744	DB 00000000B
0254	00	745	DB 00011100B
0255	00	746	DB 00000010B

```

%IF (XLOWER
  740 +1
  741 "a"
  742 DB 00000000B
  743 DB 00000000B
  744 DB 00000000B
  745 DB 00011100B
  746 DB 00000010B

```

LOC	OBJ	LINE	SOURCE
		802	DB 00000000B
		803	DB 00000000B
		804	DB 00000000B
		805	DB 00011110B
		806	DB 00100100B
		807	DB 00111000B
		808	DB 00011100B
		809	DB 00100010B
		810	DB 00011100B
		811	; "h"
		812	DB 00000000B
		813	DB 00100000B
		814	DB 00100000B
		815	DB 00111100B
		816	DB 00100010B
		817	DB 00100010B
		818	DB 00100010B
		819	DB 00100010B
		820	DB 00000000B
		821	; "i"
		822	DB 00000000B
		823	DB 00001000B
		824	DB 00000000B
		825	DB 00011000B
		826	DB 00001000B
		827	DB 00001000B
		828	DB 00001000B
		829	DB 00011100B
		830	DB 00000000B
		831	; "j"
		832	DB 00000000B
		833	DB 00000010B
		834	DB 00000000B
		835	DB 00000010B
		836	DB 00000010B
		837	DB 00000010B
		838	DB 00000010B
		839	DB 00100010B
		840	DB 00011100B
		841	; "k"
		842	DB 00000000B
		843	DB 00100000B
		844	DB 00100000B
		845	DB 00100100B
		846	DB 00101000B
		847	DB 00110100B
		848	DB 00100010B
		849	DB 00100010B
		850	DB 00000000B
		851	; "l"
		852	DB 00000000B
		853	DB 00011000B
		854	DB 00001000B
		855	DB 00001000B
		856	DB 00001000B

LOC	OBJ	LINE	SOURCE
		912	DB 00000000B
		913	DB 00000000B
		914	DB 00000000B
		915	DB 00101100B
		916	DB 00110010B
		917	DB 00100000B
		918	DB 00100000B
		919	DB 00100000B
		920	DB 00000000B
		921	; "s"
		922	DB 00000000B
		923	DB 00000000B
		924	DB 00000000B
		925	DB 00011100B
		926	DB 00100000B
		927	DB 00011100B
		928	DB 00000010B
		929	DB 00011100B
		930	DB 00000000B
		931	; "t"
		932	DB 00000000B
		933	DB 00010000B
		934	DB 00010000B
		935	DB 00111000B
		936	DB 00010000B
		937	DB 00010000B
		938	DB 00010010B
		939	DB 00001100B
		940	DB 00000000B
		941	; "u"
		942	DB 00000000B
		943	DB 00000000B
		944	DB 00000000B
		945	DB 00100010B
		946	DB 00100010B
		947	DB 00100010B
		948	DB 00100110B
		949	DB 00011010B
		950	DB 00000000B
		951	; "v"
		952	DB 00000000B
		953	DB 00000000B
		954	DB 00000000B
		955	DB 00100010B
		956	DB 00100010B
		957	DB 00100010B
		958	DB 00010100B
		959	DB 00001000B
		960	DB 00000000B
		961	; "w"
		962	DB 00000000B
		963	DB 00000000B
		964	DB 00000000B
		965	DB 00100010B
		966	DB 00100010B

LOC	OBJ	LINE	SOURCE
0249	00	1022	DB 00000000B
024A	00	1023	DB 00011000B
024B	00	1024	DB 000000100B
024C	1C	1025	DB 00000100B
024D	02	1026	DB 000000010B
024E	1E	1027	DB 00000100B
024F	22	1028	DB 000000100B
0250	1E	1029	DB 00011000B
0251	00	1030	DB 00000000B
		1031	; "v"
		1032	DB 00000000B
		1033	DB 00110000B
		1034	DB 01001001B
		1035	DB 00000110B
		1036	DB 00000000B
		1037	DB 00000000B
		1038	DB 00000000B
		1039	DB 00000000B
		1040	DB 00000000B
		1041	DB 00000000B
		1042	; "a"
		1043	DB 00000000B
		1044	DB 00000000B
		1045	DB 00000000B
		1046	DB 00000000B
		1047	DB 00011100B
		1048	DB 00000010B
		1049	DB 00011110B
		1050	DB 00100010B
		1051	DB 00011110B
		1052	DB 00000000B
		1053	; "b"
		1054	DB 00000000B
		1055	DB 00100000B
		1056	DB 00100000B
		1057	DB 00111100B
		1058	DB 00100010B
		1059	DB 00100010B
		1060	DB 00100010B
		1061	DB 00111100B
		1062	DB 00000000B
		1063	; "c"
		1064	DB 00000000B
		1065	DB 00000000B
		1066	DB 00000000B
		1067	DB 00011100B
		1068	DB 00100010B
		1069	DB 00100000B
		1070	DB 00100000B
		1071	DB 00011100B
		1072	DB 00000000B
		1073	; "d"
		1074	DB 00000000B
		1075	DB 00000010B
		1076	DB 00000010B

LDC	OBJ	LINE	SOURCE
0297	00	1132 +1	DB 00000000B
029A	00	1133 +1	; "j"
029B	02	1134 +1	DB 00000000B
029C	00	1135 +1	DB 00000010B
029D	02	1136 +1	DB 00000000B
029E	02	1137 +1	DB 00000010B
029F	02	1138 +1	DB 00000010B
02A0	02	1139 +1	DB 00000010B
02A1	22	1140 +1	DB 00000010B
02A2	1C	1141 +1	DB 00100010B
		1142 +1	DB 00011100B
		1143 +1	; "k"
02A3	00	1144 +1	DB 00000000B
02A4	20	1145 +1	DB 00100000B
02A5	20	1146 +1	DB 00100000B
02A6	24	1147 +1	DB 00100100B
02A7	28	1148 +1	DB 00101000B
02A8	34	1149 +1	DB 00110100B
02A9	22	1150 +1	DB 00100010B
02AA	22	1151 +1	DB 00100010B
02AB	00	1152 +1	DB 00000000B
		1153 +1	; "l"
02AC	00	1154 +1	DB 00000000B
02AD	18	1155 +1	DB 00011000B
02AE	08	1156 +1	DB 00001000B
02AF	08	1157 +1	DB 00001000B
02B0	08	1158 +1	DB 00001000B
02B1	08	1159 +1	DB 00001000B
02B2	08	1160 +1	DB 00001000B
02B3	1C	1161 +1	DB 00011100B
02B4	00	1162 +1	DB 00000000B
		1163 +1	; "m"
02B5	00	1164 +1	DB 00000000B
02B6	00	1165 +1	DB 00000000B
02B7	00	1166 +1	DB 00000000B
02B8	34	1167 +1	DB 00110100B
02B9	2A	1168 +1	DB 00101010B
02BA	2A	1169 +1	DB 00101010B
02BB	2A	1170 +1	DB 00101010B
02BC	2A	1171 +1	DB 00101010B
02BD	00	1172 +1	DB 00000000B
		1173 +1	; "n"
02BE	00	1174 +1	DB 00000000B
02BF	00	1175 +1	DB 00000000B
02C0	00	1176 +1	DB 00000000B
02C1	3C	1177 +1	DB 00111100B
02C2	22	1178 +1	DB 00100010B
02C3	22	1179 +1	DB 00100010B
02C4	22	1180 +1	DB 00100010B
02C5	22	1181 +1	DB 00100010B
02C6	00	1182 +1	DB 00000000B
		1183 +1	; "o"
02C7	00	1184 +1	DB 00000000B
02C8	00	1185 +1	DB 00000000B
02C9	00	1186 +1	DB 00000000B

LOC	OBJ	LINE	SOURCE
02FC	00	1242 +1	DB 00000000B
02FD	00	1243 +1	; "u"
02FE	00	1244 +1	DB 00000000B
02FF	00	1245 +1	DB 00000000B
0300	22	1246 +1	DB 00000000B
0301	22	1247 +1	DB 00100010B
0302	22	1248 +1	DB 00100010B
0303	26	1249 +1	DB 00100010B
0304	1A	1250 +1	DB 00100110B
0305	00	1251 +1	DB 00011010B
		1252 +1	DB 00000000B
		1253 +1	; "v"
0306	00	1254 +1	DB 00000000B
0307	00	1255 +1	DB 00000000B
0308	00	1256 +1	DB 00000000B
0309	22	1257 +1	DB 00100010B
030A	22	1258 +1	DB 00100010B
030B	22	1259 +1	DB 00100010B
030C	14	1260 +1	DB 00010100B
030D	08	1261 +1	DB 00001000B
030E	00	1262 +1	DB 00000000B
		1263 +1	; "w"
030F	00	1264 +1	DB 00000000B
0310	00	1265 +1	DB 00000000B
0311	00	1266 +1	DB 00000000B
0312	22	1267 +1	DB 00100010B
0313	22	1268 +1	DB 00100010B
0314	2A	1269 +1	DB 00101010B
0315	2A	1270 +1	DB 00101010B
0316	14	1271 +1	DB 00010100B
0317	00	1272 +1	DB 00000000B
		1273 +1	; "x"
0318	00	1274 +1	DB 00000000B
0319	00	1275 +1	DB 00000000B
031A	00	1276 +1	DB 00000000B
031B	22	1277 +1	DB 00100010B
031C	14	1278 +1	DB 00010100B
031D	08	1279 +1	DB 00001000B
031E	14	1280 +1	DB 00010100B
031F	22	1281 +1	DB 00100010B
0320	00	1282 +1	DB 00000000B
		1283 +1	; "y"
0321	00	1284 +1	DB 00000000B
0322	00	1285 +1	DB 00000000B
0323	00	1286 +1	DB 00000000B
0324	22	1287 +1	DB 00100010B
0325	22	1288 +1	DB 00100010B
0326	22	1289 +1	DB 00100010B
0327	1E	1290 +1	DB 00011110B
0328	02	1291 +1	DB 00000010B
0329	1C	1292 +1	DB 00011100B
		1293 +1	; "z"
032A	00	1294 +1	DB 00000000B
032B	00	1295 +1	DB 00000000B
032C	00	1296 +1	DB 00000000B

LOC	OBJ	LINE	SOURCE
		1352	DB 00111110B
		1353	DB 00111110B
		1354	DB 00011100B
		1355	DB 00000000B
		1356	DB 00000000B
		1357	; graphic " "
		1358	DB 11111111B
		1359	DB 01111111B
		1360	DB 00111111B
		1361	DB 00011111B
		1362	DB 00001111B
		1363	DB 00000111B
		1364	DB 00000011B
		1365	DB 00000001B
		1366	DB 00000000B
		1367	; graphic " . "
		1368	DB 00011000B
		1369	DB 00011000B
		1370	DB 00011000B
		1371	DB 00011000B
		1372	DB 00011000B
		1373	DB 00011000B
		1374	DB 00011000B
		1375	DB 00011000B
		1376	DB 00011000B
		1377	; graphic " a "
		1378	DB 00000000B
		1379	DB 00000000B
		1380	DB 00000000B
		1381	DB 00000000B
		1382	DB 11111111B
		1383	DB 00000000B
		1384	DB 00000000B
		1385	DB 00000000B
		1386	DB 00000000B
		1387	; graphic " b "
		1388	DB 00011000B
		1389	DB 00011000B
		1390	DB 00011000B
		1391	DB 00011000B
		1392	DB 11111111B
		1393	DB 00011000B
		1394	DB 00011000B
		1395	DB 00011000B
		1396	DB 00011000B
		1397	; graphic " c "
		1398	DB 00000000B
		1399	DB 00000000B
		1400	DB 00000000B
		1401	DB 00000000B
		1402	DB 11111000B
		1403	DB 00011000B
		1404	DB 00011000B
		1405	DB 00011000B
		1406	DB 00011000B


```

LOC OBJ          LINE          SOURCE
1462             DB 10101010B
1463             DB 01010101B
1464             DB 10101010B
1465             DB 01010101B
1466             DB 10101010B
1467             ; graphic "j"
1468             %IF(ZNES(0,1))
1469             THEN (
1470             DB 11110000B
1471             DB 11110000B
1472             DB 11110000B
1473             DB 11110000B
1474             DB 11111111B
1475             DB 00001111B
1476             DB 00001111B
1477             DB 00001111B
1478             DB 00001111B )
1479             ELSE (
1480             DB 00000000B
1481             DB 00000000B
1482             DB 00001000B
1483             DB 00000000B
1484             DB 00111110B
1485             DB 00000000B
1486             DB 00001000B
1487             DB 00000000B
1488             DB 00000000B )FI
1489             ; graphic "k"
1490             DB 00000000B
1491             DB 00000000B
1492             DB 00001000B
1493             DB 00001000B
1494             DB 00101010B
1495             DB 00011100B
1496             DB 00001000B
1497             DB 00000000B
1498             DB 00000000B
1499             ; graphic "l"
1500             DB 00000000B
1501             DB 00000000B
1502             DB 00000000B
1503             DB 00000000B
1504             DB 00001111B
1505             DB 00001111B
1506             DB 00001111B
1507             DB 00001111B
1508             DB 00001111B
1509             ; graphic "m"
1510             DB 00000000B
1511             DB 00000000B
1512             DB 00000000B
1513             DB 00000000B
1514             DB 11110000B
1515             DB 11110000B
1516             DB 11110000B

```


LOC	OBJ	LINE	SOURCE
		1572	DB 00000000B
		1573	DB 00000000B
		1574	DB 11111111B
		1575	DB 00011000B
		1576	DB 00011000B
		1577	DB 00011000B
		1578	DB 00011000B
		1579	; graphic "t"
		1580	DB 00011000B
		1581	DB 00011000B
		1582	DB 00011000B
		1583	DB 00011000B
		1584	DB 11111000B
		1585	DB 00011000B
		1586	DB 00011000B
		1587	DB 00011000B
		1588	DB 00011000B
		1589	; graphic "u"
		1590	DB 00011000B
		1591	DB 00011000B
		1592	DB 00011000B
		1593	DB 00011000B
		1594	DB 11111111B
		1595	DB 00000000B
		1596	DB 00000000B
		1597	DB 00000000B
		1598	DB 00000000B
		1599	; graphic "v"
		1600	DB 00011000B
		1601	DB 00011000B
		1602	DB 00011000B
		1603	DB 00011000B
		1604	DB 00011111B
		1605	DB 00011000B
		1606	DB 00011000B
		1607	DB 00011000B
		1608	DB 00011000B
		1609	; graphic "w"
		1610	DB 10000001B
		1611	DB 11000011B
		1612	DB 01100110B
		1613	DB 00111100B
		1614	DB 00011000B
		1615	DB 00111100B
		1616	DB 01100110B
		1617	DB 11000011B
		1618	DB 10000001B
		1619	; graphic "x"
		1620	DB 00000001B
		1621	DB 00000011B
		1622	DB 000000110B
		1623	DB 00001100B
		1624	DB 00011000B
		1625	DB 00110000B
		1626	DB 01100000B

LOC	OBJ	LINE	SOURCE
		1682	DB 00111100B
		1683	DB 00111100B
		1684	DB 00011100B
		1685	DB 00001100B
		1686	DB 00001100B
		1687	DB 00000000B
		1688	DB 00000000B
		1689)FI
		1690	+1
		1691	
		1692	FONTAB ENDS
		1693	
		1694	END



```
= $SAVE  
= $NOLIST  
INCLUDE (':F2:GLOBAL.H')  
= $SAVE  
= $NOLIST  
INCLUDE (':F2:ISSDEF.H')  
= $SAVE  
= $NOLIST  
INCLUDE (':F2:INIT.H')  
= $SAVE  
= $NOLIST  
INCLUDE (':F2:IODDEF.H')  
= $SAVE  
= $NOLIST  
INCLUDE (':F2:ITCDEF.H')  
= $SAVE  
= $NOLIST  
INCLUDE (':F2:KEYDEF.H')  
= $SAVE  
= $NOLIST  
INCLUDE (':F2:KEYLIB.H')  
= $SAVE  
= $NOLIST  
INCLUDE (':F2:MISC.H')  
= $SAVE  
= $NOLIST  
INCLUDE (':F2:MTR100.H')  
= $SAVE  
= $NOLIST  
INCLUDE (':F2:P6821.H')  
= $SAVE  
= $NOLIST  
INCLUDE (':F2:REGDEF.H')  
= $SAVE  
= $NOLIST  
INCLUDE (':F2:VIDEO.H')  
= $SAVE  
= $NOLIST  
$EJECT
```

```
306 1  COMMAND:      PROCEDURE      EXTERNAL;  
307 2  END;  
308 1  C_BOOT:      PROCEDURE      EXTERNAL;  
309 2  END;  
310 1  INIT:        PROCEDURE      EXTERNAL;  
311 2  END;  
      $ IF EXTENDED_MONITOR  
      $STEP:        PROCEDURE      EXTERNAL;  
      $ END;  
      $ ENDIF  
312 1  DECLARE     STEP_COUNT      WORD EXTERNAL;  
      $SUBTITLE('MTR-101 - Monitor Loop')
```

```

323 1 VIDEO_INTR: PROCEDURE PUBLIC;
324 2 DECLARE TEMP BYTE;
325 2 DO;
326 3 CALL SDS; /* Set the Data Segment */

/*
/* Vertical Retrace Interrupt
*/
327 3 IF ( INPUT(GEN_CNT) AND P6821_IRQ2 ) <> 0 THEN
328 3 DO;
329 4 TEMP=INPUT(GEN_DAT); /* Clear Interrupt */
330 4 OUTPUT(GEN_DAT)=(INPUT(GEN_DAT) AND (NOT 0010$0000B));
331 4 TEMP=INPUT(IO_DIP); /* Dummy I/O for 6821 */
332 4 OUTPUT(GEN_DAT)=(INPUT(GEN_DAT) OR 0010$0000B);
333 4 CALL MTR_TTY_INTR; /* Vertical Retrace */
334 4 END;

/*
/* Key-Board Interrupt
*/
335 3 IF ( INPUT(KEY_STAT) AND KS_CXRDY ) <> 0 THEN
336 3 DO;
337 4 KEY_CHAR=INPUT(KEY_DATA);
338 4 KEY_AVAIL=TRUE;
339 4 END;
340 3 END;
341 2 END;

```

*EJECT

```

; STATEMENT # 6
; STATEMENT # 20
; STATEMENT # 39
; STATEMENT # 53
; STATEMENT # 67
; STATEMENT # 108
; STATEMENT # 109
; STATEMENT # 111
; STATEMENT # 138
; STATEMENT # 193
; STATEMENT # 229
; STATEMENT # 237
; STATEMENT # 243
; STATEMENT # 255
; STATEMENT # 265
; STATEMENT # 275
; STATEMENT # 304
; STATEMENT # 314

MTR101 PROC NEAR
0024 55          PUSH BP
0025 8BEC      MOV BP, SP
; STATEMENT # 315

0027 B007      MOV AL, 7H
0029 50        PUSH AX
002A E80000    CALL WRITEC
; STATEMENT # 316

002D A00000    MOV AL, RESETF
0030 D0D8      RCR AL, 1
0032 7309     JNB @1
0034 E4FF     IN @FFH
0036 A808     TEST AL, 8H
0038 7403     JZ @1
; STATEMENT # 317

003A E30000    CALL C_BOOT
; STATEMENT # 318

003D C6060000 @1:
@2: MOV RESETF, 0H
; STATEMENT # 320

0042 E80000    CALL COMMAND
; STATEMENT # 321

0045 EBFB      JMP @2
; STATEMENT # 322

MTR101 ENDP
; STATEMENT # 323

VIDEO_INTR PROC NEAR
0047 55          PUSH BP
0048 8BEC      MOV BP, SP
; STATEMENT # 326

004A E80000    CALL SDS
; STATEMENT # 327

004D E4E1      IN @E1H
004F A840      TEST AL, 40H
0051 741B     JZ @4
; STATEMENT # 329

0053 E4E0      IN @E0H

```

DEFN	ADDR	SIZE	NAME, ATTRIBUTES, AND REFERENCES
291	0000H	1	BACK
7	0000H	1	BEL.
94	0000H	1	BILL
4	0000H	4	BOOL
74	0000H	83	BOOT_PAR
	0000H	1	INDEX
	0001H	1	PORT
	0002H	80	STRING
	0052H	1	UNIT
8	0000H	1	BS
95	0000H	1	BSIL
27	0000H	4	BYTEPTR.
30	0000H	1	C.
22	0000H	1	C.
9	0000H	1	CAN.
279	0000H	1	CHAR
58	0000H	1	CHAR
63	0000H	1	CHAR
236	0000H	1	CMND
68	0000H	1	CODE_SEG
303	0000H	1	COL.
102	0000H	7	COLOR.
	0000H	1	FORE
	0001H	1	BACK
	0002H	1	MASK
	0003H	1	CLEAR.
	0004H	1	PAINTED.
	0005H	1	FONT
	0006H	1	COMP_FONT
306	0000H	1	COMMAND.
313	0000H	35	COPYRIGHT.
303	0000H	2	COUNT.
273			CPU_AF
275			CPU_CF
268			CPU_DF
269			CPU_IF
267			CPU_OF
274			CPU_PF
271			CPU_SF
270			CPU_TF
272			CPU_ZF
10			CR
55	0000H		CRLF
103	0000H	3	CRTC_CURSOR.
	0000H	2	START.
	0002H	1	UPDATE.
104	0000H	3	CRTC_DISPLAY
	0000H	2	START.
	0002H	1	UPDATE
276	0000H	1	CURSOR
308	0000H	1	C_BOOT
			BYTE IN PROC (SCA) PARAMETER
			LITERALLY '007H' 315
			BYTE EXTERNAL(36)
			LITERALLY 'BYTE' 98 103 104 106 108 230 231 250
			285
			STRUCTURE EXTERNAL(16)
			BYTE
			BYTE
			BYTE ARRAY(80)
			BYTE
			LITERALLY '008H'
			BYTE EXTERNAL(37)
			POINTER IN PROC (INCB) PARAMETER
			BYTE IN PROC (SXMT) PARAMETER
			BYTE IN PROC (DXMTC) PARAMETER
			LITERALLY '018H'
			BYTE IN PROC (D CRT) PARAMETER
			BYTE IN PROC (MCU) PARAMETER
			BYTE IN PROC (WRITC) PARAMETER
			BYTE IN PROC (WRITK) PARAMETER
			LITERALLY '0FE05H'
			BYTE IN PROC (XMTSC) PARAMETER
			STRUCTURE EXTERNAL(41)
			BYTE
			BYTE
			BYTE
			BYTE
			BYTE
			BYTE
			PROCEDURE EXTERNAL(71) STACK=0000H
			BYTE ARRAY(35) DATA
			WORD IN PROC (XMTSC) PARAMETER
			LITERALLY '00000000\$00010000B' 303
			LITERALLY '00000000\$00000001B'
			LITERALLY '00000010\$00000000B'
			LITERALLY '00000010\$00000000B'
			LITERALLY '00000001\$00000000B'
			LITERALLY '00000000\$00000100B'
			LITERALLY '00000000\$10000000B'
			LITERALLY '00000001\$00000000B'
			LITERALLY '00000000\$01000000B'
			LITERALLY '00DH' 313
			PROCEDURE EXTERNAL(8) STACK=0000H
			STRUCTURE EXTERNAL(42)
			WORD
			BYTE
			STRUCTURE EXTERNAL(43)
			WORD
			STRUCTURE EXTERNAL(43)
			WORD
			PROCEDURE EXTERNAL(59) STACK=0000H
			PROCEDURE EXTERNAL(72) STACK=0000H
			317

15	00000H	FF	LITERALLY '00CH'		
24	00000H	FLAGS	PROCEDURE WORD EXTERNAL(1) STACK=0000H		
80	00000H	FONT	POINTER EXTERNAL(22)		
89	00000H	FONT SIZE	WORD EXTERNAL(31)		
291	00000H	1 FORE	BYTE IN PROC (SCA) PARAMETER	291	
241		GEN_CNT	LITERALLY '10_GENERAL+1'	327	
242		GEN_DIR	LITERALLY '10_GENERAL'	329	330 332
243		GEN_MODE	LITERALLY '10_GENERAL'		
106	00000H	18 H19_MODE	STRUCTURE EXTERNAL(45)		
	00000H	1 ALTERNATE	BYTE		
	00010H	1 ANSI	BYTE		
	00020H	1 AUTO_CR	BYTE		
	00030H	1 AUTO_LF	BYTE		
	00040H	1 AUTO_REPEAT	BYTE		
	00050H	1 BMD	BYTE		
	00060H	1 CURSOR	BYTE		
	00070H	1 CURSOR_ON	BYTE		
	00080H	1 EXPAND	BYTE		
	00090H	1 GRAPHIC	BYTE		
	000AH	1 INSERT	BYTE		
	000BH	1 KEY_EN	BYTE		
	000CH	1 REVERSE	WORD		
	000EH	1 SHIFTED	BYTE		
	000FH	1 STATUS	BYTE		
	0010H	1 UPDN	BYTE		
	0011H	1 WRAP	BYTE		
107	00000H	9 H19_PAR	STRUCTURE EXTERNAL(46)		
	00000H	1 CPL	BYTE		
	00010H	1 DSC	BYTE		
	00020H	1 LPS	BYTE		
	00030H	1 PVRAM	BYTE		
	00040H	1 SLI	BYTE		
	00050H	1 SPC	BYTE		
	00060H	1 SM401	BYTE		
	00070H	1 SM402	BYTE		
	00080H	1 VRAM_SIZE	BYTE		
54	00000H	1 HEX_DIGIT	BYTE ARRAY(0) EXTERNAL(7) DATA		
92	00000H	1 HORZ_CHAR	BYTE EXTERNAL(34)		
16		HT	LITERALLY '007H'		
109		I85_JMP	LITERALLY '03030'		
153		ICW1_A7A5	LITERALLY '1110*0000B'		
156		ICW1_AD14	LITERALLY '0000*0100B'		
158		ICW1_IC4	LITERALLY '0000*0001B'		
154		ICW1_ICM1	LITERALLY '0001*0000B'		
155		ICW1_L1TM	LITERALLY '0000*1000B'		
157		ICW1_SML	LITERALLY '0000*0010B'		
159		ICW2_A15A8	LITERALLY '1111*1111B'		
167		ICW3_S0	LITERALLY '0000*0001B'		
166		ICW3_S1	LITERALLY '0000*0010B'		
165		ICW3_S2	LITERALLY '0000*0100B'		
164		ICW3_S3	LITERALLY '0000*1000B'		
163		ICW3_S4	LITERALLY '0001*0000B'		
162		ICW3_S5	LITERALLY '0010*0000B'		
161		ICW3_S6	LITERALLY '0100*0000B'		
160		ICW3_S7	LITERALLY '1000*0000B'		
172		ICW4_S6	LITERALLY '0000*0001B'		

CROSS-REFERENCE LISTING

Address	Hex	Symbol	Label	Address	Hex	Symbol	Label
0000CH	2	SP	WORD				
0000EH	2	DX	WORD				
00010H	2	CX	WORD				
00012H	2	BX	WORD				
00014H	2	AX	WORD				
00016H	2	IP	WORD				
00018H	2	CS	WORD				
0001AH	2	FLAGS	WORD				
00000H	4	REGP	POINTER IN PROC (XEC) PARAMETER	35			
00000H	4	REGP	POINTER EXTERNAL(39)				
00000H	4	RESETE	BYTE EXTERNAL(40)	316	318*		
00000H	1	REV_SCROLL	PROCEDURE EXTERNAL(69) STACK=0000H				
00000H	1	ROM	BYTE IN PROC (XMTSC) PARAMETER	303			
00000H	1	SCA	PROCEDURE EXTERNAL(65) STACK=0000H				
00000H	1	SCP	PROCEDURE EXTERNAL(66) STACK=0000H				
00000H	1	SCP1	PROCEDURE EXTERNAL(67) STACK=0000H				
00000H	1	SCROLL	PROCEDURE EXTERNAL(68) STACK=0000H				
00000H	2	SDS	PROCEDURE EXTERNAL(58) STACK=0000H	326			
00000H	2	STEP_COUNT	WORD EXTERNAL(74)				
00000H	4	STRNGP	POINTER IN PROC (WRITES) PARAMETER	66			
00000H	4	SMTC	PROCEDURE EXTERNAL(3) STACK=0000H				
00000H	4	S_INT0	LITERALLY '24'				
00000H	4	S_ITC_0	LITERALLY '10_INT_SL+0'				
00000H	4	S_ITC_1	LITERALLY '10_INT_SL+1'				
00000H	4	S_XMTC	POINTER EXTERNAL(27)				
00007H	1	TEMP	BYTE IN PROC (VIDEO_INTR)	329*	331*		
00000H	1	TESTK	PROCEDURE BYTE EXTERNAL(50) STACK=0000H				
00000H	6	TRUE	LITERALLY '0FFH'	338			
00000H	2	TTY_INTR	PROCEDURE EXTERNAL(62) STACK=0000H				
00000H	4	TTYPOLL	PROCEDURE BYTE EXTERNAL(63) STACK=0000H				
00000H	1	UIES	POINTER EXTERNAL(28)				
00000H	1	VALU	BYTE IN PROC (SCP1) PARAMETER	296			
00000H	52	VECTORS	POINTER ARRAY(13) EXTERNAL(30)				
00000H	1	VERT_LINE	BYTE EXTERNAL(14)				
00000H	1	VIDEO_INTR	PROCEDURE PUBLIC STACK=0006H				
00047H	57	VIDEO_INTR_A	PROCEDURE EXTERNAL(4) STACK=0000H				
00000H	18	VT	LITERALLY '00BH'				
00000H	5	WIP	BYTE ARRAY(5) EXTERNAL(13)				
00000H	62	WRITEC	PROCEDURE EXTERNAL(11) STACK=0000H	315			
00000H	65	WRITES	PROCEDURE EXTERNAL(12) STACK=0000H				
00000H	235	WRITK	PROCEDURE EXTERNAL(52) STACK=0000H				
00000H	67	XCA	POINTER EXTERNAL(29)				
00000H	4	XCOLOR_BACK	LITERALLY '00*111*000B'				
00000H	100	XCOLOR_FORE	LITERALLY '00*000*111B'				
00000H	108	XEC	PROCEDURE EXTERNAL(5) STACK=0000H				
00000H	10	XMT	STRUCTURE EXTERNAL(47)				
00000H	1	BURST	BYTE				
00000H	1	RCOUNT	INTEGER				
00000H	2	COUNT	WORD				
00000H	1	COL	BYTE				
00000H	1	RCM	BYTE				
00000H	1	COLOR	BYTE				
00000H	1	GRAPHIC	BYTE				
00000H	1	REVERSE	BYTE				
00000H	1	XMTSC	PROCEDURE EXTERNAL(70) STACK=0000H				


```

$ INCLUDE ('F2:SUBLIB.H')
= $SAVE
= $NOLIST
$ INCLUDE ('F2:VIDEO.H')
= $SAVE
= $NOLIST

```

```

$ IF EXTENDED_MONITOR
DC BUFFER STRUCTURE (
IN_POINTER BYTE,
OUT_POINTER BYTE,
COUNT BYTE,
CHAR(100) BYTE);
$ ENDIF

```

```

333 1 D_KBD: PROCEDURE(C) EXTERNAL;
334 2 DECLARE C BYTE;
335 2 END;
336 1 MTR_SWIM: PROCEDURE EXTERNAL INTERRUPT INT_STEP ;
337 2 END;

```

```

$ IF EXTENDED_MONITOR
P8085:
DECLARE AF WORD, EXTERNAL;
BC WORD,
DE WORD,
HL WORD,
PC WORD,
SP WORD,
PAGE WORD;
$ END;
ENDIF

```

```

338 1 BOOT_207_5: PROCEDURE EXTERNAL;
339 2 END;
340 1 BOOT_207_8: PROCEDURE EXTERNAL;
341 2 END;
$EJECT

```

```

$ IF EXTENDED_MONITOR
DECLARE CMD(*) BYTE DATA(
'Boot',0,
'Color Bar',0,
'Continue',0,
'Diagnose',0,
'Dump',0,
'Examine',0,
'Execute',0,
'Fill',0,
'Input',0,
'Move',0,
'Output',0,
'Register',0,
'Step',0,
'Swap',0,
'Terminal',0,
'Trace',0,
'Version',0,
0,0);
ELSE
CMD_STR(4) STRUCTURE (
CHAR BYTE,
STRING POINTER)
DATA (
'B',@CS_BOOT,
'V',@CS_VERS);
/* Identifying Character
/* Address of Command String
/* Boot String
/* Version String
CS_BOOT(*) BYTE DATA ('Boo',t'+E0S);
CS_VERS(*) BYTE DATA ('Version 1.','2'+E0S);
ENDIF
$

344 1 1 DC (ADDR_1,ADDR_2,ADDR_3)
BAROBT BOOL,
BYTE_1 BYTE,
C BYTE,
CMD_IDX BYTE,
CMD_PTR BYTE,
DELM BYTE,
I WORD,
INP_PTR WORD,
J WORD,
K WORD,
LINE(80) WORD,
MATCH BYTE,
PTR#P POINTER,
PTR_B BASED_PTR#P,
SELEC SELECTOR,
STALLED BOOL,
STEP_COUNT WORD
ADDR:
/* True if Boot Aborted
*/

345 1 1 DC CS_BOOT(*)
CS_VERS(*) BYTE DATA ('Boo',t'+E0S);
/* Version 1.','2'+E0S);
ENDIF
$

346 1 1 DC (ADDR_1,ADDR_2,ADDR_3)
BAROBT BOOL,
BYTE_1 BYTE,
C BYTE,
CMD_IDX BYTE,
CMD_PTR BYTE,
DELM BYTE,
I WORD,
INP_PTR WORD,
J WORD,
K WORD,
LINE(80) WORD,
MATCH BYTE,
PTR#P POINTER,
PTR_B BASED_PTR#P,
SELEC SELECTOR,
STALLED BOOL,
STEP_COUNT WORD
ADDR:
/* True if Boot Aborted
*/

347 1 1 DC (ADDR_1,ADDR_2,ADDR_3)
BAROBT BOOL,
BYTE_1 BYTE,
C BYTE,
CMD_IDX BYTE,
CMD_PTR BYTE,
DELM BYTE,
I WORD,
INP_PTR WORD,
J WORD,
K WORD,
LINE(80) WORD,
MATCH BYTE,
PTR#P POINTER,
PTR_B BASED_PTR#P,
SELEC SELECTOR,
STALLED BOOL,
STEP_COUNT WORD
ADDR:
/* True if Boot Aborted
*/
/* I/O is currently stalled
*/

```

```

$ IF EXTENDED_MONITOR
COMMAND: PROCEDURE BYTE; PUBLIC;
DECLARE C
DO;
CALL DPT???; /* Display Prompt */
MATCH, INP_PTR, CMD_PTR, CMD_IDX=0;
DO WHILE CMD(CMD_PTR) <> 0 ;
IF MATCH=0 THEN
C = MCU(READC);
MATCH=0;
IF (C=DEL OR C=BS) AND INP_PTR=0 THEN
CALL WRITEC(BEL);
ELSE IF C=DEL OR C=BS THEN
DO;
CALL RUBOUT;
INP_PTR=INP_PTR-1;
TMP_IDX, TMP_PTR=0;
CALL FNM;
CMD_PTR=TMP_PTR+INP_PTR;
CMD_IDX=TMP_IDX;
END;
ELSE IF C = MCU(CMD(CMD_PTR)) THEN
DO;
CALL WRITEC(CMD(CMD_PTR));
LINE(INP_PTR)=C;
TMP_PTR, CMD_PTR=CMD_PTR+1;
TMP_INP, INP_PTR=INP_PTR+1;
TMP_IDX=CMD_IDX;
CALL ANC;
CALL FNM;
BYTE_1=MCU(CMD(CMD_PTR));
DO WHILE BYTE_1<>0 AND BYTE_1=MCU(CMD(TMP_PTR+TMP_INP)) ;
CALL ANC;
CALL FNM;
END;
IF CMD(TMP_PTR) = 0 THEN
DO;
MATCH=1;
C=MCU(CMD(CMD_PTR+TMP_INP));
END;
ELSE
DO;
TMP_INP=INP_PTR;
TMP_PTR=CMD_PTR;
TMP_IDX=CMD_IDX;
CALL ANC;
CALL FNM;
DO WHILE CMD(TMP_PTR)<>0 AND C<>MCU(CMD(TMP_PTR+TMP_INP)) ;
CALL ANC;
    
```

```

      TMP_IDX=TMP_IDX+1;
      TMP_INP=0;
    END;
  END;

```

FNM: PROCEDURE;

```

DO;
  TMP_INP=0;
  DO WHILE CMD(TMP_PTR+TMP_INP)<>0 AND TMP_INP<INP_PTR ;
    DO WHILE CMD(TMP_PTR+TMP_INP)<>0 AND
      MCU(CMD(TMP_PTR+TMP_INP))=LINE(TMP_INP) AND
      TMP_INP<INP_PTR ;
      TMP_INP=TMP_INP+1;
    END;
  IF TMP_INP=INP_PTR OR CMD(TMP_PTR)=0
  THEN
    RETURN;
  ELSE
    DO;
      TMP_PTR=TMP_PTR+TMP_INP;
      CALL ANC;
    END;
  END;
END;

```

* ELSE

```

COMMAND: PROCEDURE PUBLIC;
DO;
CALL PROMPT; /* Display Prompt

```

*/

```

353 CMD_IDX = 2;
354 DO WHILE CMD_IDX = 2 ;
355 C = MCU(READC);
356 IF C = 'B' THEN
357 CMD_IDX = 0;
358 ELSE IF C = 'V' THEN
359 CMD_IDX = 1;
360 ELSE
361 CALL WRITEC(BEL);
362 END;
363 CALL WRITEC(' ');
364 DO CASE CMD_IDX ;
365 CALL C_BOOT;
366 CALL C_VERS;
367 END;

```

```

368 END;
369 END;

```

* ENDF


```

370 1      C_BOOT:      PROCEDURE      PUBLIC;
371 2      DECLARE      BOOT      ADDRESS,
                                C      BYTE,
                                PRIMARY      BOOL;
372 2      DO;
                                /* Address of Boot Routine
                                /* Temporarily Input Character
                                /* TRUE for boot from Prim. Dev */
                                DO;

373 3      ECHO:      PROCEDURE;
374 4      DO;
375 5      CALL WRITEC(C);
376 5      C = MCU(READC);
377 5      END;
378 4      END;

/* Default to the DIP-Switch
BOOT_PAR_INDEX = INPUT(IO_DIP) AND DIP_DEVICE_MASK;
IF BOOT_PAR_INDEX >= LENGTH(BOOT_DEVICE) THEN
DO;
CALL WRITES(@('BEL,CR,LF','Illegal Boot Configuratio','n'+EOS));
RETURN;
END;

385 3      BABORT = FALSE;
386 3      BOOT_PAR_UNIT = 0;
387 3      BOOT_PAR_STRNG(0) = 0;
388 3      PRIMARY = TRUE;

/* No initial boot Abort
/* Default is unit 0
/* Default to NULL string
/* Default to Primary Controller*/
IF NOT RESETF THEN
DO;
C=MCU(READC);
IF KY_F0+1 <= C AND C < KY_F0+1+LENGTH(BOOT_DEVICE) THEN
DO;
BOOT_PAR_INDEX = C - KY_F0 - 1;
CALL WRITES(@('ESC','p','f'+EOS));
CALL WRITEC(''+BOOT_PAR_INDEX+1);
CALL WRITES(@('ESC','q'+EOS));
C = MCU(READC);
END;
IF '0' <= C AND C<'0'+BOOT_DEVICE(BOOT_PAR_INDEX).NUM_UNITS THEN
DO;
BOOT_PAR_UNIT = C - '0';
CALL ECHO;
END;
IF C = 'S' THEN
DO;
PRIMARY = FALSE;
CALL ECHO;
END;
IF C = '.' THEN
DO;
I=0;
CALL WRITEC(C);
C=READC;

```

*EJECT

#EJECT

```
* IF EXTENDED_MONITOR
C_DIAG: PROCEDURE;
DO;
END;
END;

* ENDIF

$EJECT
```

```
CALL WRITEC(C);  
ELSE  
CALL WRITES(@(ESC,'F1',ESC,'G'+EOL)); /* Checkerboard */  
ADDR_3.OFFS=ADDR_3.OFFS+1;  
END;  
END;  
END;  
* ENDIF  
  
*EJECT
```

```
/*
 *      Fill      nnn:mmm -- pppp , qq
 */
$      IF EXTENDED_MONITOR
C_FILL:      PROCEDURE;
DO;
  DELIM=IHA(' ', @ADDR_1);
  IF DELIM<>' ' THEN
    RETURN;
  CALL WRITEC(DELIM);

  DELIM=IHV(' ', @ADDR_2.OFFS, 2);
  IF DELIM<>' ' THEN
    RETURN;
  CALL WRITEC(DELIM);

  DELIM=IHV(CR, @WORD_1, 1);
  IF DELIM<>CR THEN
    RETURN;

DO WHILE ADDR_1.OFFS <> ADDR_2.OFFS ;
  CALL SFB(LOW(WORD_1), ADDR_1.BASE, ADDR_1.OFFS);
  ADDR_1.OFFS=ADDR_1.OFFS+1;
END;
CALL SFB(LOW(WORD_1), ADDR_1.BASE, ADDR_1.OFFS);
END;
$      ENDIF

$EJECT
```

```

/*
 *      Move      nnnn:mmmm -- pppp , qqqq
 */
$      IF EXTENDED_MONITOR
C_MOVE:      PROCEDURE;
DO;
  DELIM=IHA(' ', @ADDR_1);
  IF DELIM<>' ' THEN
    RETURN;
  CALL WRITEC(DELIM);

  DELIM=IHV(' ', @ADDR_2.OFFS, 2);
  IF DELIM<>' ' THEN
    RETURN;
  CALL WRITEC(DELIM);

  DELIM=IHV(CR, @WORD_1, 2);
  IF DELIM<>CR THEN
    RETURN;

  IF (ADDR_1.OFFS<=ADDR_2.OFFS AND
      ADDR_1.OFFS<=WORD_1 AND WORD_1<=ADDR_2.OFFS) OR
      (ADDR_1.OFFS>=ADDR_2.OFFS AND
      (ADDR_2.OFFS<=WORD_1 OR WORD_1<=ADDR_1.OFFS))
  THEN
    DO;
      I=-1;
      WORD_1=WORD_1+ADDR_2.OFFS-ADDR_1.OFFS;
      WORD_2=ADDR_1.OFFS;
      ADDR_1.OFFS=ADDR_2.OFFS;
      ADDR_2.OFFS=WORD_2;
    END;
  ELSE
    I=1;

  DO WHILE ADDR_1.OFFS <> ADDR_2.OFFS ;
  CALL SFB(GFB(ADDR_1.BASE, ADDR_1.OFFS), ADDR_1.BASE, WORD_1);
  ADDR_1.OFFS=ADDR_1.OFFS+I;
  WORD_1=WORD_1+I;
  END;
  CALL SFB(GFB(ADDR_1.BASE, ADDR_1.OFFS), ADDR_1.BASE, WORD_1);
  END;
$      ENDIF

```

*EJECT

```

$ IF EXTENDED_MONITOR
  PROCEDURE;
  DO;
    STEP_COUNT=0;
    DELIM=IHV(CR,@WORD_1,2);
    IF DELIM <> CR THEN
      RETURN;
    CALL CRLF;
  
```

```

STEP_COUNT = WORD_1 ;
CALL SSTEP;
END;
END;
END;

```

```

$ ENDIF

```

```

$ IF EXTENDED_MONITOR
  PROCEDURE PUBLIC;
  DO;
    WORD_1=REG_IP;
    DO WHILE PREFIX(GFB(REG_CS,WORD_1)) ;
      WORD_1=WORD_1+1;
    END;
    IF GFB(REG_CS,WORD_1)=0SEH AND
      (GFB(REG_CS,WORD_1+1) AND 00*011*000B)=00*010*000B
    THEN
      DO;
        CALL WRITES('@Bad to trap through mov to SS,CR,LF+EOS);
        REG_FLAGS = REG_FLAGS AND (NOT CPU_TF) ;
      END;
    ELSE
      DO;
        REG_FLAGS = REG_FLAGS OR CPU_TF ;
        CALL XEC(REG*P);
      END;
    END;
  
```

```

END;
END;

```

```

PREFIX:
DECLARE
  op_code
  BYTE;
  BOOL;
DO;
  IF
    (op_code AND 111*00*111B)=001*00*110B THEN
    RETURN(TRUE);
  ELSE IF op_code = 0F0H THEN
  
```



```
* IF EXTENDED_MONITOR
C_SWAP: PROCEDURE;
DO;
  DELIM=IHA(' ', @ADDR_1);
  IF DELIM <> ' ' THEN
    RETURN;
  DELIM=IHV(CR, @WORD_1, 2);
  IF DELIM <> CR THEN
    RETURN;
CALL P8085(ADDR_1, BASE, WORD_1, ADDR_1, OFFS, 0, 0, 0, 0);
END;
* ENDIF

*EJECT
```

```
CALL WRITES(@(' AX BX CX DX SI DI BP',CR,LF+EOS));
CALL ORV(REG.AX);
CALL ORV(REG.BX);
CALL ORV(REG.CX);
CALL ORV(REG.DX);
CALL ORV(REG.SI);
CALL ORV(REG.DI);
CALL OHM(REG.BP);
CALL CRLF;

CALL CRLF;
CALL WRITES(@(' IP CS SP SS DS ES Flags',CR,LF+EOS));
CALL ORV(REG.IP);
CALL ORV(REG.CS);
CALL ORV(REG.SP);
CALL ORV(REG.SS);
CALL ORV(REG.DS);
CALL ORV(REG.ES);
CALL OHM(REG.FLAGS);
CALL CRLF;
CALL CRLF;
END;
```

```
$ ENDIF
```

```
*EJECT
```



```
*        IF EXTENDED_MONITOR  
C_EXECUTE:        PROCEDURE;  
DO;  
  DELIM=IHAYCR,eADDR_1);  
  IF DELIM<>YCR THEN  
    RETURN;  
  REG_CS=ADDR_1.BASE;  
  REG_IP=ADDR_1.OFFS;  
  CALL XEC(REG#P);  
END;  
*        ENDIF
```

464 1 END;

```

00C0 A02A00 MOV AL,CMD_IDX
00C3 B105 MOV CL,5H
00C5 F6E1 MUL CL
00C7 89C3 MOV BX,AX
00C9 2EC4870B00 LES AX,CS:CMD_STRCBX+1HJ
00CE 06 PUSH ES ; 1
00CF 50 PUSH AX ; 2
00D0 E90000 CALL WRITES
; STATEMENT # 363
00D3 B020 MOV AL,20H
00D5 50 PUSH AX ; 1
00D6 E90000 CALL WRITTEC
; STATEMENT # 364
00D9 8A1E2A00 MOV BL,CMD_IDX
00DD B700 MOV BH,0H
00DF D1E3 SHL BX,1
00E1 2EFA7E600 JMP CS:@IBXJ
; STATEMENT # 365
00E6 EA00 DW @9
00E8 EF00 DW @10
; STATEMENT # 366
00EA E90700 CALL C_BOOT
; STATEMENT # 369
00ED 5D POP BP
00EE C3 RET
; STATEMENT # 370
00FF E9C201 CALL C_VERS
; STATEMENT # 373
00F2 5D POP BP
00F3 C3 RET
; STATEMENT # 374
00F4 55 C_BOOT PROC NEAR
00F5 8BEC MOV BP,SP
; STATEMENT # 375
0276 55 ECHO PROC NEAR
0277 8BEC MOV BP,SP
; STATEMENT # 376
0279 FF368300 PUSH C
027D E90000 CALL WRITTEC
; STATEMENT # 377
0280 E90000 CALL READC
0283 50 PUSH AX ; 1
0284 E90000 CALL MCU
0287 A28300 MOV C,AL
; STATEMENT # 378
028A 5D POP BP
028B C3 RET
ECHO ENDP
; STATEMENT # 379
00F7 E4FF IN @FFH
00F9 2407 AND AL,7H
00FB A20000 MOV BOOT_PAR,AL
  
```

```

015F A28300      MOV      C,AL      ; STATEMENT # 400
                                @13:
0162 B130      MOV      CL,30H
0164 A08300      MOV      AL,C
0167 3AC8      CMP      CL,AL
0169 7721      JA      @14
016B A00000      MOV      AL,BOOT_PAR
016E B205      MOV      DL,5H
0170 F6E2      MULL   DL
0172 89C3      MOV      BX,AX
0174 2E8A70200  MOV      AL,CS:BOOT_DEVICE(BX+2H)
0179 02C1      ADD      AL,CL
017B 8A168300  MOV      DL,C
017E 3AD0      CMP      DL,AL
0181 7309      JNB     @14
                                ; STATEMENT # 402
0183 2AD1      SUB      DL,CL
0185 80165200  MOV      BOOT_PAR+52H,DL
                                ; STATEMENT # 403
0189 E8EA00      CALL    ECHO
                                ; STATEMENT # 405
                                @14:
018C 803E83053  CMP      C,53H
0191 7508      JNZ     @15
                                ; STATEMENT # 407
0193 C606840000  MOV      PRIMARY,0H
                                ; STATEMENT # 408
0198 E8DB00      CALL    ECHO
                                ; STATEMENT # 410
                                @15:
019B A08300      MOV      AL,C
019E 3C3A      CMP      AL,3AH
01A0 7539      JNZ     @16
                                ; STATEMENT # 412
01A2 C7060C000000  MOV      I,0H
                                ; STATEMENT # 413
01A8 50      PUSH   AX
                                ; 1
01A9 E80000      CALL    WRITEC
                                ; STATEMENT # 414
01AC E80000      CALL    READC
01AF A28300      MOV      C,AL
                                ; STATEMENT # 415
                                @17:
01B2 A08300      MOV      AL,C
01B5 3C0D      CMP      AL,0DH
01B7 7419      JZ      @18
01B9 A10C00      MOV      AX,I
01BC 83F84E      CMP      AX,4EH
01BF 7311      JNB     @18
                                ; STATEMENT # 416
01C1 87C3      MOV      BX,AX
01C3 8A0E8300  MOV      CL,C
01C7 888F0200  MOV      BOOT_PAR(BX+2H),CL
                                ; STATEMENT # 417

```

```

0231 732D JNB @24
0233 A02700 MOV AL,BARBRT
0236 D0D8 RCR AL,1
0238 7226 JB @24
; STATEMENT # 438

023A B80000 MOV AX,0H
023D C41E0000 LES BX,REGP
0241 26894718 ES:REGIBX+19HJ,AX
0245 268907 ES:REGIBXJ,AX
0248 26894704 ES:REGIBX+4HJ,AX
; STATEMENT # 439

024C 26C747160004 MOV ES:REGIBX+16HJ,400H
; STATEMENT # 440

0252 E80000 CALL ORLF
; STATEMENT # 441

0255 C4060000 LES AX,REGP
0259 06 PUSH ES ; 1
025A 50 PUSH AX ; 2
025B E80000 CALL XEC
; STATEMENT # 443

025E 5D POP BP
025F C3 RET

; STATEMENT # 444

0260 A02700 MOV AL,BARBRT
0263 D0D8 RCR AL,1
0265 7305 JNB @26
; STATEMENT # 445

0267 B86500 MOV AX,OFFSET(@@LONG*CONSTANT*0065H)
026A EB03 JMP @31
; STATEMENT # 445

; STATEMENT # 446

026C B87200 MOV AX,OFFSET(@@LONG*CONSTANT*0072H)
; STATEMENT # 446

; STATEMENT # 447

026F 0E PUSH CS ; 1
0270 50 PUSH AX ; 2
0271 E80000 CALL WRITES
; STATEMENT # 447

; STATEMENT # 448

0274 5D POP BP
0275 C3 RET
; STATEMENT # 448

; STATEMENT # 449

0277 5D POP BP
0278 C3 RET
; STATEMENT # 449

; STATEMENT # 450

027A 5D POP BP
027B C3 RET
; STATEMENT # 450

; STATEMENT # 451

027D 5D POP BP
027E C3 RET
; STATEMENT # 451

; STATEMENT # 452

027F 5D POP BP
0280 C3 RET
; STATEMENT # 452

; STATEMENT # 453

0282 5D POP BP
0283 C3 RET
; STATEMENT # 453

; STATEMENT # 454

0285 5D POP BP
0286 C3 RET
; STATEMENT # 454

; STATEMENT # 455

0288 5D POP BP
0289 C3 RET
; STATEMENT # 455

; STATEMENT # 456

028B 5D POP BP
028C C3 RET
; STATEMENT # 456

; STATEMENT # 457

028E 5D POP BP
028F C3 RET
; STATEMENT # 457

; STATEMENT # 458

0290 5D POP BP
0291 C3 RET
; STATEMENT # 458

; STATEMENT # 459

0293 5D POP BP
0294 C3 RET
; STATEMENT # 459

; STATEMENT # 460

0295 5D POP BP
0296 C3 RET
; STATEMENT # 460

; STATEMENT # 461

0297 5D POP BP
0298 C3 RET
; STATEMENT # 461

; STATEMENT # 462

0299 5D POP BP
029A C3 RET
; STATEMENT # 462
    
```


CROSS-REFERENCE LISTING

107	0000H	4	DCI.	139	140	141	142	143	144	145	146	147	148	149	150
11	002CH	1	DEL.	151	152	153	154	155	156	157	158	159	160	161	162
347	002CH	1	DELIM.	163	164	165	166	167	168	169	170	171	172	173	174
108	0000H	4	DFC.	175	176	177	178	179	180	181	182	183	184	185	186
72			DIP_0.	187	188	189	190	191	192	193	194	195	196	197	198
73			DIP_1.	199	200	201	202	203	204	205	206	207	208	209	210
74			DIP_2.	211	212	213	214	215	216	217	218	219	220	221	222
75			DIP_3.	223	224	225	226	227	228	229	230	231	232	233	234
76			DIP_4.	235	236	237	238	239	240	241	242	243	244	245	246
77			DIP_5.	247	248	249	250	251	252	253	254	255	256	257	258
30			DIP_50HZ.	259	260	261	262	263	264	265	266	267	268	269	270
78			DIP_6.	271	272	273	274	275	276	277	278	279	280	281	282
79			DIP_7.	344	345	346	347	348							
84			DIP_AUTO_BOOT.												
85			DIP_DEVICE_MASK.												
81			DIP_RSV_1.												
82			DIP_RSV_2.												
83			DIP_RSV_3.												
123	0000H	256	DMAP.												
105	0000H	2	DS_SIZE.												
21	0000H		DXMTC.												
306	0000H		D_CRT.												
333	0000H		D_KBD.												
309	0000H		D_TTY_RES.												
109	0000H	4	D_XMTC.												
373	0276H	22	ECHO.												
110	0000H	4	EDC.												
111	0000H	4	EMEC.												
315	0000H		ENABLE_LINES.												
12			EOL.												
13			EQS.												
14			ESC.												
137	0000H	10	ESCP.												
	0000H	1	COMMAND.												
	0001H	2	FUNCTION.												
	0003H	1	MODE.												
	0004H	1	OPER_COUNT.												
	0005H	1	OPER_INDEX.												
	0006H	4	OPERAND.												
147			F86_AF.												
149			F86_CF.												
142			F86_DF.												
143			F86_IF.												

POINTER EXTERNAL (17) 455
LITERALLY '07FH'

POINTER EXTERNAL (18)
LITERALLY '000\$0001B'

LITERALLY '0000\$0010B'

LITERALLY '0000\$1000B'

LITERALLY '0001\$0000B'

LITERALLY '0100\$0000B'

LITERALLY '1000\$0000B'

LITERALLY '0\$000\$1\$000B'

LITERALLY '0\$100\$0\$000B'

LITERALLY '0\$010\$0\$000B'

LITERALLY '0\$001\$0\$000B'

BYTE ARRAY(256) EXTERNAL(33)

WORD EXTERNAL(15)

PROCEDURE EXTERNAL(0) STACK=0000H

PROCEDURE EXTERNAL(59) STACK=0000H

PROCEDURE EXTERNAL(70) STACK=0000H

PROCEDURE EXTERNAL(60) STACK=0000H

POINTER EXTERNAL(19)

PROCEDURE IN PROC (C_BOOT) STACK=0006H

POINTER EXTERNAL(20)

POINTER EXTERNAL(21)

PROCEDURE EXTERNAL(63) STACK=0000H

LITERALLY '080H'

LITERALLY '080H' 345 382 395 397 425 444 445

LITERALLY '01BH' 395 397

STRUCTURE EXTERNAL(44)

BYTE

WORD

FUNCTION

MODE

OPER_COUNT

OPER_INDEX

OPERAND

BYTE ARRAY(4)

LITERALLY '0000\$0001\$0000B'

LITERALLY '0000\$0000\$0001B'

LITERALLY '0100\$0000\$0000B'

LITERALLY '0010\$0000\$0000B'

453

204	ICW3_S6.	LITERALLY '0100\$0000B'	
203	ICW3_S7.	LITERALLY '1000\$0000B'	
215	ICW4_86.	LITERALLY '0000\$0001B'	
214	ICW4_AE01.	LITERALLY '0000\$0010B'	
212	ICW4_BUF.	LITERALLY '0000\$1000B'	
211	ICW4_FNM.	LITERALLY '0001\$0000B'	
213	ICW4_MS.	LITERALLY '0000\$0100B'	
170	IL_KV.	LITERALLY '6'	
184	IL_PERR.	LITERALLY '0'	
185	IL_PSWAP.	LITERALLY '1'	
191	IL_PTR.	LITERALLY '7'	
187	IL_S100.	LITERALLY '3'	
188	IL_SER_A.	LITERALLY '4'	
189	IL_SER_B.	LITERALLY '5'	
186	IL_TIMER.	LITERALLY '2'	
26	INCB.	PROCEDURE EXTERNAL (2) STACK=0000H	
37	INIT_ITV.	PROCEDURE EXTERNAL (6) STACK=0000H	
0000H	INPUT.	BUILTIN	
002DH	INP_PTR.	BYTE	379
150	INT_DBZ.	LITERALLY '0'	
154	INT_IOF.	LITERALLY '4'	
152	INT_NMI.	LITERALLY '2'	
153	INT_OBI.	LITERALLY '3'	
151	INT_SSTEP.	LITERALLY '1'	336
175	IO_CRTC.	LITERALLY '00DCH'	
155	IO_DIP.	LITERALLY '00F7H'	379
172	IO_GENERAL.	LITERALLY '00E0H'	
157	IO_HIADR.	LITERALLY '00FDH'	
166	IO_INT_MS.	LITERALLY '00F2H'	
167	IO_INT_SL.	LITERALLY '00F0H'	
165	IO_KEYBRD.	LITERALLY '00F4H'	
174	IO_LTPN.	LITERALLY '00DEH'	
158	IO_MEM.	LITERALLY '00FCH'	
171	IO_PRINTER.	LITERALLY '00E2H'	
160	IO_RSRV_1.	LITERALLY '00FAH'	
162	IO_RSRV_2.	LITERALLY '00F3H'	
163	IO_RSRV_3.	LITERALLY '00F7H'	
164	IO_RSRV_4.	LITERALLY '00F6H'	
173	IO_RSRV_5.	LITERALLY '00DFH'	
177	IO_RSRV_6.	LITERALLY '00CFH'	
169	IO_SER_A.	LITERALLY '00E8H'	
168	IO_SER_B.	LITERALLY '00ECH'	
161	IO_SOUND.	LITERALLY '00F9H'	
156	IO_SWAP.	LITERALLY '00FEH'	
170	IO_TIMER.	LITERALLY '00E4H'	
159	IO_TSTAT.	LITERALLY '00FBH'	
176	IO_VIDED.	LITERALLY '00D3H'	
179	IO_Z207_0.	LITERALLY '00B0H'	342
178	IO_Z207_1.	LITERALLY '00B8H'	342
181	IO_Z217_0.	LITERALLY '00A8H'	
180	IO_Z217_1.	LITERALLY '00A0H'	
38	IWI.	BYTE IN PROC (INIT_ITV) PARAMETER	38
38	IVP.	POINTER IN PROC (INIT_ITV) PARAMETER	38
347	J.	WORD	
347	K.	WORD	
242	KC_ARF.	LITERALLY '02H'	

32	0000H	VIDEO_INTR_A	PROCEDURE EXTERNAL(4) STACK=0000H				
44		VID_CDC	LITERALLY '10_VIDEO+1'				
43		VID_CDD	LITERALLY '10_VIDEO+0'				
42		VID_CMD	LITERALLY '10_VIDEO+0'				
45		VRM_DAT	LITERALLY '10_VIDEO+2'				
47		VRM_MPC	LITERALLY '10_VIDEO+3'				
46		VRM_MPD	LITERALLY '10_VIDEO+2'				
18		VT	LITERALLY '00BH'				
103	0000H	WIP	BYTE ARRAY(5) EXTERNAL(13)				
349	001AH	WORD_1	WORD				
349	001CH	WORD_2	WORD				
349	001EH	WORD_3	WORD				
349	0020H	WORD_4	WORD				
94	0000H	WRITEC	PROCEDURE EXTERNAL(11) STACK=0000H	360	363	375	396
97	0000H	WRITES	418				
			PROCEDURE EXTERNAL(12) STACK=0000H	362	382	395	397
278	0000H	WRITE	444	445			
119	0000H	XCA	PROCEDURE EXTERNAL(51) STACK=0000H				
133		XCOLOR_BACK	POINTER EXTERNAL(29)				
132		XCOLOR_FORE	LITERALLY '001111\$00B'				
34	0000H	XEC	LITERALLY '001000\$111B'				
140	0000H	XMT	PROCEDURE EXTERNAL(5) STACK=0000H	441			
			STRUCTURE EXTERNAL(47)				
			BYTE				
			INTEGER				
			WORD				
			BYTE				
			BYTE				
			BYTE				
			BYTE				
			BYTE				
			PROCEDURE EXTERNAL(69) STACK=0000H				
330	0000H	XMTSC	LITERALLY '013H'				
19		XOHF	LITERALLY '011H'				
20		XON	LITERALLY '10\$00\$00B'				
131		XREVERSE	LITERALLY '10\$00\$00B'				

MODULE INFORMATION:

CODE AREA SIZE = 02R9H 697D
 CONSTANT AREA SIZE = 0000H 0D
 VARIABLE AREA SIZE = 0085H 133D
 MAXIMUM STACK SIZE = 000AH 10D
 2272 LINES READ
 0 PROGRAM WARNINGS
 0 PROGRAM ERRORS

END OF PL/M-86 COMPILATION

Initialization Routines

```

/*
 * INIT_68A21' initializes the General/Printer 68A21.
 *
 * NOTE: To provide a viable system, the interrupts
 * in the data port should always be enabled.
 * This is so that it is never necessary to
 * examine this port before outputting to it.
 * Such an output might accidentally clear a
 * pending interrupt. Instead, any interrupt
 * enable/disable should be done in the con-
 * trol port of the 6821.
 *
 * The various ports and pins are initialized as follows:
 *
 * Port A
 * bits 1--0: Output Printer Data, bits 1--0
 * bit 2: Output,1; NOT Strobe
 * bit 3: Output,1; NOT Prime
 * bit 4: Input; Vertical Synchronization
 * bit 5: Output,1; Video Interrupt Enable
 * bit 6: Input; Light Pen Switch
 * bit 7: Output,1; Light Pen Interrupt Enable
 *
 * CA1: Low to High; Light Pen Strobe
 * CA2: Low to High; Video Interrupt
 *
 * Port B
 * bit 0: Input; Busy
 * bit 1: Input; NOT Fault
 * bits 7--2: Output,0; Printer Data, bits 7--2
 *
 * CB1: Input; Printer Acknowledge
 * CB2: Input; Printer Busy
 */
242 1 INIT_68A21: PROCEDURE;
243 2 DO;
/*
 * Initialize Port A
 */
OUTPUT(GEN_CNT)=(P6821_C2_1 OR P6821_OR_A OR P6821_C1_1);
OUTPUT(GEN_DAT)=0000011100B; /* Initialize Data */
OUTPUT(GEN_CNT)=(P6821_C2_1 OR P6821_C1_1);
OUTPUT(GEN_DIR)=101011111B; /* Set direction */
OUTPUT(GEN_CNT)=(P6821_C2_1 OR P6821_OR_A OR P6821_C1_1);
OUTPUT(GEN_DAT)=101011100B; /* Enable Interrupts */
/*

```

```
/*
 * INIT_8259_85 - Initialize 8259 for 8085
 *
 * INIT_8259_85 initializes the 8259's for the 8085 mode
 * of operation.
 */
```

\$ IF EXTENDED_MONITOR

INIT_8259_85: PROCEDURE PUBLIC;

```
DO;
  OUTPUT(M_ITC_0)=ICW1_ICW1 OR ICW1_LTIM OR ICW1_IC4;
  OUTPUT(M_ITC_1)=0;
  OUTPUT(M_ITC_1)=ICW3_S3;
  OUTPUT(M_ITC_1)=ICW4_FNM OR ICW4_AEOI;
  OUTPUT(M_ITC_1)=OCW1_ALL; /* Mask all interrupts */
  OUTPUT(S_ITC_0)=ICW1_ICW1 OR ICW1_LTIM OR ICW1_IC4;
  OUTPUT(S_ITC_1)=0FFH;
  OUTPUT(S_ITC_1)=3;
  OUTPUT(S_ITC_1)=ICW4_FNM OR ICW4_AEOI;
  OUTPUT(S_ITC_1)=OCW1_ALL; /* Mask all interrupts */
END;
```

\$ ENDIF

\$EJECT


```

290 1 INIT_TERMINAL:      PROCEDURE;
291 2 DECLARE      I      WORD;
292 2 DO;
    /*
293 3 * Initialize RAM Vectors to ROM Routines
    */
    CALL MOVW(@INITIAL_VECTORS,@VECTORS,SIZE(VECTORS)/2);

    /*
294 3 * Initialize H-19 Parameters
    */
    H19_PAR.CPL = 80;      /* 80 Characters Per Line */
    H19_PAR.LPS = 25;     /* 25 Lines Per Screen */
    H19_PAR.SLI = 24;     /* 24 is Status Line Index */
    H19_PAR.DSC = 9;     /* Displayed Scan Lines Per Character */
    H19_PAR.SPC = 11;     /* 11 Scan Lines Per Character */
    XMT_BURST = 960/60;   /* 9600 Baud, or 16 Char/Sec */

    /*
295 3 * Initialize Keyboard and Display Maps
    */
    DO I=0 TO LAST(DMAP) ;
296 4 KMAP(I),DMAP(I)=I;
297 4 END;
298 4 IF 0=1
299 4 DO I='a'-' ' TO DEL-' ' ;
    DMAP(I)=I-'a'-'A';
    END;
    /*
300 4 * ENDIF
301 4 IF 0=0
302 4 DO I=DEL+1-' ' TO (DEL+1-' ')+(DEL-' ' -1) ;
    DMAP(I)=I-(DEL+1-' ')+' '-' ' ;
    END;
    /*
303 4 * ENDIF
304 4 ENDIF
305 4 ENDIF

    /*
306 3 * Reset Terminal to Power-Up Configuration
    */
    CALL P_RES;

    /*
307 3 * Enable VSYNC Interrupts
308 3 */
    OUTPUT(GEN_CNT)=INPUT(GEN_CNT) OR P6821_C2_0;
309 2 END;
310 1 END;
  
```

```

006E E6E3 OUT 0E3H ; STATEMENT # 251
0070 B000 MOV AL,0H
0072 E6E2 OUT 0E2H ; STATEMENT # 252
0074 B012 MOV AL,12H
0076 E6E3 OUT 0E3H ; STATEMENT # 253
0078 B0FC MOV AL,0FCH
007A E6E2 OUT 0E2H ; STATEMENT # 254
007C B016 MOV AL,16H
007E E6E3 OUT 0E3H ; STATEMENT # 256
0080 SD POP BP
0081 C3 RET BP
; STATEMENT # 257
INIT_68A21 ENDP
; STATEMENT # 257
INIT_8259_88 PROC NEAR
0082 55 PUSH BP
0083 8BEC MOV BP,SP
; STATEMENT # 259
0085 B019 MOV AL,19H
0087 E6F2 OUT 0F2H ; STATEMENT # 260
0089 A00000 MOV AL,B1IL
008C B1F8 MOV CL,0F8H
008E 22C1 AND AL,CL
0090 E6F3 OUT 0F3H ; STATEMENT # 261
0092 B008 MOV AL,8H
0094 E6F3 OUT 0F3H ; STATEMENT # 262
0096 B013 MOV AL,13H
0098 E6F3 OUT 0F3H ; STATEMENT # 263
009A B0FF MOV AL,0FFH
009C E6F3 OUT 0F3H ; STATEMENT # 264
009E B019 MOV AL,19H
00A0 E6F0 OUT 0F0H ; STATEMENT # 265
00A2 A00000 MOV AL,B3IL
00A5 22C1 AND AL,CL
00A7 E6F1 OUT 0F1H ; STATEMENT # 266
00A9 B003 MOV AL,3H
00AB E6F1 OUT 0F1H ; STATEMENT # 267
00AD B013 MOV AL,13H
00AF E6F1 OUT 0F1H ; STATEMENT # 268
00B1 B0FF MOV AL,0FFH
00B3 E6F1 OUT 0F1H ; STATEMENT # 270
00B5 SD POP BP
    
```

```

0112 FE060200      INC      I          ; STATEMENT # 286
0116 75CE          JNZ      @1         ; STATEMENT # 287
@2:
0118 A00000        MOV      AL,BILL
011B 0406          ADD      AL,6H
011D 50            PUSH     AX          ; 1
011E BA0000        MOV      DX,SEG(VIDEO_INTR_A)
0121 B80000        MOV      AX,OFFSET(VIDEO_INTR_A)
0124 52            PUSH     DX          ; 2
0125 50            PUSH     AX          ; 3
0126 E80000        CALL     INIT_IV
; STATEMENT # 289
0129 5D            POP      BP
012A C3            RET

INIT_IV ENDP
; STATEMENT # 290
012B 55            INIT_TERMINAL
012C 8BEC          PUSH     BP,SP
BP,SP
; STATEMENT # 293
012E BE0000        MOV      SI,OFFSET(INITIAL_VECTORS)
0131 BF0000        MOV      DI,OFFSET(VECTORS)
0134 B91A00        MOV      CX,1AH
0137 1E            PUSH     DS          ; 1
0138 07            POP      ES          ; 1
0139 0E            PUSH     CS          ; 1
013A 1F            POP      DS          ; 1
013B FC            CLD
013C F2A5          REP     MOVSM
013E 06            PUSH     ES          ; 1
013F 1F            POP      DS          ; 1
; STATEMENT # 294
0140 C606000050     MOV      HI9_PAR,50H
; STATEMENT # 295
0145 C606020019     MOV      HI9_PAR+2H,19H
; STATEMENT # 296
014A C606040018     MOV      HI9_PAR+4H,18H
; STATEMENT # 297
014F C606010009     MOV      HI9_PAR+1H,9H
; STATEMENT # 298
0154 C60605000B     MOV      HI9_PAR+5H,0BH
; STATEMENT # 299
0159 C606000010     MOV      XMT,10H
; STATEMENT # 300
015E C70600000000  MOV      I,0H
@3:
0164 A10000        MOV      AX,I
0167 3DF000        CMP      AX,0FFH
016A 7710          JA      @4
; STATEMENT # 301
016C 89C3          MOV      BX,AX
016E 88870000     MOV      DMAP[BX],AL
0172 88870000     MOV      KMAP[BX],AL
; STATEMENT # 302

```

DEFN	ADDR	SIZE	NAME, ATTRIBUTES, AND REFERENCES
7	00000H	1	BEL.
67	00000H	1	BILL.
4	00000H	83	BOUL.
47	00000H	1	ROOT_PAR.
	00001H	1	INDEX.
	00011H	1	PORT.
	0002H	80	STRING.
	0052H	1	UNIT.
8	00000H	1	BS.
68	00000H	1	BSIL.
27	00000H	4	BYTEPTR.
30	00000H	1	C.
22	00000H	1	C.
7	00000H	1	CAN.
214	00000H	1	CHAR.
83	00000H	1	CHAR.
211	00000H	1	CHAR.
217	00000H	1	CHAR_DST.
217	00000H	1	CHAR_SRC.
41	00000H	1	CODE_SEG.
86	00000H	1	COL.
75	00000H	7	COLOR.
	0001H	1	FORE.
	0001H	1	BACK.
	0002H	1	MASK.
	0003H	1	CLEAR.
	0004H	1	PAINTED.
	0005H	1	FONT.
	0006H	1	COMP_FONT.
211	00000H	2	COMP_F.
217	00000H	1	COUNT.
214	00000H	1	COUNT.
10	00000H	3	CR.
76	00000H	3	CRTC_CURSOR.
	00000H	2	START.
	0002H	1	UPDATE.
77	00000H	3	CRTC_DISPLAY.
	00000H	2	START.
	0002H	1	UPDATE.
2	0002H	1	DC.
			LITERALLY '007H'
			BYTE EXTERNAL(31)
			LITERALLY 'BYTE'
			STRUCTURE EXTERNAL(11)
			BYTE
			BYTE
			BYTE ARRAY(80)
			BYTE
			LITERALLY '003H'
			BYTE EXTERNAL(32)
			POINTER IN PROC (INCB) PARAMETER
			BYTE IN PROC (SXMT) PARAMETER
			BYTE IN PROC (DXMT) PARAMETER
			LITERALLY '018H'
			BYTE IN PROC (MTR_EDC) PARAMETER
			BYTE IN PROC (S_CRT) PARAMETER
			BYTE IN PROC (MTR_DFC) PARAMETER
			BYTE IN PROC (MTR_MDC) PARAMETER
			BYTE IN PROC (MTR_MDC) PARAMETER
			LITERALLY '0FE05H'
			BYTE IN PROC (DCA) PARAMETER
			STRUCTURE EXTERNAL(36)
			BYTE
			BYTE
			BYTE
			BYTE
			WORD IN PROC (MTR_DFC) PARAMETER
			WORD IN PROC (MTR_MDC) PARAMETER
			BYTE IN PROC (MTR_EDC) PARAMETER
			LITERALLY '00DH'
			STRUCTURE EXTERNAL(37)
			WORD
			BYTE
			STRUCTURE EXTERNAL(38)
			WORD
			WORD
			LITERALLY 'DECLARE'
			10 11 12 13 14 15 16 17 18 19 39 40
			41 42 43 44 45 46 47 48 49 50 51 52
			53 54 55 56 57 58 59 60 61 62 63 64
			65 66 67 68 69 70 71 72 73 74 75 76
			77 78 79 80 97 98 99 100 101 102 103 104
			105 106 107 108 109 110 111 112 113 114 115 116
			117 118 119 120 121 122 123 124 125 126 127 128
			129 130 131 132 133 134 135 136 137 138 139 140
			141 142 143 144 145 146 147 148 149 150 151 152
			153 154 155 156 157 158 159 160 161 162 163 164
			165 166 167 168 169 170 171 172 173 174 175 176
			177 178 179 180 181 182 183 184 185 186 187 188
			189 190 191 192 193 194 195 196 197 198 199 200

Address	Hex	Label	Value	Address	Hex	Label	Value
225	0000H	VRAM_SIZE	1	225	0000H	BYTE IN PROC (MTR_ROC) PARAMETER	225
211	0000H	HORZ	1	211	0000H	BYTE IN PROC (MTR_DFC) PARAMETER	211
65	0000H	HORZ_CHAR	1	65	0000H	BYTE EXTERNAL(29)	
16	0000H	HT	1	16	0000H	LITERALLY '009H'	
281	0002H	I	1	281	0002H	BYTE IN PROC (INIT_IV)	283*
291	0000H	I	1	291	0000H	WORD IN PROC (INIT_TERMINAL)	300* 300 301 302 303* 303
139	0000H	ICM1_A7A5	1	139	0000H	LITERALLY '1110#0000B'	
142	0000H	ICM1_A014	1	142	0000H	LITERALLY '0000#0100B'	
144	0000H	ICM1_IC4	1	144	0000H	LITERALLY '0000#0001B'	259 264
140	0000H	ICM1_ICM1	1	140	0000H	LITERALLY '0001#0000B'	259 264
141	0000H	ICM1_LTIM	1	141	0000H	LITERALLY '0000#11000B'	259 264
143	0000H	ICM1_SINGL	1	143	0000H	LITERALLY '0000#0010B'	
145	0000H	ICM2_A15A8	1	145	0000H	LITERALLY '1111#1111B'	
153	0000H	ICM3_S0	1	153	0000H	LITERALLY '0000#0001B'	
152	0000H	ICM3_S1	1	152	0000H	LITERALLY '0000#0010B'	
151	0000H	ICM3_S2	1	151	0000H	LITERALLY '0000#0100B'	
150	0000H	ICM3_S3	1	150	0000H	LITERALLY '0000#11000B'	261
149	0000H	ICM3_S4	1	149	0000H	LITERALLY '0001#0000B'	
148	0000H	ICM3_S5	1	148	0000H	LITERALLY '0010#0000B'	
147	0000H	ICM3_S6	1	147	0000H	LITERALLY '0100#0000B'	
146	0000H	ICM3_S7	1	146	0000H	LITERALLY '1000#0000B'	
158	0000H	ICM4_S6	1	158	0000H	LITERALLY '0000#0001B'	262 267
157	0000H	ICM4_AE01	1	157	0000H	LITERALLY '0000#0010B'	262 267
155	0000H	ICM4_BUF	1	155	0000H	LITERALLY '0000#1000B'	
154	0000H	ICM4_FNM	1	154	0000H	LITERALLY '0001#0000B'	262 267
156	0000H	ICM4_MS	1	156	0000H	LITERALLY '0000#0100B'	
133	0000H	IL_KV	1	133	0000H	LITERALLY '6'	287
127	0000H	IL_PENR	1	127	0000H	LITERALLY '0'	
128	0000H	IL_PSWAP	1	128	0000H	LITERALLY '1'	
134	0000H	IL_PTR	1	134	0000H	LITERALLY '7'	
130	0000H	IL_S100	1	130	0000H	LITERALLY '3'	
131	0000H	IL_SER_A	1	131	0000H	LITERALLY '4'	
132	0000H	IL_SER_B	1	132	0000H	LITERALLY '5'	
129	0000H	IL_TIMER	1	129	0000H	LITERALLY '2'	
26	0000H	INCB	1	26	0000H	PROCEDURE EXTERNAL(2) STACK=0000H	
232	003CH	INIT	21	232	003CH	PROCEDURE PUBLIC STACK=0004H	
271	0034H	INIT_DS	8	271	0034H	STRUCTURE DATA	274
271	0000H	WIP	5	271	0000H	BYTE ARRAY(5)	
271	0005H	VERSION	1	271	0005H	BYTE	
231	0004H	DS_SIZE	2	231	0004H	WORD	
231	0000H	INITIAL_VECTORS	52	231	0000H	POINTER ARRAY(13) DATA	293
242	003CH	INIT	49	242	003CH	PROCEDURE STACK=0000H	
257	0051H	INIT_68A21	53	257	0051H	PROCEDURE STACK=0002H	233
272	0082H	INIT_8259_88	39	272	0082H	PROCEDURE PUBLIC STACK=0002H	235
37	00B7H	INIT_DATA_SEGMENT	77	37	00B7H	PROCEDURE STACK=0004H	234
280	0000H	INIT_IV	77	280	0000H	PROCEDURE EXTERNAL(6) STACK=0000H	236 284 285 287
280	000EH	INIT_TERMINAL	77	280	000EH	PROCEDURE STACK=0004H	236
290	012BH	INPUT	129	290	012BH	PROCEDURE STACK=0004H	237
118	0000H	ID_CRIC	1	118	0000H	BULFIN	307
98	0000H	ID_DIP	1	98	0000H	LITERALLY '00DCH'	
115	0000H	ID_GENERAL	1	115	0000H	LITERALLY '00FFH'	244 245 246 247 248 249 307
100	0000H	ID_HIADR	1	100	0000H	LITERALLY '00FDH'	
109	0000H	ID_INT_MS	1	109	0000H	LITERALLY '00F2H'	259 260 261 262 263

SERIES-111 PL/M-86 V2.0 COMPILATION OF MODULE FNCLIB
OBJECT MODULE PLACED IN :F2:FNCLIB.OBJ
COMPILER INVOKED BY: PLM86.86 :F2:FNCLIB.PLM CODE PRINT(:TO:)

```
1 $TITLE('MTR-101 Z-Machine Monitor ROM: Function Library')
  $SUBTITLE('Compiler Controls')
  $INCLUDE ('F2:COMMON.H')
  $SUBTITLE('Compiler Controls')
  $OPTIMIZE(3)
  $NOOVERFLOW
  $COMPACT
  $ROM
  $XREF
  $LARGE ( MTR100 EXPORTS MTR_MON;
  = EXPORTS MTR_MON;
  = EXPORTS MTR_SWIM;
  = EXPORTS MTR_DCRT;
  = EXPORTS MTR_DKED;
  = EXPORTS MTR_SCRIPT;
  = EXPORTS MTR_SKED;
  = EXPORTS MTR_TTY_INTR;
  = EXPORTS MTR_TTY_POLL;
  = EXPORTS MTR_IRET)
  $LARGE ( VIDEOA EXPORTS MTR_DC1;
  = EXPORTS MTR_DFC;
  = EXPORTS MTR_EDC;
  = EXPORTS MTR_FONT;
  = EXPORTS MTR_MIC;
  = EXPORTS MTR_MDL;
  = EXPORTS MTR_PROMPT;
  = EXPORTS MTR_RDG;
  = EXPORTS MTR_UES;
  = EXPORTS MTR_XCA)
  $LARGE ( FONT EXPORTS MTR_FONT)
  $LARGE ( ASTLIB EXPORTS VIDEO_INTR_A)
  $RESET(EXTENDED_MONITOR)
  $SUBTITLE('External Definitions')
  FNCLIB:
  DO;
  $INCLUDE ('F2:LEXCAL.H')
  $SAVE
  $NCLIST
  $INCLUDE ('F2:IODEF.H')
  $SAVE
  $NCLIST
  $INCLUDE ('F2:ASCII.H')
  $SAVE
  $NCLIST
  $INCLUDE ('F2:ASTLIB.H')
  $SAVE
  $NCLIST
```

```

/*
 * CRLF -- Carriage Return / Line-Feed
 *
 * 'CRLF' outputs a carriage-return/line-feed
 * sequence to the console.
 */
CRLF: PROCEDURE PUBLIC;
DO;
CALL WRITEC(CR);
IF NOT HI9_MODE.AUTO_LF THEN
CALL WRITEC(LF);
END;
183 1
184 2
185 3
186 3
187 3
188 3
189 2

```

```

/*
 * GFW -- Get Far Word
 *
 * GFW gets the specified word based on the supplied
 * paragraph/segment and offset.
 */
NOTE: The actual routine which performs the work
is contained in 'ASTLIB', the assembly lan-
guage assist library.
*
* Entry: base = paragraph/segment
* offset = Offset
*
* Exit: Returns WORD addressed by the base/offset pair
*/
$ IF 1=2

```

```

GFW: PROCEDURE(base,offset) WORD PUBLIC;
DECLARE base WORD,
offset WORD;
DO;
RETURN(GFB(base,offset)+SHL(GFB(base,offset+1),8));
END;
$ ENDIF

```

/*


```
* IF EXTENDED_MONITOR  
IHC: PROCEDURE(delim) BYTE PUBLIC;  
DECLARE delim BYTE;  
DECLARE C BYTE;  
  
DO;  
  C=MOU(READC);  
  DO WHILE (C<>delim) AND (C<>DEL) AND (C<>BS) AND (NOT VHC(C)) ;  
    CALL WRITC(BEL);  
  C=MOU(READC);  
  END;  
  RETURN(C);  
END;  
END;
```

```
* ENDIF  
*  
/* IHV -- Input Hex Value
```

```
* IHV inputs a hex value from the console. The  
* value is to be terminated by the supplied de-  
* limiter. Other interpretable characters are  
* DEL and BS. If DEL or BS are hit, the routine  
* returns immediately, otherwise, the value at  
* the supplied address is modified according to  
* the attribute specified. If 'size' is 1, then  
* a byte value is assumed. If 'size' is 2, then  
* a word value is assumed.
```

```
* NOTE: Delimiters which are valid hex characters  
* should be avoided, and that at least one  
* valid hex character is required before  
* the delimiter is accepted.
```

```
* Entry: delim = required value delimiter  
*          val$ = value pointer  
*          size = 1 for byte value, 2 for word value  
*  
* Exit: Returns the actual delimiter entered  
*        val$ modified if the terminating character  
*        was not 'delim'.  
*  
*/
```

```
* IF EXTENDED_MONITOR
```

```
IHV: PROCEDURE(delim, val$, size) BYTE PUBLIC;  
DECLARE delim BYTE,  
          val$ POINTER,  
          size BYTE;  
DECLARE C BYTE;
```

```

193 3 IF 'a' <= char AND char <= 'z'
      THEN
194 3 RETURN (char-'a'+'A');
195 3 ELSE
196 3 RETURN (char);
197 2 END;
    
```

```

/*
*
* OHB outputs a hex byte to the console.
*
* Entry: dat = byte value to output
*
* Exit: NONE
*
*/
    
```

```

$ IF EXTENDED_MONITOR
OHB: PROCEDURE(dat) PUBLIC;
DECLARE dat BYTE;

DO;
CALL OHC(SHR(dat,4));
CALL OHC(dat AND 00FH);
END;
ENDIF
    
```

```

/*
* OHC -- Output Hex Character
*
* OHC outputs a hex character to the console.
* This routine must be called carefully, as
* the data supplied is not checked for valid-
* ity.
*
* Entry: dat = Binary value to output the hex character for
*
* Exit: NONE
*
*/
    
```

```

$ IF EXTENDED_MONITOR
OHC: PROCEDURE(dat) PUBLIC;
DECLARE dat BYTE;
    
```

```

*
* WRITES outputs a string of text to the console.
* This is accomplished by outputting the bytes spec-
* ified by the supplied string pointer, until a
* terminating byte is found. A terminator is any
* byte with the MSB set.
*
* WRITEC is invoked for the console output.
*
* Entry: string#p = pointer to terminated byte string
*
* Exit: NONE
*
*/
WRITEC:
    PROCEDURE(string#p)
    PUBLIC:
    POINTER;
    INTEGER;
    BYTE;
213 1 1 WRITES:
214 2 2 DECLARE string#p
215 2 2 DECLARE I
        STRING BASED string#p(1)
        IF 0=1
        DO;
        I = 0;
        DO WHILE (STRING(I) AND EOL)=0 ;
            CALL WRITEC(STRING(I));
            I = I + 1;
        END;
        CALL WRITEC(STRING(I) AND 07FH);
        END;
        ELSE
        DO;
        I = -1;
        WRITES1:
        DO;
            I = I+1 ;
            CALL WRITEC(STRING(I));
            IF (STRING(I) AND EOS)=0 THEN
                GO TO WRITES1;
            END;
        ENDIF
        END;
225 2 2 END;
226 1 1 END;
    
```

```

0046 8BEC      MOV      BP,SP      ; STATEMENT # 201
0048 E80000    CALL     READK
004B A20200    MOV      T,AL      ; STATEMENT # 202
004E B1B0      MOV      CL,@B0H
0050 3AC8      CMP      CL,AL
0052 7704      JA       @5
0054 3CB9      CMP      AL,@B7H
0056 760F      JBE      @6
0058 A00200    @5:  MOV      AL,T
005B 3C8D      CMP      AL,8DH
005D 7408      JZ       @6
005F 3CAD      CMP      AL,@ADH
0061 7404      JZ       @6
0063 3CAE      CMP      AL,@AEH
0065 7505      JNZ      @4
0067 80260207F AND     T,7FH      ; STATEMENT # 203
006C A00200    @4:  MOV      AL,T
006F 5D       POP      BP
0070 C3       RET

0071 55       WRITTEC  PROC NEAR
0072 8BEC      MOV      BP,SP      ; STATEMENT # 210
0074 FF7604    PUSH     [BP],CHAR; 1
0077 E80000    CALL     S_CRT      ; STATEMENT # 212
007A 5D       POP      BP
007B C20200    RET      2H        ; STATEMENT # 213
007E 55       WRITES  PROC NEAR
007F 8BEC      MOV      BP,SP
0081 C706000FFF MOV     I,0FFFFH  ; STATEMENT # 217
0087 A10000    MOV      AX,I      ; STATEMENT # 219
008A 40       INC     AX
008B A30000    MOV      I,AX
008E 89C6      MOV      SI,AX      ; STATEMENT # 220
0090 C4E04     LES     BX,[BP],STRNGP
0093 26FF30    PUSH    ES:[BX],STRNGCSI
0096 E8DBFF    CALL    WRITTEC    ; STATEMENT # 221
    
```

CROSS-REFERENCE LISTING

DEFN	ADDR	SIZE	NAME, ATTRIBUTES, AND REFERENCES
34	0000H	1	BEL.
107	0000H	1	BILL.
4	0000H	1	BOOL.
87	0000H	83	BOOT_PAR
	0000H	1	INDEX.
	0001H	1	PORT.
	0002H	80	STRING.
	0052H	1	UNIT.
35	0000H	1	BS.
108	0000H	1	BSTL.
54	0000H	4	BYTEPTR.
57	0000H	1	C.
49	0000H	1	C.
36	0004H	1	CAN.
191	0004H	1	CHAR.
208	0004H	1	CHAR.
123	0000H	1	CHAR.
180	0000H	1	CMND.
81	0000H	1	CODE_SEQ.
126	0000H	1	COL.
115	0000H	7	COLOR.
	0000H	1	FORE.
	0001H	1	BACK.
	0002H	1	MASK.
	0003H	1	CLEAR.
	0004H	1	PAINTED.
	0005H	1	FONT.
	0006H	1	COMP_FONT.
37	0010H	24	CR.
183	0000H	3	CRLE.
116	0000H	2	CRTC_CURSOR.
	0000H	3	START.
	0002H	1	UPDATE.
117	0000H	3	CRTC_DISPLAY.
	0000H	2	START.
	0002H	1	UPDATE.
2		1	DC.
125	0000H	4	DCA.
88	0000H	4	DCL.
38			DEL.
89	0000H	4	DFC.

LITERALLY '007H'									
BYTE EXTERNAL(30)									
LITERALLY 'BYTE'	111	116	117	119	121	174	175		
STRUCTURE EXTERNAL(10)									
BYTE									
BYTE									
BYTE ARRAY(80)									
BYTE									
LITERALLY '008H'									
BYTE EXTERNAL(31)									
POINTER IN PROC (INCB) PARAMETER									
BYTE IN PROC (SXMTD) PARAMETER									
BYTE IN PROC (DXMTD) PARAMETER									
LITERALLY '018H'									
BYTE IN PROC (MCU) PARAMETER AUTOMATIC									
BYTE IN PROC (WRITD) PARAMETER AUTOMATIC									
BYTE IN PROC (S CRT) PARAMETER									
BYTE IN PROC (WRITK) PARAMETER									
LITERALLY '0FE0SH'									
BYTE IN PROC (DCA) PARAMETER									
STRUCTURE EXTERNAL(35)									
BYTE									
BYTE									
BYTE									
BYTE									
BYTE									
LITERALLY '00DH'									
PROCEDURE PUBLIC STACK=0006H									
STRUCTURE EXTERNAL(36)									
WORD									
BYTE									
STRUCTURE EXTERNAL(37)									
WORD									
BYTE									
LITERALLY 'DECLARE'									
10	11	12	13	14	15	16	17	18	19
22	23	24	25	26	27	28	29	30	31
34	35	36	37	38	39	40	41	42	43
46	46	67	68	69	70	71	72	73	74
77	78	79	80	81	82	83	84	85	86
89	90	91	92	93	94	95	96	97	98
101	102	103	104	105	106	107	108	109	110
113	114	115	116	117	118	119	120	137	138
141	142	143	144	145	146	147	148	149	150
153	154	155	156	157	158	159	160	161	162
165	166	167	168	169	170	171	172	173	

182	000001H	16	HEX_DIGIT.	BYTE ARRAY(16) PUBLIC DATA			
105	000001H	1	HORZ_CHAR.	BYTE EXTERNAL(28)			
43	000003H	1	VRAM_SIZE.	BYTE			
215	000004H	2	I.	INTEGER IN PROC (WRITES)	217*	219*	219 220 221
53	000001H		INCB . . .	PROCEDURE EXTERNAL(2) STACK=0000H			
64	000001H		INIT_ITV . . .	PROCEDURE EXTERNAL(6) STACK=0000H			
27			IO_CRTC . . .	LITERALLY '00DCH'			
7			IO_DIP . . .	LITERALLY '00FFH'			
24			IO_GENERAL . . .	LITERALLY '00E0H'			
9			IO_HIADR . . .	LITERALLY '00F0H'			
18			IO_INT_MS . . .	LITERALLY '00F2H'			
19			IO_INT_SL . . .	LITERALLY '00F0H'			
17			IO_KEYBRD . . .	LITERALLY '00F4H'			
26			IO_LFPN . . .	LITERALLY '00DEH'			
10			IO_MEM . . .	LITERALLY '00FCH'			
23			IO_PRINTER . . .	LITERALLY '00E2H'			
12			IO_RSRV_1 . . .	LITERALLY '00FAH'			
14			IO_RSRV_2 . . .	LITERALLY '00F3H'			
15			IO_RSRV_3 . . .	LITERALLY '00F7H'			
16			IO_RSRV_4 . . .	LITERALLY '00F6H'			
25			IO_RSRV_5 . . .	LITERALLY '00DFH'			
29			IO_RSRV_6 . . .	LITERALLY '00C0H'			
21			IO_SER_A . . .	LITERALLY '00E3H'			
20			IO_SER_B . . .	LITERALLY '00E3H'			
13			IO_SOUND . . .	LITERALLY '00F9H'			
8			IO_SWAP . . .	LITERALLY '00E4H'			
22			IO_TIMER . . .	LITERALLY '00FBH'			
11			IO_TSTAT . . .	LITERALLY '00D8H'			
28			IO_VIDEO . . .	LITERALLY '00B0H'			
31			IO_Z207_0 . . .	LITERALLY '00A8H'			
30			IO_Z207_1 . . .	LITERALLY '00A8H'			
33			IO_Z217_0 . . .	LITERALLY '00A8H'			
32			IO_Z217_1 . . .	LITERALLY '00A8H'			
65	000001H	1	IVI . . .	BYTE IN PROC (INIT_ITV) PARAMETER			65
65	000001H	4	IVP . . .	POINTER IN PROC (INIT_ITV) PARAMETER			65
143			KC_ARF . . .	LITERALLY '02H'			
144			KC_ARO . . .	LITERALLY '01H'			
145			KC_BEP . . .	LITERALLY '07H'			
150			KC_CFI . . .	LITERALLY '05H'			
151			KC_CLK . . .	LITERALLY '06H'			
146			KC_DI . . .	LITERALLY '0DH'			
147			KC_ET . . .	LITERALLY '0CH'			
152			KC_KBD . . .	LITERALLY '09H'			
153			KC_KBE . . .	LITERALLY '08H'			
148			KC_KCF . . .	LITERALLY '04H'			
149			KC_KCO . . .	LITERALLY '03H'			
154			KC_MNS . . .	LITERALLY '0BH'			
155			KC_MUD . . .	LITERALLY '0AH'			

214	00004H	4	SIRNGP	214	220	221
56	00000H		SXMTG.			
122	00000H		S_CRT.			
98	00000H	4	S_XMTC	210		
179	00020H	1	T.	201*	202	203
136	00000H		TESTK.			204
175	00000H		TRUE			
6	00000H	4	UIES			
97	00000H	52	VECTORS.			
101	00000H	1	VERSION.			
85	00000H	1	VERT_LINE.			
106	00000H	1	VIDEO_INTR_A			
59	00000H		VT			
45	00000H	5	WIP.			
84	00000H	13	WRITEC		185	187
207	00710H	44	WRITES.		220	
213	007EH		WRITES1.			
179	00000H		WRITEK.			
100	00000H	4	XCA.			
114			XCOLOR_BACK.			
113			XCOLOR_FORE.			
61	00000H		XEC.			
121	00000H	10	XMT.			
	00000H	1	BURST.			
	00010H	2	BCOUNT.			
	00030H	2	COUNT.			
	00050H	1	COL.			
	00060H	1	ROW.			
	00070H	1	COLOR.			
	00080H	1	GRAPHIC.			
	00090H	1	REVERSE.			
46			XOFF.			
47			XON.			
112			XREVERSE			

MODULE INFORMATION:

CODE AREA SIZE = 000AAH 170D
 CONSTANT AREA SIZE = 00000H 0D
 VARIABLE AREA SIZE = 00030H 3D
 MAXIMUM STACK SIZE = 00100H 16D
 1125 LINES READ
 0 PROGRAM WARNINGS
 0 PROGRAM ERRORS

END OF PL/M-86 COMPILATION

```
/*  
* I2661  
* * I2661 initializes the specified 2661 EPCI.  
* *  
* * Entry: base = Base address of port  
* * Exit: NONE  
* */
```

```
$ IF EXTENDED_MONITOR  
I2661: PROCEDURE(base) PUBLIC;  
DECLARE base WORD;
```

```
DO;  
OUTPUT(0EAH)=04EH;  
OUTPUT(0EAH)=05DH;  
OUTPUT(0EBH)=027H;  
END;  
ENDIF
```

```
/*  
* RCHAR  
* * RCHAR returns a character from the specified EPCI.  
* * RCHAR waits for the character task-time.  
* *  
* * Entry: byte = The base address of the EPCI  
* * Exit: Byte returned, with the parity bit stripped  
* */
```

```
$ IF EXTENDED_MONITOR  
RCHAR: PROCEDURE(base) BYTE PUBLIC;  
DECLARE base WORD;
```

```
DO;  
DO WHILE NOT TCHAR(base) ;  
END;  
RETURN (INPUT(0EBH) AND 07FH);  
END;
```



```
MOCHAR: PROCEDURE(base, char) PUBLIC:
DECLARE base WORD,
char BYTE;
00;
OUTPUT(0ESH+3)=INPUT(0ESH+3) OR 1;
DO WHILE (INPUT(0E9H) AND @01H)=0;
END;
OUTPUT(0E9H)=char;
END;
* ENDF
7 1 END;
```

DEFN ADDR SIZE NAME, ATTRIBUTES, AND REFERENCES

DEFN	ADDR	SIZE	NAME, ATTRIBUTES, AND REFERENCES
4			BOOL LITERALLY 'BYTE'
2			DC LITERALLY 'DECLARE'
5	0000H		FALSE LITERALLY '000H'
3			IOLIB. PROCEDURE STACK=0000H
6			LI LITERALLY 'LITERALLY'
			TRUE LITERALLY '0FFH'

MODULE INFORMATION:

CODE AREA SIZE = 0000H 0D
 CONSTANT AREA SIZE = 0000H 0D
 VARIABLE AREA SIZE = 0000H 0D
 MAXIMUM STACK SIZE = 0000H 0D
 191 LINES READ
 0 PROGRAM WARNINGS
 0 PROGRAM ERRORS

END OF PL/M-86 COMPILATION


```
76 1 READK: PROCEDURE BYTE PUBLIC;  
77 2 DECLARE C BYTE;  
78 3 DO;  
79 4 DO WHILE NOT TESTK ;  
80 5 END;  
81 6 DISABLE;  
82 7 IF KEY.AVAIL  
83 8 THEN  
84 9 DO;  
85 10 C=KEY.CHAR;  
86 11 KEY.AVAIL=FALSE;  
87 12 END;  
88 13 ELSE  
89 14 C=INPUT(KEY..DATA);  
90 15 ENABLE;  
91 16 RETURN(C);  
END;
```

*REJECT

```

; STATEMENT # 6
; STATEMENT # 33
; STATEMENT # 69
; STATEMENT # 71
; STATEMENT # 73
; STATEMENT # 75
; STATEMENT # 76
; STATEMENT # 79
; STATEMENT # 81
; STATEMENT # 82
; STATEMENT # 84
; STATEMENT # 85
; STATEMENT # 87
; STATEMENT # 88
; STATEMENT # 89
; STATEMENT # 91
; STATEMENT # 92

```

TESTK PROC NEAR

0000 55
 0001 8BEC

PUSH BP
 MOV BP,SP

; STATEMENT # 73

0003 E4F5
 0005 2401
 0007 08C0
 0009 B0FF
 000B 7501
 000D 40
 000E 0A060100
 0012 5D
 0013 C3

IN 0FSH
 AND AL,1H
 OR AL,AL
 MOV AL,0FFH
 JNZ \$+3H
 INC AX
 OR AL,KEY+1H
 POP BP
 RET

; STATEMENT # 75

TESTK ENDP

READK

0014 55
 0015 8BEC

PROC NEAR
 PUSH BP
 MOV BP,SP

; STATEMENT # 76

@1:

0017 E8E6FF
 001A D0D8
 001C 73F9

CALL TESTK
 RCR AL,1
 JNB @1

; STATEMENT # 81

001E FA

CLI

; STATEMENT # 82

001F A00100
 0022 D0D8
 0024 730D

MOV AL,KEY+1H
 RCR AL,1
 JNB @3

; STATEMENT # 84

0026 A00000
 0029 A20200

MOV AL,KEY
 MOV C,AL

; STATEMENT # 85

002C C606010000
 0031 EB05

MOV KEY+1H,0H
 JMP @4

; STATEMENT # 87

0033 E4F4
 0035 A20200

IN 0F4H
 MOV C,AL

; STATEMENT # 88

@4:

0038 FB

STI

; STATEMENT # 89

0039 A00200
 003C 5D
 003D C3

MOV AL,C
 POP BP
 RET

; STATEMENT # 91

READK ENDP

; STATEMENT # 92

003E 55

WRITK PROC NEAR
 PUSH BP

CROSS-REFERENCE LISTING

DEFN ADDR SIZE NAME, ATTRIBUTES, AND REFERENCES

DEFN	ADDR	SIZE	NAME, ATTRIBUTES, AND REFERENCES
4	0002H	1	BOOL LITERALLY 'BYTE'
77	0004H	1	C BYTE IN PROC (READK)
93	0004H	1	CMND BYTE IN PROC (WRITK)
2			DC LITERALLY 'DECLARE'
			10 11 12 13 14 15 16 17 18 19 20 21
			22 23 24 25 26 27 28 29 30 31 32
			34 35 36 37 38 39 40 41 42 43 44 45
			46 47 48 49 50 51 52 53 54 55 56 57
			58 59 60 61 62 63 64 65 66 67 68 69
5			FALSE LITERALLY '000H'
27			INPUT BULLTIN
7			IO_CRIC LITERALLY '00DCH'
24			IO_DIP LITERALLY '00FH'
9			IO_GENERAL LITERALLY '00E0H'
18			IO_HIADR LITERALLY '00FDH'
19			IO_INIT_MS LITERALLY '00F2H'
17			IO_INT_SL LITERALLY '00F0H'
26			IO_KEYERD LITERALLY '00F4H'
10			IO_LFPN LITERALLY '00DEH'
23			IO_MEM LITERALLY '00FCH'
12			IO_PRINTER LITERALLY '00E2H'
14			IO_RSRV_1 LITERALLY '00FAH'
15			IO_RSRV_2 LITERALLY '00F3H'
16			IO_RSRV_3 LITERALLY '00F7H'
25			IO_RSRV_4 LITERALLY '00F6H'
29			IO_RSRV_5 LITERALLY '00C0H'
21			IO_RSRV_6 LITERALLY '00E8H'
20			IO_SERV_A LITERALLY '00E9H'
13			IO_SERV_B LITERALLY '00E7H'
8			IO_SOUND LITERALLY '00F9H'
22			IO_SWAP LITERALLY '00E4H'
11			IO_TIMER LITERALLY '00FBH'
28			IO_VSTAT LITERALLY '00B3H'
31			IO_VIDEO LITERALLY '00B0H'
30			IO_ZZ07_0 LITERALLY '00B3H'
33			IO_ZZ07_1 LITERALLY '00B3H'
32			IO_ZZ17_0 LITERALLY '00A8H'
39			IO_ZZ17_1 LITERALLY '00A8H'
40			KC_ANF LITERALLY '02H'
41			KC_AR0 LITERALLY '01H'
46			KC_REP LITERALLY '07H'
47			KC_CFI LITERALLY '05H'
42			KC_CLK LITERALLY '06H'
43			KC_DI LITERALLY '0DH'
48			KC_KBD LITERALLY '0CH'
49			KC_KBE LITERALLY '09H'
44			KC_KCF LITERALLY '08H'
45			KC_KCO LITERALLY '04H'
50			KC_MNS LITERALLY '03H'
51			KC_MUD LITERALLY '0AH'
52			KC_RES LITERALLY '00H'

SERIES-III PL/M-86 V2.0 COMPILATION OF MODULE SUBLIB
 OBJECT MODULE PLACED IN :F2:SUBLIB.OBJ
 COMPILER INVOKED BY: PLM86.86 :F2:SUBLIB.PLN CODE PRINT(:TO:)

```

1
$TITLE('MIR-101 Z-Machine Monitor ROM: Subroutine Library')
$SUBTITLE('Compiler Controls')
$INCLUDE('F2:COMMON.H')
$SUBTITLE('Compiler Controls')
$OPTIMIZE(3)
$NOOVERFLOW
$COMPACT
$FROM
$XREF
$LARGE(MTR100 EXPORTS MTR_MON;
EXPORTS MTR_MON;
EXPORTS MTR_SWIM;
EXPORTS MTR_DCRT;
EXPORTS MTR_DKRD;
EXPORTS MTR_SCRT;
EXPORTS MTR_SKED;
EXPORTS MTR_TTY_INTR;
EXPORTS MTR_TTY_POLL;
EXPORTS MTR_IRET)
$LARGE(VIDEQA EXPORTS MTR_DC1;
EXPORTS MTR_DFC;
EXPORTS MTR_EDC;
EXPORTS MTR_FONT;
EXPORTS MTR_MDC;
EXPORTS MTR_MDL;
EXPORTS MTR_PROMPT;
EXPORTS MTR_RDC;
EXPORTS MTR_LIES;
EXPORTS MTR_XCA)
$LARGE(FONT EXPORTS MTR_FONT)
$LARGE(ASTLIB EXPORTS VIDEO_INTR_A)
$RESET(EXTENDED_MONITOR)
$SUBTITLE('Definitions')
SUBLIB:
DU;
$INCLUDE('F2:LEXCAL.H')
$SAVE
$NOLIST
$INCLUDE('F2:STRUCT.H')
$SAVE
/*
* STRUCT.H
*
* This file defines all of the structures for
* MIR-100.
*

```

```

/*
**      IHA      -- Input Hex Address
**
**      IHA inputs a hex address from the console. The
**      format enforced is:
**
**      nnnn:mmm
**
**      where 'nnnn' is the paragraph, and 'mmm' is the
**      offset within the paragraph.
**
**      NOTE: Any partially entered address may result
**      in partially modified parameters. Further...
**      more, the same cautions about 'delim' as
**      outlined in 'IHV()' apply since 'IHV()' is
**      invoked.
**
**      Entry:  delim = Required delimiter
**             addr$* = Pointer to address structure
**
**      Exit:   Returns actual delimiter
**
**      */
$      IF EXTENDED_MONITOR
IHA:
  DECLARE  delim      BYTE,
           addr$*     POINTER;
  DECLARE  DELIMITER  BYTE,
           I          BYTE,
           ADDR_     BASED addr$*  ADDR;
  BYTE PUBLIC;
DO:
  I=0;
  DO WHILE 0=0 ;
    IF I=0
      THEN
        DO:
          DELIMITER=IHV(';',@ADDR_+BASE,2);
          IF DELIMITER<>';' THEN
            RETURN(DELIMITER);
          I=I+1;
        ELSE
          DO:
            CALL WRITEC(DELIMITER);
            DELIMITER=IHV(';',@ADDR_+OFFS,2);
            IF DELIMITER<>';' THEN
              THEN
                DO:
                  CALL RUBOUT;

```



```

$      IF EXTENDED_MONITOR
      DECLARE REG_SPEC (*) BYTE DATA
      ( 'ESSSDSDISIPSPDXCXBAXI'PCSF1DLDHCLCHBLHALAH' );
/*
*      IRI      - Input Register Identifier
*      *      IRI inputs a valid register name, and returns the
*      *      appropriate Index into the register structure.
*      *      Entry: NONE
*      *      Exit: Returns -1 for delete or back-space, other wise
*      *      register index into structure.
*      */

IRI:
DECLARE      PROCEDURE      BYTE,      BYTE PUBLIC;
              C              BYTE,
              C1             BYTE,
              I              BYTE,
              J              BYTE,
              MATCH         BYTE,
              PTR           BYTE;

      DO;
      I = 0 ;
      DO WHILE 0=0 ;
      IF I<2 THEN
      C = MCU(READC);
      IF I=0 AND (C=DEL OR C=RS) THEN
      RETURN(-1);
      ELSE IF C=DEL OR C=RS THEN
      DO;
      CALL RUBOUT;
      I = I - 1;
      END;
      ELSE IF I=0 THEN
      DO;
      MATCH = 0 ;
      DO J=0 TO LENGTH(REG_SPEC)--2 BY 2 ;
      IF C = REG_SPEC(J) THEN
      DO;
      MATCH = MATCH + 1 ;
      PTR = J ;
      END;
      IF MATCH = 0 THEN
      CALL WRITEC(BEL);
      ELSE IF MATCH = 1 THEN
      DO;
      CALL WRITEC(C);
      C1 = C ;
      
```

```

/*
 *
 * OHA      -- Output Hex Address
 *
 * OHA outputs the specified hex address in the same
 * format specified input by 'IHA()':
 *
 *      nnnn:mmm
 *
 * where 'nnnn' is the segment, and 'mmm' is the
 * offset within the segment.
 *
 * Entry:  addr$P = Pointer to address structure
 *
 */

```

```

$
  IF EXTENDED_MONITOR
    OHA:
      PROCEDURE(addr$P)      PUBLIC;
      DECLARE   addr$P      POINTER;
      DECLARE   ADDR_       BASED addr$P  ADDR;
      DO;
        CALL OHM(ADDR_+BASE);
        CALL WRITEC('?');
        CALL OHM(ADDR_+OFFS);
      END;
  END;
$
  ENDIF

```

```

/*
 *
 * RNC      -- Require Next Character
 *
 * RNC requires the next character from the input device
 * to be the specified one. If the character is DEL or
 * BS, RNC returns this character as the delimiter. If
 * the character is any character besides the specified
 * delimiter, RNC outputs a bell, and waits.
 *
 * Entry:  delim = Character required
 *
 * Exit:   Returns the delimiter actually read as a BYTE
 *
 */

```

```

$
  IF EXTENDED_MONITOR
    RNC:
      PROCEDURE(delim)      BYTE PUBLIC;
      DECLARE   delim      BYTE;
      DECLARE   C           BYTE;

```

```
/*  
* RUBOUT ... Rub out a character  
*  
* RUBOUT rubs out a character currently displayed on  
* the screen. This is done by simply outputting a  
* backspace, space, and backspace.  
*  
* Entry: NONE  
*  
* Exit: NONE  
*  
*/
```

```
* IF EXTENDED_MONITOR  
RUBOUT: PROCEDURE PUBLIC;  
DO;  
CALL WRITES(@CS, ' ', BSHEOS);  
END;  
END;  
* ENDIF
```

36 1 END;

CROSS-REFERENCE LISTING

DEFN	ADDR	SIZE	NAME, ATTRIBUTES, AND REFERENCES
7	00000H		ADDR
8	00000H		BEQ
4	00000H		BEQ
9	00000H		BEQ
10	00000H		CAN
26	00000H	1	CHAR
31	00000H	1	CHAR
11	00000H		CR
23	00000H		CRLF
2	00000H		DC
12	00000H		DEL
13	00000H		EDL
14	00000H		EDS
15	00000H		ESC
5	00000H		FALSE
16	00000H		FF
22	00000H		HEX_DIGIT
17	00000H		HT
18	00000H		LF
3	00000H		LT
25	00000H		MCU
28	00000H		READC
34	00000H	4	STRNGP
6	00000H		SUBLIB
19	00000H		TRUE
30	00000H		VT
33	00000H		WRITEC
20	00000H		WRITES
21	00000H		XOFF
			XON

MODULE INFORMATION:

CODE AREA SIZE = 00000H 0D
 CONSTANT AREA SIZE = 00000H 0D
 VARIABLE AREA SIZE = 00000H 0D
 MAXIMUM STACK SIZE = 00000H 0D
 501 LINES READ
 0 PROGRAM WARNINGS
 0 PROGRAM ERRORS

END OF PL/M-86 COMPILATION

```

=      $      $      INCLUDE ('F2:COLORS.H')
=      $SAVE
=      $NQLIST
=      $      INCLUDE ('F2:CRTC.H')
=      $SAVE
=      $NQLIST
=      $      INCLUDE ('F2:DIPDEF.H')
=      $SAVE
=      $NQLIST
=      $      INCLUDE ('F2:FNCLIB.H')
=      $SAVE
=      $NQLIST
=      $      INCLUDE ('F2:GLOBAL.H')
=      $SAVE
=      $NQLIST
=      $      INCLUDE ('F2:H19CRT.H')
=      $SAVE
=      $NQLIST
=      $      INCLUDE ('F2:I8086.H')
=      $SAVE
=      $NQLIST
=      $      INCLUDE ('F2:ITCDEF.H')
=      $SAVE
=      $NQLIST
=      $      INCLUDE ('F2:KEYDEF.H')
=      $SAVE
=      $NQLIST
=      $      INCLUDE ('F2:KEYLIB.H')
=      $SAVE
=      $NQLIST
=      $      INCLUDE ('F2:MISC.H')
=      $SAVE
=      $NQLIST
=      $      INCLUDE ('F2:MTR100.H')
=      $SAVE
=      $NQLIST
=      $      INCLUDE ('F2:P6821.H')
=      $SAVE
=      $NQLIST
=      $SUBTITLE('Global Declarations')
```

```

/*
 *
 * INIT_VIDEO      -- Initialize Video
 *
 * INIT_VIDEO initializes the video parameters. Initially,
 * the CRT-C parameters are set. Then the 6821 controlling
 * access to the video command bits is initialized. The
 * 6821's must be carefully initialized to avoid accidentally
 * 'glitching' the screen. Then, the Video RAM Mapping Mod-
 * ule is initialized. Since it only controls access to the
 * pages of video RAM from the CPU, one need not take as much
 * care in the initialization.
 *
 * If the first byte of the blue page is modifiable, then
 * it is assumed that all of the color planes are present,
 * and update from all of the planes is enabled, otherwise,
 * only the green plane is enabled (though the multiple-write
 * bits for all planes are set.
 *
 * Entry:  NONE
 * Exit:   NONE
 */
INIT_VIDEO:
DO;
DECLARE
  I          I          BYTE,
  P1#PTR    P1#PTR    POINTER,
  P1         P1         BASED P1#PTR  BYTE,
  P2#PTR    P2#PTR    POINTER,
  P2         P2         BASED P2#PTR  BYTE,
  P3         P3         BASED P1#PTR(1) BYTE,
  T1        T1        BYTE,
  T2        T2        BYTE;
PROCEDURE;
/*
 * Initialize CRT-Controller, and sub-system
 */
IF (INPUT(IO_DIP) AND DIP_50HZ) <> 0
THEN
  P1#PTR=@CRTC_REG_50(0);
ELSE
  P1#PTR=@CRTC_REG_60(0);
DO I=0 TO 15;
  CALL UCOR(I,P3(I));
END;
CALL 16821;
OUTPUT(VRMM_DAT)=0;
/*
 * Initialize Terminal Emulation Parameters
 */

```

330 1 INIT_VIDEO: PROCEDURE;
 331 DO;
 332 DECLARE

I I BYTE,
 P1#PTR P1#PTR POINTER,
 P1 P1 BASED P1#PTR BYTE,
 P2#PTR P2#PTR POINTER,
 P2 P2 BASED P2#PTR BYTE,
 P3 P3 BASED P1#PTR(1) BYTE,
 T1 T1 BYTE,
 T2 T2 BYTE;

333 3
 334 3 P1#PTR=@CRTC_REG_50(0);
 335 3 ELSE
 336 3 P1#PTR=@CRTC_REG_60(0);
 337 4 DO I=0 TO 15;
 338 4 CALL UCOR(I,P3(I));
 339 3 END;
 340 3 CALL 16821;
 340 3 OUTPUT(VRMM_DAT)=0;

/*
 * Initialize Terminal Emulation Parameters
 */

```

/*
 * 16821
 *
 * '16821' initializes the both ports of the
 * 6821 used primarily for video applications.
 * Port A is used for video commands, and Port
 * B is used for the Video RAM Mapping Module
 * offset.
 *
 */
16821: PROCEDURE;
DO;
  /* Initialize CA2 for input, and access peripheral register A */
  OUTPUT(VID_CDC)=(P6821_ORA OR P6821_C2_1 OR P6821_C2_0);
  /* Clear peripheral reg. to reset condition, all signals active low */
  OUTPUT(VID_CMD)=0FFH;
  /* Initialize Data Direction Register CA2 for output, and */
  /* Data Direction Register A access */
  OUTPUT(VID_CDC)=(P6821_C2_2 OR P6821_C2_1 OR P6821_C2_0);
  /* Set all bits for output */
  OUTPUT(VID_CDD)=0FFH;
  /* Set access to peripheral register A */
  OUTPUT(VID_CDC)=(P6821_C2_2 OR P6821_C2_1 OR P6821_C2_0 OR P6821_ORA);
  /* Set data direction for all lines as output */
  OUTPUT(VRMM_MPC)=0;
  OUTPUT(VRMM_MPD)=0FFH;
  /* Set access to peripheral register B and zero adder */
  OUTPUT(VRMM_MPC)=(P6821_ORA OR P6821_C2_2 OR P6821_C2_1 OR P6821_C2_0);
  OUTPUT(VRMM_DAT)=0;
END;
383: 2
384: 3

```

REJECT

```

402 1 TTY_INTR: PROCEDURE PUBLIC;
403 2 DECLARE TEMP BYTE,
404 2 DO; TFLAGS WORD;
405 3 TFLAGS = FLAGS; /* Save Current Processor Flags
406 3 DISABLE; /* Disable ALL Interrupts */
/*
/* Update the CRT-C Display Start Address
*/
IF CRTC_DISPLAY.UPDATE THEN
DO;
OUTPUT(CRTC_RSEL)=CR_DSARH;
OUTPUT(CRTC_RVAL)=HIGH(CRTC_DISPLAY.START);
OUTPUT(CRTC_RSEL)=CR_DSAL;
OUTPUT(CRTC_RVAL)=LOW(CRTC_DISPLAY.START);
CRTC_DISPLAY.UPDATE=FALSE;
END;
/*
/* Update the CRT-C Cursor Start Address
*/
IF CRTC_CURSOR.UPDATE THEN
DO;
OUTPUT(CRTC_RSEL)=CR_CSARH;
OUTPUT(CRTC_RVAL)=HIGH(CRTC_CURSOR.START);
OUTPUT(CRTC_RSEL)=CR_CSAL;
OUTPUT(CRTC_RVAL)=LOW(CRTC_CURSOR.START);
CRTC_CURSOR.UPDATE=FALSE;
END;
/*
/* Transmit any required characters
*/
IF XMT.COUNT <> 0 THEN
DO;
XMT.BCOUNT = XMT.BCOUNT + INT(XMT.BURST);
DO WHILE XMT.BCOUNT > 0 AND XMT.COUNT <> 0 ;
CALL XCA;
XMT.COUNT = XMT.COUNT - 1;
XMT.COL = XMT.COL + 1;
IF XMT.COL = HI9_PAR.CPL THEN
DO;
XMT.COL = 0;
XMT.ROW = XMT.ROW + 1;
END;
END;
IF XMT.COUNT = 0 THEN
CALL S%XMT(CR);
END;
423 3
424 3
425 4
426 4
427 5
428 5
429 5
430 5
431 5
432 6
433 6
434 6
435 5
436 4
437 4
438 4
422 4
421 4
418 4
417 4
416 3
415 3
414 4
413 4
412 4
411 4
410 4
409 4
408 3
407 3

```



```

443 1      TTY_POLL;      PROCEDURE      BOOL PUBLIC;
444 2      RETURN(CRTC_CURSOR.UPDATE OR CRTC_DISPLAY.UPDATED);
445 2      END;

446 1      D_TTY_RES;      PROCEDURE      PUBLIC;
447 2      DECLARE      TFLAGS      WORD;
448 2      DO;
      /* Disable VSYNC, Keyboard, and Light-Pen Interrupts
      */
449 3      TFLAGS = FLAGS;
450 3      DISABLE;
451 3      OUTPUT(M_ITC_1)=INPUT(M_ITC_1) OR OCW1_M6;
452 3      IF (TFLAGS AND F86_IF) <> 0 THEN
453 3      ENABLE;
      /* Initialize Dumb Terminal Sub-system
      */
454 3      CALL INIT_VIDEO;
455 3      CALL D_TTY_INIT;
      /*
      * Re-Enable VSYNC, Keyboard, and Light-Pen Interrupts
      */
456 3      TFLAGS = FLAGS;
457 3      DISABLE;
458 3      OUTPUT(M_ITC_1) = INPUT(M_ITC_1) AND (NOT OCW1_M6);
459 3      IF (TFLAGS AND F86_IF) <> 0 THEN
460 3      ENABLE;
461 3      END;
462 2      END;
  
```

* EJECT

```
499 1 D_KBD; PROCEDURE(C) PUBLIC;  
500 2 DECLARE C BYTE;  
501 3 DO;  
502 3 CALL D$XMT(C(KMAP(C)));  
503 3 END;  
504 2 END;
```

\$EJECT

```
534 3 IF (CA AND (XCOLOR_FORE OR XCOLOR_BACK)) <> XMT.COLOR THEN
535 3 DO:
536 4 XMT.COLOR = CA AND (XCOLOR_FORE OR XCOLOR_BACK);
537 4 CALL TXMTC(ESC);
538 4 CALL TXMTC('m');
539 4 CALL TXMTC('0'+(CA AND XCOLOR_FORE));
540 4 CALL TXMTC('0'+SHR(CA AND XCOLOR_BACK,3));
541 4 END;
542 3 IF ((DEL-'')<C) AND XMT.GRAPHIC
543 3 THEN
544 3 CALL TXMTC((C-(DEL+''))+'');
545 3 ELSE
546 2 CALL TXMTC(C+'');
546 2 END;
546 2 END;
```

*EJECT

```

565 1 REV_SCROLL: PROCEDURE PUBLIC;
566 2 DECLARE TFLAGS WORD;
567 2 DO;
568 3 CALL MDL(H19_PAR_SLI,H19_PAR_SLI-1); /* Move Status Line
569 3 OUTPUT(VRMM_DAT)=INPUT(VRMM_DAT)-5; /* Retreat Mapping Offset
570 3 CALL EDC(0,0,H19_PAR_CPL); /* Clear top line */

571 3 TFLAGS = FLAGS;
572 3 DISABLE;
573 3 CRTC_DISPLAY.START=CRTC_DISPLAY.START-80; /* Retreat Start Address */
574 3 CRTC_DISPLAY.UPDATE=TRUE;
575 3 IF (TFLAGS AND F86_IF) <> 0 THEN
576 3 ENABLE;
577 3 END;
578 2 END;

579 1 SCROLL: PROCEDURE PUBLIC;
580 2 DECLARE TFLAGS WORD;
581 2 DO;
582 3 IF H19_MODE.STATUS THEN
583 3 CALL MDL(H19_PAR_SLI,H19_PAR_SLI+1); /* Move Status Line */
584 3 CALL EDC(H19_PAR_SLI,0,H19_PAR_CPL); /* Erase the new bottom line */
585 3 OUTPUT(VRMM_DAT)=INPUT(VRMM_DAT)+5; /* Advance the mapping offset */

586 3 TFLAGS = FLAGS;
587 3 DISABLE;
588 3 /* Advance Display Start Address */
589 3 CRTC_DISPLAY.START=CRTC_DISPLAY.START+80;
590 3 CRTC_DISPLAY.UPDATE=TRUE;
591 3 IF (TFLAGS AND F86_IF) <> 0 THEN
592 3 ENABLE;
593 3 END;
593 2 END;

*EJECT
  
```

```

631 1 1 SCPI; PROCEDURE(mask,valu) PUBLIC;
632 2 2 DECLARE mask BYTE;
        DECLARE valu BYTE;
633 2 2 DO;
634 3 3 HI?_MODE_CURSOR = (HI?_MODE_CURSOR AND mask) OR valu;
635 3 3 CALL SCPI;
636 3 3 END;
637 2 2 END;

638 1 1 XMTSC; PROCEDURE(row,col,count) PUBLIC;
639 2 2 DECLARE row BYTE;
        DECLARE col BYTE;
        DECLARE count WORD;
640 2 2 DO;
641 3 3 XMT_ROW = row;
642 3 3 XMT_COL = col;
643 3 3 XMT_BCOUNT = 0;
644 3 3 XMT_GRAPHIC;
645 3 3 XMT_REVERSE = FALSE;
646 3 3 XMT_COLOR = BLACK*8 + WHITE;
647 3 3 XMT_COUNT = count;
648 2 2 END;
  
```

*EJECT

```
657 2 DECLARE TFLAGS WORD;  
658 2 DO;  
659 3 TFLAGS = FLAGS; /* Save Current Processor Flags */  
660 3 DISABLE; /* Disable all interrupts */  
661 3 OUTPUT(CRTC_RSEL)=reg; /* Select specified register */  
662 3 OUTPUT(CRTC_RVAL)=val; /* Set new value */  
663 3 IF (TFLAGS AND F96_1F) <> 0 THEN  
664 3 ENABLE;  
665 3 END;  
666 2 END;  
  
667 1 END;
```

```

0060 A20F00      MOV      ; STATEMENT # 341
                                H19_MODE+0FH,AL
                                ; STATEMENT # 342
0063 B107      MOV      CL,7H
0065 51       PUSH     CX ; 1
0066 50       PUSH     AX ; 2
0067 E80705   CALL     SCA ; STATEMENT # 343
006A F1E000   CALL     DCI ; STATEMENT # 344
006E E80000   CALL     P_HOM ; STATEMENT # 345
0071 E80000   CALL     P_EPAO ; STATEMENT # 346
0074 B0F0     MOV      AL,0FH
0076 50       PUSH     AX ; 1
0077 B0B0     MOV      AL,80H
0079 50       PUSH     AX ; 2
007A E8A505   CALL     DVC ; STATEMENT # 347
007D B900C0   MOV      CX,0C00H
0080 B80000   MOV      AX,0H
0083 A30000   MOV      P1PTR,AX
0086 870E0200 MOV      P1PTR+2H,CX ; STATEMENT # 348
008A 87C3     MOV      BX,AX
008C 8EC1     MOV      ES,CX
008E 268A17   MOV      DL,ES:P1FBX1
0091 88161500 MOV      TI,DL ; STATEMENT # 349
0095 06       ES ; 1
0096 50       PUSH     AX ; 2
0097 E80000   CALL     INCB ; STATEMENT # 350
009A C41E0000 LES      BX,P1PTR
009E 268A07   MOV      AL,ES:P1FBX1
00A1 3A061500 CMP      AL,TI
00A5 7507     JNZ      @5 ; STATEMENT # 351
00A7 C60603001 MOV      H19_PAR+3H,1H ; STATEMENT # 352
00AC EB0F     JMP      @6 ; STATEMENT # 353
                                @5:
00AE C60603003 MOV      H19_PAR+3H,3H ; STATEMENT # 354
00B3 A01500   MOV      AL,1500
00B6 C41E0000 LES      BX,P1PTR
00BA 268807   MOV      ES:P1FBX1,AL ; STATEMENT # 356
                                @6:
00BD B900E0     MOV      CX,0E00H
00C0 B80000   MOV      AX,0H
00C3 A30000   MOV      P1PTR,AX
00C6 870E0200 MOV      P1PTR+2H,CX ; STATEMENT # 357
    
```

```

0138 E9E704 CALL QVC
; STATEMENT # 371
0139 50 POP BP
013C C3 RET
INIT_VIDED
ENDP
; STATEMENT # 372
16921 PROC NEAR
013D 55 PUSH BP
013E 9BEC MOV BP,SP
; STATEMENT # 374
0140 B01C MOV AL,1CH
0142 E6D9 OUT 0DD9H
; STATEMENT # 375
0144 B0FF MOV AL,0FFH
0146 E6D8 OUT 0D8H
; STATEMENT # 376
0148 B038 MOV AL,38H
014A E6D9 OUT 0D9H
; STATEMENT # 377
014C B0FF MOV AL,0FFH
014E E6D8 OUT 0D8H
; STATEMENT # 378
0150 B03C MOV AL,3CH
0152 E6D9 OUT 0D9H
; STATEMENT # 379
0154 B000 MOV AL,0H
0156 E6D8 OUT 0D8H
; STATEMENT # 380
0158 B0FF MOV AL,0FFH
015A E6DA OUT 0DAH
; STATEMENT # 381
015C B03C MOV AL,3CH
015E E6D8 OUT 0D8H
; STATEMENT # 382
0160 B000 MOV AL,0H
0162 E6DA OUT 0DAH
; STATEMENT # 384
0164 5D POP BP
0165 C3 RET
16921 ENDP
; STATEMENT # 385
0_TTY_INIT PROC NEAR
0166 55 PUSH BP
0167 9BEC MOV BP,SP
; STATEMENT # 388
0169 B30000 MOV AX,0H
016C A30000 CRTD_DISPLAY,AX
016F A30C00 H19_MODE+0CH,AX
0172 A30300 XMT+3H,AX
; STATEMENT # 389
0175 A00500 MOV AL,H19_PAR+5H
0178 2C03 AL,3H
017A 0C40 AL,40H
017C A20600 H19_MODE+6H,AL
; STATEMENT # 390
017F E000 MOV AL,0H
    
```



```

01DE E6DD      OUT      @DDH      ; STATEMENT # 411
01E0 B00D      MOV      AL,@DH
01E2 E6DC      OUT      @DCH      ; STATEMENT # 412
01E4 A10000    MOV      AX,CRTC_DISPLAY
01E7 E6DD      OUT      @DDH      ; STATEMENT # 413
01E9 C606020000 MOV      CRTC_DISPLAY+2H,@H ; STATEMENT # 415
                                @12:
01EE A00200    MOV      AL,CRTC_CURSOR+2H
01F1 D0DS      RCR      AL,1
01F3 7317      JNB     @13      ; STATEMENT # 417
01F5 B00E      MOV      AL,@EH
01F7 E6DC      OUT      @DCH      ; STATEMENT # 418
01F9 A00100    MOV      AL,CRTC_CURSOR+1H
01FC E6DD      OUT      @DDH      ; STATEMENT # 419
01FE B00F      MOV      AL,@FH
0200 E6DC      OUT      @DCH      ; STATEMENT # 420
0202 A10000    MOV      AX,CRTC_CURSOR
0205 E6DD      OUT      @DDH      ; STATEMENT # 421
0207 C606020000 MOV      CRTC_CURSOR+2H,@H ; STATEMENT # 423
                                @13:
020C 833E030000 CMP      XMT+3H,@H
0211 7445      JZ      @14      ; STATEMENT # 425
0213 A00000    MOV      AL,XMT
0216 B400      MOV      AH,@H
0218 01060100  ADD     XMT+1H,AX ; STATEMENT # 426
                                @15:
021C 833E010000 CMP      XMT+1H,@H
0221 7E28      JLE     @16
0223 833E030000 CMP      XMT+3H,@H
0228 7421      JZ      @16      ; STATEMENT # 427
022A FF1E0000  CALL   XCA      ; STATEMENT # 428
022E FF0E0300  DEC     XMT+3H ; STATEMENT # 429
0232 A00500    MOV      AL,XMT+5H
0235 FED0      INC     AL
0237 A20500    MOV      XMT+5H,AL ; STATEMENT # 430
023A 38060000    CMP      HI9_PAR,AL
023E 75DC      JNZ     @15
0240 C606050000 MOV      XMT+5H,@H ; STATEMENT # 433
    
```

```

023E E80000 CALL FLAGS ; STATEMENT # 456
0291 A30A00 MOV TFLAGS,AX ; STATEMENT # 457
0294 FA CLI ; STATEMENT # 458
0295 E4F3 IN 0F3H ; STATEMENT # 459
0297 24BF AND AL,0BFH
0299 E6F3 OUT 0F3H ; STATEMENT # 459
029B F706A00002 TEST TFLAGS,200H
02A1 7401 JZ @21 ; STATEMENT # 460
02A3 FB STI @21: ; STATEMENT # 462
02A4 5D POP BP ; STATEMENT # 462
02A5 C3 RET ; STATEMENT # 463
        D_CRT
        UTTY_RES ENDP
        ; STATEMENT # 463
02A6 55 PROC NEAR
02A7 8BEC PUSH BP
        MOV BP,SP ; STATEMENT # 466
02A9 8A4604 MOV AL,EBP1,C
02AC 3C20 CMP AL,20H
02AE 7204 JB @23
02B0 3C7F CMP AL,7FH
02B2 7556 JNZ @22 ; STATEMENT # 468
        @23:
02B4 E007 MOV AL,7H ; STATEMENT # 468
02B6 384604 CMP EBP1,C,AL
02B9 7506 JNZ @24 ; STATEMENT # 469
02BB 50 PUSH AX ; 1
02BC E80000 CALL WRITK ; STATEMENT # 470
        @18:
02BF EB47 JMP @17
        @24:
02C1 807E0408 CMP EBP1,C,SH
02C5 750D JNZ @26
02C7 823E000000 CMP HORZ_CHAR,0H
02CC 7406 JZ @26 ; STATEMENT # 471
02CE FE0E0000 DEC HORZ_CHAR ; STATEMENT # 472
02D2 E8EB JMP @18
        @26:
02D4 807E0409 CMP EBP1,C,7H
02D8 7505 JNZ @26 ; STATEMENT # 473
02DA E83301 CALL P_HT ; STATEMENT # 474
02DD EBE0 JMP @18
    
```

```

034A A00000 MOV AL,H19_PAR
034D HEC8 DEC AL
034F 38060000 CMP HORZ_CHAR,AL
0353 7306 JNB @37 ; STATEMENT # 472
0355 FE060000 INC HORZ_CHAR ; STATEMENT # 473
0359 EB0A JMP @35 ; STATEMENT # 473
035B A01100 @37: MOV AL,H19_MODE+1H
035E D0D8 RCR AL,1
0360 7303 JNB @35
0362 E80000 CALL ORLF ; STATEMENT # 474
0365 E8C501 @35: CALL CURSOR ; STATEMENT # 476
0368 50 POP BP ; STATEMENT # 478
0369 C20200 RET ZH
037C C20200 @37: U_CKT ENDP ; STATEMENT # 479
036D 88EC @36C: U_KBD PROC NEAR
036E 55 PUSH BP
036F 88EC MOV BP,SP ; STATEMENT # 502
0371 3A5E04 MOV BL,EBP+4
0372 B700 MOV BH,0H
0374 FFB70000 PUSH KMAPLTX+1 ; STATEMENT # 504
0378 E80000 CALL DXMTC ; STATEMENT # 504
037B 5D POP BP
037C C20200 RET ZH ; STATEMENT # 505
037F 55 @37F: TXMT PROC NEAR
0380 88EC PUSH BP
0381 88EC MOV BP,SP ; STATEMENT # 507
0384 55 @384: TXMTC PROC NEAR
0385 88EC PUSH BP
0386 88EC MOV BP,SP ; STATEMENT # 510
0388 FF7604 @388: FF7604 PUSH CBP+4 ; 1
0389 E80000 @389: E80000 CALL SXMTC ; STATEMENT # 511
038B FF0E0100 @38B: FF0E0100 DEC XMT+1H ; STATEMENT # 513
038C 5D @38C: 5D POP BP ; STATEMENT # 513
038D C20200 @38D: C20200 RET ZH
038E 55 @38E: TXMTC ENDP ; STATEMENT # 515
038F B80C00 @38F: B80C00 MOV AX,OFFSET(XC)
0390 1E @390: 1E PUSH DS ; 1
0391 50 @391: 50 PUSH AX ; 2
0392 FF360600 @392: FF360600 PUSH XMT+6H ; 3

```

```

03E0 EB02      JMP      @27      ; STATEMENT # 532
@44:
03E1 B071      MOV      AL,71H
03E2 E85A00    PUSH     AX        ; 1
@45:
CALL     TXMTC
; STATEMENT # 534

@43:
03F5 A01A00    MOV      AL,CA
03F6 B13F      MOV      CL,3FH
03F7 22C1      AND     AL,CL
03F8 3A060700  CMP     AL,XMT+7H
0400 7429      JZ      @46
; STATEMENT # 536
0402 A20700    MOV      XMT+7H,AL
; STATEMENT # 537
0405 B01E      MOV      AL,1BH
0407 50        PUSH     AX        ; 1
0408 E84400    CALL     TXMTC
; STATEMENT # 538
040B B06D      MOV      AL,6DH
040D 50        PUSH     AX        ; 1
040E E33E00    CALL     TXMTC
; STATEMENT # 539
0411 A01A00    MOV      AL,CA
0414 2407      AND     AL,7H
0416 0430      ADD     AL,30H
0418 50        PUSH     AX        ; 1
0419 E83300    CALL     TXMTC
; STATEMENT # 540
041C A01A00    MOV      AL,CA
041F 2438      AND     AL,38H
0421 B103      MOV      CL,3H
0423 D2E8      SHR     AL,CL
0425 0430      ADD     AL,30H
0427 50        PUSH     AX        ; 1
0428 E82400    CALL     TXMTC
; STATEMENT # 542

@46:
042B B15F      MOV      CL,5FH
042D A01700    MOV      AL,C
0430 3AC8      CMP     CL,AL
0432 7310      JNB     @47
0434 A00800    MOV      AL,XMT+8H
0437 D0D8      RCR     AL,1
0439 7309      JNB     @47
; STATEMENT # 543
043B A01700    MOV      AL,C
043E 2C60      SUB     AL,60H
0440 045E      ADD     AL,5EH
0442 EB05      JMP     @29
; STATEMENT # 544
0444 A01700    MOV      AL,C
@47:

```

```

04A6 7503 JNZ @53 ; STATEMENT # 562
04A8 E83D00 @53: CALL SCROLL ; STATEMENT # 562
04AB 5D POP BP ; STATEMENT # 564
04AC C3 RET ENDP
; STATEMENT # 565
04AD 55 REV_SCROLL PROC NEAR
04AE 8BEC PUSH BP
MOV BP,SP
; STATEMENT # 568
04B0 A00400 MOV AL,H1?_PAR+4H
04B3 50 PUSH AX ; 1
04B4 FEC8 DEC AL
04B6 B400 MOV AH,0H
04B8 50 PUSH AX ; 2
04B9 F1E000 CALL MDL ; STATEMENT # 569
04BD E4DA IN @DAH
04BF 2C05 SUB AL,5H
04C1 E6DA OUT @DAH ; STATEMENT # 570
04C3 B000 MOV AL,0H ; 1
04C5 50 PUSH AX ; 2
04C6 50 PUSH AX ; 3
04C7 FF360000 FF360000
04C8 F1E000 CALL EDC ; STATEMENT # 571
04CF E80000 CALL FLAGS
04D2 A30E00 MOV TFLAGS,AX ; STATEMENT # 572
04D5 FA CLI ; STATEMENT # 573
04D6 832E000050 SUB CRIC_DISPLAY,50H ; STATEMENT # 574
04D8 C6060200FF MOV CRIC_DISPLAY+2H,0FFH ; STATEMENT # 575
04E0 A70002 TEST AX,200H @55
04E3 7401 JZ @55 ; STATEMENT # 576
04E5 FB STI ; STATEMENT # 578
04E6 5D POP BP ; STATEMENT # 579
04E7 C3 RET ENDP
; STATEMENT # 582
04E8 55 SCROLL PROC NEAR
04E9 8BEC PUSH BP
MOV BP,SP
; STATEMENT # 582
04EB A00F00 MOV AL,H1?_MODE+0FH
04EE D0D8 RCR AL,1
04F0 730D JNB @56
    
```

```

054E A30000 MOV CRTD_CURSOR,AX ; STATEMENT # 600
0551 D6060200FF MOV CRTD_CURSOR+2H,0FFH ; STATEMENT # 601
0556 F70612000002 TEST TFLAGS,200H ; STATEMENT # 602
055C 7401 JZ 058 ; STATEMENT # 602
055E FB STI ; STATEMENT # 602
058:
055F 5D POP BP ; STATEMENT # 604
0560 C3 RET ; STATEMENT # 604
CURSOR ENDP
ENABLE_LINES ; STATEMENT # 605
0561 55 BP PROC NEAR
0562 8BEC PUSH BP
MOV BP,SP ; STATEMENT # 608
0564 B006 MOV AL,6H
0566 50 AX ; 1
0567 FF7604 PUSH [BP],LINE$ 2
056A E80100 CALL UCCR
; STATEMENT # 610
056D 5D POP BP
056E C20200 RET 2H
ENABLE_LINES ENDP ; STATEMENT # 611
SDA PROC NEAR
0571 55 BP PUSH BP
0572 8BEC MOV BP,SP ; STATEMENT # 614
0574 844606 MOV AL,[BP],FORE ; STATEMENT # 615
0577 A20000 MOV COLOR,AL
; STATEMENT # 615
057A 844604 MOV AL,[BP],BACK
057D A20100 MOV COLOR+1H,AL
; STATEMENT # 616
0580 B103 MOV CL,3H
0582 D2E0 SHL AL,CL
0584 844E06 MOV CL,[BP],FORE
0587 0AC1 OR AL,CL
0589 A20200 MOV COLOR+2H,AL
; STATEMENT # 617
058C E207 MOV DL,7H
058E 3ACC2 CMP AL,DL
0590 B0FF MOV AL,0FFH
0592 7401 JZ $+3H
0594 40 INC AX
0595 20060500 H19_MODE+5H,AL
; STATEMENT # 618
0599 844604 MOV AL,[BP],BACK
059C 0AC1 OR AL,CL
059E 32C2 XOR AL,DL
05A0 A20300 MOV COLOR+3H,AL
; STATEMENT # 619
05A3 844604 MOV AL,[BP],BACK

```

05F8	55	XMTSC	PROC NEAR		
05F9	8BEC		PUSH BP		
			MOV BP, SP		
				;	STATEMENT # 641
05FB	8A4603		MOV AL, [BP], ROM		
05FE	A20600		MOV MOV		
				;	STATEMENT # 642
0601	8A4606		MOV MOV		
				;	STATEMENT # 643
0604	A20500		MOV MOV		
				;	STATEMENT # 643
0607	B30000		MOV MOV		
				;	STATEMENT # 644
060A	A30100		MOV MOV		
				;	STATEMENT # 644
060D	A20700		MOV MOV		
				;	STATEMENT # 644
0610	A20E00		MOV MOV		
				;	STATEMENT # 645
0613	C606070007		MOV MOV		
				;	STATEMENT # 645
0618	8B4604		MOV MOV		
				;	STATEMENT # 646
061B	A30300		MOV MOV		
				;	STATEMENT # 646
061E	5D		POP BP		
061F	C20600		RET 6H		
		XMTSC	ENDP		
				;	STATEMENT # 649
0622	55	OVOC	PROC NEAR		
0623	8BEC		PUSH BP		
			MOV BP, SP		
				;	STATEMENT # 652
0625	E4D8		IN 0D8H		
0627	8A4E06		MOV CL, [BP], MASK		
062A	F6D1		MOV NOT CL		
				;	STATEMENT # 652
062C	22C1		MOV AND AL, CL		
062E	8A4E04		MOV CL, [BP], VALL		
0631	F6D1		MOV NOT CL		
0633	224E06		MOV AND CL, [BP], MASK		
0636	0AC1		MOV OR AL, CL		
0638	E4D8		MOV OUT 0D8H		
				;	STATEMENT # 654
063A	5D		POP BP		
063B	C20400		RET 4H		
		OVOC	ENDP		
				;	STATEMENT # 655
063E	55	UOOR	PROC NEAR		
063F	8BEC		PUSH BP		
			MOV BP, SP		
0641	51		PUSH CX		
				;	STATEMENT # 659
0642	E80000		CALL FLAGS		
0645	8746FE		MOV MOV		
				;	STATEMENT # 660
0648	FA		CLI		
				;	STATEMENT # 661
0649	8A4606		MOV MOV		
				;	STATEMENT # 661
064C	E4D8		MOV OUT 0D8H		
				;	STATEMENT # 662

CROSS-REFERENCE LISTING

DEFN	ADDR	SIZE	NAME, ATTRIBUTES, AND REFERENCES
612	0004H	1	BACK
34	0000H	1	BEL
161	0000H	1	BILL
67			BLACK
68			BLUE
4			BOOL
141	0000H	83	BOOT_PAR
	0000H	1	INDEX
	0001H	1	PORT
	0002H	80	STRNG
	0052H	1	UNIT
35			BS
162	0000H	1	BSIL
			BUILPTR
54	0000H	4	BYTEPTR
500	0004H	1	C
508	0004H	1	C
464	0004H	1	C
49	0000H	1	C
506	0017H	1	C
57	0000H	1	C
506	001AH	1	CA
36			CAN
130	0000H	1	CHAR
125	0000H	1	CHAR
177	0000H	1	CHAR
298	0000H	1	CHAR
135			CODE_SEG
180	0000H	1	COL
639	0006H	1	COL
169	0000H	7	COLR
			FORE
			BACK
			MASK
			CLEAR
			PAINTED
			FONT
			COMP_FONT
639	0004H	2	COUNT
37			CR
122	0000H	3	CRLF
170	0000H	2	CRTC_CURSOR
			START
			UPDATE
171	0000H	3	CRTC_DISPLAY
			START
			UPDATE
328	0000H	16	CRTC_REG_50
329	0010H	16	CRTC_REG_60
75			CRTC_RSEL
			BYTE IN PROC (SCA) PARAMETER AUTOMATIC
			LITERALLY '007H' 468
			BYTE EXTERNAL (36) 342 645
			LITERALLY '0#0#0B' 165 170 171 173 175 292 293 312
			LITERALLY '0#0#1B' 443
			LITERALLY 'BYTE' 470
			STRUCTURE EXTERNAL (16)
			BYTE
			BYTE
			BYTE ARRAY (80)
			BYTE
			LITERALLY '008H' 470
			BYTE EXTERNAL (37)
			BUILTN
			347 356 357
			POINTER IN PROC (INCB) PARAMETER
			54
			BYTE IN PROC (D_KBD) PARAMETER AUTOMATIC
			500 502
			BYTE IN PROC (TXMTC) PARAMETER AUTOMATIC
			508 510
			BYTE IN PROC (D_CRT) PARAMETER AUTOMATIC
			464 466 468 470
			472 474 480 490
			BYTE IN PROC (DXMTC) PARAMETER
			49
			BYTE IN PROC (TXMT) 516* 518 542 543 544
			BYTE IN PROC (SXMT) PARAMETER 57
			BYTE IN PROC (TXMT) 517* 526 534 536 539 540
			LITERALLY '018H'
			PARAMETER
			130
			BYTE IN PROC (WRITEC) PARAMETER
			125
			BYTE IN PROC (MCU) PARAMETER
			177
			BYTE IN PROC (S_CRT) PARAMETER
			298
			LITERALLY '0FE5H'
			PARAMETER
			180
			BYTE IN PROC (DCA) PARAMETER
			180
			BYTE IN PROC (XMTSC) PARAMETER AUTOMATIC
			639 642
			STRUCTURE EXTERNAL (41)
			614* 616 618 619 620
			BYTE 615* 616 618 619 621
			BYTE 616* 617
			BYTE 618*
			619* 620 621
			BYTE 620*
			621*
			BYTE 621*
			WORD IN PROC (XMTSC) PARAMETER AUTOMATIC
			639 646
			LITERALLY '00DH' 437 480
			PROCEDURE EXTERNAL (8) STACK=0000H 494
			STRUCTURE EXTERNAL (42)
			418 420 599*
			WORD 418 420 599*
			STRUCTURE EXTERNAL (43)
			397* 415 421* 444 600*
			WORD 397* 415 421* 444 600*
			STRUCTURE EXTERNAL (43)
			338* 410 412 573* 573 588* 588 599
			WORD 338* 410 412 573* 573 588* 588 599
			BYTE 397* 407 413* 444 574* 589*
			BYTE ARRAY (16) DATA 334
			335
			BYTE ARRAY (16) DATA 409
			411 417 419 661
			LITERALLY '10_CRTC+0'

140	0000H	2	DS_SIZE	WORD EXTERNAL(15)					
48	0000H		DXMTC	PROCEDURE EXTERNAL(0) STACK=0000H				502	
463	02A6H	198	D_CRT	PROCEDURE PUBLIC STACK=0010H					
479	036CH	19	D_KBD	PROCEDURE PUBLIC STACK=0009H					
385	0166H	96	D_TTY_INIT	PROCEDURE STACK=0006H	455				
446	026FH	55	D_TTY_RES	PROCEDURE PUBLIC STACK=000CH					
144	0000H	4	D_XMTC	POINTER EXTERNAL(19)					
145	0000H	4	EDC	POINTER EXTERNAL(20)	570	584			
146	0000H	4	EMEC	POINTER EXTERNAL(21)					
605	0561H	16	ENABLE_LINES	PROCEDURE PUBLIC STACK=000AH					
39			EOL	LITERALLY '080H'					
40			EOS	LITERALLY '030H'					
41			ESC	LITERALLY '01BH'	521	529	537		
172	0000H	10	ESCP	STRUCTURE EXTERNAL(44)					
	0000H	1	COMMAND	BYTE					
	0001H	2	FUNCTION	WORD					
	0003H	1	MODE	BYTE					
	0004H	1	OPER_COUNT	BYTE					
	0005H	1	OPER_INDEX	BYTE					
	0006H	4	OPERAND	BYTE ARRAY(4)					
178			F86_AF	LITERALLY '0000*0001*0000B'					
200			F86_CF	LITERALLY '0000*0000*0000B'					
173			F86_DF	LITERALLY '0100*0000*0000B'					
174			F86_IF	LITERALLY '0010*0000*0000B'	439	452	459	575	590
				643					601
192			F86_OF	LITERALLY '1000*0000*0000B'					
179			F86_Pf	LITERALLY '0000*0000*0100B'					
196			F86_Sf	LITERALLY '0000*1000*0000B'					
195			F86_Tf	LITERALLY '0001*0000*0000B'					
197			F86_Zf	LITERALLY '0000*0100*0000B'					
5			FALSE	LITERALLY '000H'	341	390	395	397	413
42			FF	LITERALLY '00CH'					421
51	0000H		FLAGS	PROCEDURE WORD EXTERNAL(1) STACK=0000H	405	449	456	571	
				586	597	659			
147	0000H	4	FONT	POINTER EXTERNAL(22)					
156	0000H	2	FONT_SIZE	WORD EXTERNAL(31)					
612	0006H	1	FORE	BYTE IN PROC (SCA) PARAMETER AUTOMATIC	612	614			
303			GEN_CNT	LITERALLY 'ID_GENERAL+1'					
304			GEN_DAT	LITERALLY 'ID_GENERAL'					
305			GEN_DIR	LITERALLY 'ID_GENERAL'					
71			GREEN	LITERALLY '18*0B'					
173	0000H	18	H19_MODE	STRUCTURE EXTERNAL(45)					
	0000H	1	ALTERNATE	BYTE					
	0001H	1	ANSI	BYTE	390*	476			
	0002H	1	AUTO_CR	BYTE	390*	483			
	0003H	1	AUTO_LF	BYTE					
	0004H	1	AUTO_REPEAT	BYTE					
	0005H	1	BWD	BYTE	617*	617			
	0006H	1	CURSOR	BYTE	389*	627	628	634*	634
	0007H	1	CURSOR_ON	BYTE	391*	626			
	0008H	1	EXPAND	BYTE					
	0009H	1	GRAPHIC	BYTE					
	000AH	1	INSERT	BYTE	390*	483			
	000BH	1	KEY_EN	BYTE	391*				
	000CH	2	REVERSE	WORD	383*	490			
	000EH	1	SHIFTED	BYTE					

7			IO_DIP	LITERALLY '00FEH'	333					
24			IO_GENERAL	LITERALLY '00E0H'						
7			IO_HIADR	LITERALLY '00FDH'						
18			IO_INT_MS	LITERALLY '00F2H'	451	458				
19			IO_INT_SL	LITERALLY '00F0H'						
17			IO_KEYBRD	LITERALLY '00F4H'						
26			IO_LIFN	LITERALLY '00DEH'						
10			IO_MEM	LITERALLY '00FCH'						
23			IO_PRINTER	LITERALLY '00E2H'						
12			IO_RSRV_1	LITERALLY '00FAH'						
14			IO_RSRV_2	LITERALLY '00FBH'						
15			IO_RSRV_3	LITERALLY '00F7H'						
16			IO_RSRV_4	LITERALLY '00F6H'						
25			IO_RSRV_5	LITERALLY '00DFH'						
29			IO_RSRV_6	LITERALLY '00C0H'						
21			IO_SER_A	LITERALLY '00E8H'						
20			IO_SER_B	LITERALLY '00ECH'						
13			IO_SOUND	LITERALLY '00F9H'						
8			IO_SWAP	LITERALLY '00FEH'						
22			IO_TIMER	LITERALLY '00E4H'						
11			IO_TSTAT	LITERALLY '00F8H'	340	374	375	376	377	378
28			IO_VIDEO	LITERALLY '00D8H'	381	382	569	585	652	340
31			IO_ZZ07_0	LITERALLY '00B0H'						
30			IO_ZZ07_1	LITERALLY '00B8H'						
33			IO_ZZ17_0	LITERALLY '00A8H'						
32			IO_ZZ17_1	LITERALLY '00A0H'						
65	0000H	1	IVL	BYTE IN PROC (INIT_ITV) PARAMETER						65
65	0000H	4	IVP	POINTER IN PROC (INIT_ITV) PARAMETER						65
261			KC_ARF	LITERALLY '02H'						
262			KC_AND	LITERALLY '01H'						
263			KC_BEP	LITERALLY '07H'	469					
268			KC_CFI	LITERALLY '05H'						
269			KC_CLK	LITERALLY '06H'						
264			KC_DI	LITERALLY '0DH'						
265			KC_EI	LITERALLY '0CH'	396					
270			KC_KBD	LITERALLY '07H'						
271			KC_KBE	LITERALLY '03H'						
266			KC_KCF	LITERALLY '04H'						
267			KC_KCQ	LITERALLY '03H'						
272			KC_MNS	LITERALLY '0BH'						
273			KC_MUD	LITERALLY '0AH'						
274			KC_RES	LITERALLY '00H'	392					
292	0000H	2	KEY	STRUCTURE EXTERNAL(55)						
	0000H	1	CHAR	BYTE						
	0001H	1	AVAIL	BYTE						
256			KEY_CMND	LITERALLY 'ID_KEYBRD+1'	395#					
257			KEY_DATA	LITERALLY 'ID_KEYBRD+0'						
258			KEY_STAT	LITERALLY 'ID_KEYBRD+1'						
157	0000H	256	KMAP	BYTE ARRAY(256) EXTERNAL(32)						502
259			KS_CXRDY	LITERALLY '001B'						
260			KS_KXRDY	LITERALLY '010B'						
286			KY_BREAK	LITERALLY '0AAH'						
282			KY_DOWN	LITERALLY '0AAH'						
275			KY_ENTER	LITERALLY '08DH'						
277			KY_F0	LITERALLY '096H'						

CROSS-REFERENCE LISTING

59	0000H	VIDEO	PROCEDURE STACK=0000H
79	0000H	VIDEO_INTR_A	PROCEDURE EXTERNAL(4) STACK=0000H
78	0000H	VID_CDC	LITERALLY '10_VIDE0+1'
77	0000H	VID_CDD	LITERALLY '10_VIDE0+0'
80	0000H	VID_CMD	LITERALLY '10_VIDE0+0'
82	0000H	VRM_DAT	LITERALLY '10_VIDE0+2'
81	0000H	VRM_MPC	LITERALLY '10_VIDE0+3'
45	0000H	VRM_MPD	LITERALLY '10_VIDE0+2'
74	0000H	VT	LITERALLY '00BH'
138	0000H	WHITE	LITERALLY '1\$1\$1B'
129	0000H	WIP	BYTE ARRAY(5) EXTERNAL(13)
132	0000H	WRITC	PROCEDURE EXTERNAL(11) STACK=0000H
297	0000H	WRITES	PROCEDURE EXTERNAL(12) STACK=0000H
506	0000H	WRTRK	PROCEDURE EXTERNAL(58) STACK=0000H
154	0000H	XC	WORD IN PROC (TXMT)
168	0000H	XCA	POINTER EXTERNAL(29)
167	0000H	XCOLOR_BACK	LITERALLY '00\$111\$000B'
61	0000H	XCOLOR_FORE	LITERALLY '00\$1000\$111B'
175	0000H	XEC	PROCEDURE EXTERNAL(5) STACK=0000H
		XMT	STRUCTURE EXTERNAL(47)
		BURST	BYTE
		COUNT	INTEGER
		COL	WORD
		COLM	BYTE
		COLR	BYTE
		GRAPHIC	BYTE
		REVERSE	BYTE
		XMTSC	PROCEDURE PUBLIC STACK=0008H
		XMPF	LITERALLY '013H'
		XON	LITERALLY '011H'
		XREVERSE	LITERALLY '10\$1000\$000B'
		YELLOW	LITERALLY '1\$1\$0B'

MODULE INFORMATION:

CUBE AREA SIZE = 0661H 1693D
 CONSTANT AREA SIZE = 0000H 0D
 VARIABLE AREA SIZE = 001CH 28D
 MAXIMUM STACK SIZE = 0010H 16D
 1758 LINES READ
 0 PROGRAM WARNINGS
 0 PROGRAM ERRORS

END OF PL/M-86 COMPILATION

Definitions

```

= $SAVE
= $NOLIST
= $NOLIST INCLUDE (':F2:KEYDEF.H')
= $SAVE
= $NOLIST INCLUDE (':F2:KEYLIB.H')
= $SAVE
= $NOLIST INCLUDE (':F2:VIDEO.H')
= $SAVE
= $NOLIST
= $ SET(COMPRESS)
/*
*/
Internal Terminal Emulation Modes
*/
186 1 DC M_NRM LT '0' /* Normal character display */;
187 1 DC M_ESC LT '1' /* Looking for Escape command */;
188 1 DC M_OPR LT '2' /* Accepting Sequence Operands */;
189 1 DC M_ANS LT '3' /* ANSI-Mode Sequence Processing */;

190 1 DECLARE LINE_INDEX BYTE /* Scratch Line Index */
PUBLIC;
191 1 DECLARE SAVED_HORZ_CHAR BYTE /* Saved Horizontal Char. pos. */
PUBLIC;
192 1 DECLARE SAVED_VERT_LINE_BYTE /* Saved Vertical Line pos. */
PUBLIC;

193 1 DECLARE ESC_TABLE_1(*) WORD DATA
.P_EAM, /* Enter ANSI Mode */
.P_EAKM, /* Enter Alternate Key-Pad Mode */
.P_XAKM, /* Exit Alternate Key-Pad Mode */
.P_UIM, /* Un-Implemented */
.P_EICM, /* Enter Insert Character Mode */
.P_CUP, /* Cursor Up */
.P_CDN, /* Cursor Down */
.P_CRT, /* Cursor Right */
.P_CLF, /* Cursor Left */
.P_ERPA, /* Erase Page */
.P_ERGM, /* Enter Graphics Mode */
.P_XGM, /* Exit Graphics Mode */
.P_HOM, /* Home the Cursor */
.P_RLF, /* Reverse Line Feed */
.P_EEOP, /* Erase to End-Of-Page */
.P_EEOL, /* Erase to End-Of-Line */
.P_IL, /* Insert Line */
.P_DL, /* Delete Line */
.P_DC, /* Delete Character */
.P_XICM, /* Exit Insert Character Mode */
.P_ICA, /* Direct Cursor Addressing */

194 1 DECLARE WORD DATA (
/* Direct Cursor Addressing */

```

```

196 1 S_TTY_INIT: PROCEDURE PUBLIC;
197 2 DO;
198 3 ESCP.MODE = M_NRM;
199 3 H19.MODE.EXPAND = TRUE;
200 3 H19.MODE.ANSI,
H19.MODE.GRAPHIC,
H19.MODE.ALTERNATE,
H19.MODE.SHIFTED = FALSE;
201 3 CALL P_SCP; /* Initialize Saved Cursor Position */
202 3 END;
203 2 END;

204 1 S_CRT: PROCEDURE(char) PUBLIC;
205 2 DECLARE char BYTE;
206 2 DO;
207 3 IF XMT.COUNT = 0 THEN
208 3 DO;
209 4 char = char AND 07FH;
210 4 DO CASE ESCP.MODE :
/*
*/
/* Normal Character
*/
DO;
IF char <> ESC THEN
DO;
IF H19.MODE.GRAPHIC AND (''<=char AND char<DEL)
THEN
CALL D_CRT(char'''+DEL+1);
ELSE
CALL D_CRT(char);
END;
ELSE IF H19.MODE.ANSI THEN
ESCP.MODE = M_ANSI;
ELSE
ESCP.MODE = M_ESC;
END;
/*
*/
/* Escape Sequence Command
*/
DO;
ESCP.COMMAND = char ;
ESCP.OPER_COUNT = DOC(char) ;
ESCP.OPER_INDEX = 0 ;
ESCP.MODE = M_OPR ;
IF ESCP.OPER_COUNT = 0 THEN
CALL PES;
END;
/*
*/
Escape Sequence Operands

```

```

/*
 *
 * DCA -- Direct Cursor Addressing
 *
 * DCA performs the direct cursor addressing
 * function. This involves setting the cursor
 * to the specified address. This cursor will
 * NOT be moved to the status line if the status
 * line is not enabled. Any illegal line spec-
 * ification results in the cursor remaining at
 * the current line. Any illegal column spec-
 * ification results in positioning the cursor
 * at the end of the current line.
 *
 *
 * Parameters:
 *
 * row -- Vertical Row [0,h19_par.s11]
 * col -- Horizontal Column [0,h19_par.cp1-1]
 */

```

```

244 1 JCA: PROCEDURE(row,col) PUBLIC;
245 2 DECLARE row BYTE;
246 2 col BYTE;
247 3 DO;
248 3 IF (0 <= row AND row < H19_PAR.SL1) OR
249 3 (row=H19_PAR.SL1 AND H19_MODE.STATUS) THEN
250 3 THEN
251 3 HORZ_CHAR = col;
252 3 ELSE
253 3 HORZ_CHAR = H19_PAR.CPL-1;
254 3 END;
255 2 END;

```

```

/*
 *
 * DDC -- Determine Operand Count
 *
 * DDC determines the operand count for the specified escape
 * sequence.
 *
 * Parameters:
 *
 * cmd = Escape Sequence or Command to return
 * the number of parameters for.
 *
 * Exit:
 *
 * Returns the number of parameters (characters) to be
 */

```

```

/*
 * - Process Escape Sequence
 *
 * Description
 *
 * PES processes the current escape sequence. When PES
 * is invoked, it is assumed that all of the required
 * parameters/operands have been input.
 *
 * Entry:
 *
 * ESCP.COMMAND = Escape Sequence Command
 * ESCP.OPERAND(i) = Operands for this escape sequence
 *
 * Exit:
 *
 * Emulation mode, 'ESCP,MODE', reset to normal character mode
 */

```

```

266 1 PES:
267 2 DO;
268 3 PROCEDURE;
269 3 IF ESCP.MODE = M_NRM;
270 3 ' <<=ESCP.COMMAND AND ESCP.COMMAND<='0' THEN
271 3 ESCP.FUNCTION = ESC_TABLE_1(ESCP.COMMAND<');
272 3 'Y<=ESCP.COMMAND AND ESCP.COMMAND<=' ' THEN
273 3 ESCP.FUNCTION = ESC_TABLE_2(ESCP.COMMAND<'Y');
274 3 ELSE IF ESCP.COMMAND = 'b' THEN
275 3 ESCP.FUNCTION = 'P_EDOP';
276 3 ELSE IF 'i<=ESCP.COMMAND AND ESCP.COMMAND<=' THEN
277 3 ESCP.FUNCTION = ESC_TABLE_3(ESCP.COMMAND<'i');
278 3 ELSE IF '#? = ESCP.COMMAND THEN
279 3 ESCP.FUNCTION = 'P_XMTP';
280 3 ELSE
281 3 ESCP.FUNCTION = 'P_UIM';
282 3 CALL ESCP.FUNCTION;
283 3 CALL CURSOR;
283 2 END;

```

REJECT


```
/*  
 * P_UIM ... Un-Implemented Escape Sequence  
 *  
 * 'P_UIM' processes the Un-Implemented Escape  
 * sequences. Eventually these will be vectored  
 * through RAM.  
 */  
  
P_UIM: PROCEDURE PUBLIC;  
DO;  
CALL UIES;  
END;  
290 1  
291 2  
292 3  
293 3  
294 2
```

*EJECT

346 2 END;

```

$IF EXTENDED_MONITOR
P_EHSM: PROCEDURE EXTERNAL;
END;
P_XHEM: PROCEDURE EXTERNAL;
END;
$ENDIF
    
```

347 1 P_DK: PROCEDURE EXTERNAL;

348 2 END;

349 1 P_EK: PROCEDURE EXTERNAL;

350 2 END;

351 1 P_EKPS: PROCEDURE EXTERNAL;

352 2 END;

353 1 P_XKPS: PROCEDURE EXTERNAL;

354 2 END;

355 1 P_EVVM: PROCEDURE EXTERNAL;

356 2 END;

357 1 P_XRVM: PROCEDURE EXTERNAL;

358 2 END;

359 1 P_EMRA: PROCEDURE EXTERNAL;

360 2 END;

361 1 P_XWRAP: PROCEDURE EXTERNAL;

362 2 END;

\$IF EXTENDED_MONITOR

P_BAUD: PROCEDURE EXTERNAL;

END;

\$ENDIF

363 1 P_RES: PROCEDURE EXTERNAL;

364 2 END;

365 1 P_RM: PROCEDURE EXTERNAL;

366 2 END;

367 1 P_SM: PROCEDURE EXTERNAL;

368 2 END;

369 1 P_COLOR: PROCEDURE EXTERNAL;

370 2 END;

371 1 P_IDENT: PROCEDURE EXTERNAL;

372 2 END;

373 1 P_IVT52: PROCEDURE EXTERNAL;

374 2 END;

375 1 P_XMTC: PROCEDURE EXTERNAL;

376 2 END;

377 1 P_XMTC: PROCEDURE EXTERNAL;

378 2 END;

379 1 P_XMISL: PROCEDURE EXTERNAL;

380 2 END;

381 1 P_XMTP: PROCEDURE EXTERNAL;

382 2 END;

\$ ELSE

\$ EJECT

```

/*
 * P_CUP -- Perform Cursor Up
 *
 * P_CUP moves the cursor up one line. This will NOT
 * move the cursor off of the status line. If the
 * cursor is currently on line-0, then no action is
 * taken.
 */

```

```

P_CUP: PROCEDURE;
DO;
IF VERT_LINE < H19_PAR_SLI THEN
CALL DCA(VERT_LINE-1,HORIZ_CHAR);
END;
END;

```

```

/*
 * P_CPR -- Cursor Position Report
 *
 * 'P_CPR' reports the cursor position in the format
 * expected by the Direct Cursor Addressing escape
 * sequence.
 */

```

```

P_CPR: PROCEDURE;
DO;
CALL TEC;
CALL S%XMITC('Y');
CALL S%XMITC(VERT_LINE+' ');
CALL S%XMITC(HORIZ_CHAR+' ');
END;

```

```

/*
 * P_DCA -- Perform Director Cursor Addressing
 *
 * P_DCA sets the cursor to the specified address.
 * this routine invokes the 'DCA' routine to per-
 * form the cursor addressing, and assumes that
 * the operands to the escape sequence are in the
 * operand buffer. The first byte is assumed to
 * be the row, and the second the column. The bytes
 * are as in the H-19/VT-52, which means that the
 * values are offset by the value of the space char...
 */

```

```
P_RLF:      PROCEDURE;  
DO;  
IF  
    VERT_LINE = H19_PAR_SLI THEN  
    RETURN;  
ELSE IF VERT_LINE <> 0 THEN  
    VERT_LINE = VERT_LINE - 1;  
ELSE  
    CALL REV_SCROLL;  
END;  
END;
```

```
/*  
* P_SCP -- Save Cursor Position  
*  
* P_SCP saves the current cursor position so that  
* it may be restored with the appropriate escape  
* sequence. It is important to note that the be-  
* haviour to be emulated stipulates that the pos-  
* itions NOT be stacked, therefore, only one set  
* of save locations is used.  
*  
*  
*  
*/  
P_SCP:      PROCEDURE;  
DO;  
    SAVED_HORZ_CHAR = HORZ_CHAR ;  
    SAVED_VERT_LINE = VERT_LINE ;  
END;
```

#EJECT

```
/*  
* P_EROL -- Process Erase to Beginning Of Line  
*  
* P_EROL erases to the beginning of the current line,  
* including the current character.  
*  
*  
*/
```

```
P_EROL:      PROCEDURE;  
DO;  
    CALL EDC(VERT_LINE,0,HORZ_CHAR+1);  
END;
```

```
ENDS;  
ENDS;  
ENDS;
```

```
/*  
* P_ELIN -- Process Erase Line  
*  
* P_ELIN erases the entire current line.  
*/
```

```
P_ELIN: PROCEDURE PUBLIC;  
DO;  
CALL EDL(VERT_LINE);  
ENDS;  
ENDS;
```

```
/*  
* P_EPAG -- Erase Page  
*  
* P_EPAG erases the entire page.  
*/
```

```
P_EPAG: PROCEDURE PUBLIC;  
DO;  
IF VERT_LINE = H19_PAR.SLI  
THEN  
CALL P_ELIN;  
ELSE  
DO;  
DO LINE_INDEX=0 TO H19_PAR.SLI-1;  
CALL EDL(LINE_INDEX);  
ENDS;  
CALL P_HOM;  
IF NOT H19_MODE.STATUS THEN  
H19_MODE.BWD = (COLOR.MASK = 7);  
ENDS;  
ENDS;  
ENDS;
```

```
/*  
* P_DC -- Perform Delete Character  
*  
* P_DC deletes the character at the current character  
* position. This is done by moving the rest of the  
* line to the current character position, and deleting
```

```

THEN
DO;
DO LINE_INDEX = VERT_LINE+1 TO H19__PAR.SLI-1 ;
CALL MDL(LINE_INDEX,LINE_INDEX-1);
END;
CALL EDL(H19__PAR.SLI-1);
END;
ELSE
CALL P_ELIN;
CALL DCA(VERT_LINE,0);
END;
ENDIF

```

```

/*
*
* P_IL -- Perform Insert Line
*
* P_IL performs the insert line function. A blank line
* line is inserted at the current cursor position after
* the remaining lines have been moved down.
*/

```

```

$ IF 0=1
P_IL: PROCEDURE;
DO;
IF VERT_LINE=H19__PAR.SLI THEN
DO;
CALL P_ELIN;
RETURN;
END;

```

```

IF VERT_LINE < H19__PAR.SLI/2
THEN
DO;
CALL REV_SCROLL;
DO LINE_INDEX=1 TO VERT_LINE ;
CALL MDL(LINE_INDEX,LINE_INDEX-1);
END;
ELSE

```

```

DO;
LINE_INDEX=H19__PAR.SLI-1;
DO WHILE LINE_INDEX <> VERT_LINE ;
CALL MDL(LINE_INDEX-1,LINE_INDEX);
LINE_INDEX=LINE_INDEX-1;
END;

```

```

END;
CALL P_ELIN;
END;
ELSE
P_IL: PROCEDURE;

```

```
/*  
 * P_EAM -- Enter ANSI Mode  
 *  
 * 'P_EAM' enters ANSI Mode, which means that the  
 * extended mode flag is set for external user  
 * processing.  
 */
```

```
P_EAM: PROCEDURE;  
DO;  
  H19_MODE.ANSI = TRUE;  
END;  
END;
```

```
/*  
 * P_EICM -- Process Enter Insert Character Mode  
 *  
 * P_EICM processes the insert character mode escape  
 * sequence. It merely sets the global boolean to  
 * true.  
 */
```

```
P_EICM: PROCEDURE;  
DO;  
  H19_MODE.INSERT = TRUE;  
END;  
END;
```

```
/*  
 * P_XICM -- Process Exit Insert Character Mode  
 *  
 * P_XICM processes the Exit insert character mode  
 * escape sequence. It merely sets the global bool-  
 * ean to FALSE.  
 */
```

```
P_XICM: PROCEDURE;  
DO;  
  H19_MODE.INSERT = FALSE;  
END;  
END;
```

```
*
*      P_XHSM - Exit Hold-Screen Mode
*
*      'P_XHSM' exits the Hold-Screen Mode by setting the
*      boolean H19_MODE.HOLD to FALSE.
*
*/

$      IF EXTENDED_MONITOR
P_XHSM:
  PROCEDURE;
DO;
  END;
END;
$      ENDIF

/*
*      P_DK - Disable Keyboard
*
*      'P_DK' disables the key-board.
*
*/

P_DK:
  PROCEDURE;
DO;
  CALL WRITK(KC_KBD);
  H19_MODE.KEY_EN = FALSE;
END;

/*
*      P_EK - Enable Key-Board
*
*      'P_EK' enables the key-board.
*
*/

P_EK:
  PROCEDURE;
DO;
  CALL WRITK(KC_KBE);
  H19_MODE.KEY_EN = TRUE;
END;

/*
*      P_EKPS - Enter Key-Pad Shifted Mode
*
*      'P_EKPS' enters the key-pad shifted mode by
*      merely setting the boolean 'H19_MODE.SHIFTED'
*/
```



```
* # zeroes for invoking the display font character  
* # procedure.  
*/
```

```
P_XRVM: PROCEDURE;  
DO;  
  H19_MODE.REVERSE = 00000H;  
END;  
*/
```

```
/*  
* # P_EWRAP -- Enter Wrap Mode  
* #  
* # 'P_EWRAP' enters the H19 character wrap mode  
* # by setting the global H19_MODE.WRAP to TRUE.  
* #  
*/
```

```
P_EWRAP: PROCEDURE;  
DO;  
  H19_MODE.WRAP = TRUE;  
END;  
*/
```

```
/*  
* # P_XWRAP -- Exit Wrap Mode  
* #  
* # 'P_XWRAP' exits the H19 character wrap mode  
* # by setting the global H19_MODE.WRAP to FALSE.  
* #  
*/
```

```
P_XWRAP: PROCEDURE;  
DO;  
  H19_MODE.WRAP = FALSE;  
END;  
*/
```

#EJECT

```
/*  
* # P_BAUD -- Process Baud Rate  
* #
```

```

*
* > -- Disable Function-Key Expansion
* @ -- Disable Key-Board Up/Down Mode
*/

```

P_ARM: PROCEDURE;

```

DO;
IF '1' <= ESCP.OPERAND(0) AND ESCP.OPERAND(0) <= 'e' THEN
DO CASE ESCP.OPERAND(0) '1' ;

```

```

/* 1 */

```

```

DO;
H19_MODE.STATUS = FALSE;
CALL EDL(H19_PAR.SLI);
CALL ENABLE_LINES(H19_PAR.SLI);
END;

```

```

/* 2 */

```

```

CALL P_UIM;
/* 3 */

```

```

CALL SCP1(NOT CSR_CSD,
H19_PAR.SPC-3);
/* 4 */

```

```

DO;
H19_MODE.CURSOR_ON = TRUE;

```

```

CALL SCP;
END;
/* 5 */

```

```

CALL P_XRPS;
/* 6 */

```

```

CALL P_XAKM;
/* 7 */

```

```

H19_MODE.AUTO_LF = FALSE;
/* 8 */

```

```

H19_MODE.AUTO_CR = FALSE;
/* 9 */

```

```

CALL P_UIM;
/* : */

```

```

CALL SCP1(CSR_CSD,
CSR_BLINK16);
/* ; */

```

```

CALL WRITK(KC_ARO);
/* < */

```

```

CALL P_UIM;
/* = */

```

```

CALL P_UIM;
/* > */

```

```

H19_MODE.EXPAND = FALSE;
/* ? */

```

```

DO;
H19_MODE.UPDN = FALSE;

```

```

CALL WRITK(KC_MNS);
END;
/* @ */

```

```

END;

```

```
CALL P_EKPS; /* 6 */
CALL P_EAKM; /* 7 */
H19_MODE.AUTO_LF = TRUE; /* 8 */
H19_MODE.AUTO_CR = TRUE; /* 9 */
CALL P_UIM; /* : */
CALL SCPI(NOT CSR_BLINK,0); /* ; */
CALL WRITK(KC_ARF); /* < */
CALL P_UIM; /* = */
CALL P_UIM; /* > */
H19_MODE.EXPAND = TRUE; /* ? */
DO; /* @ */
H19_MODE.UFDN = TRUE;
CALL WRITK(KC_MUD);
END;
END;
END;
```

#EJECT

```
P_COLOR: PROCEDURE;
DO;
IF ('0' <= ESCP_OPERAND(0) AND ESCP_OPERAND(0) <='7') AND
('0' <= ESCP_OPERAND(1) AND ESCP_OPERAND(1) <='7')
CALL SCA(ESCP_OPERAND(0)..'0',ESCP_OPERAND(1)..'0');
END;
END;
```

```
P_IDENT: PROCEDURE;
DO;
IF ESCP_OPERAND(0) = '0' THEN
DO;
CALL TEC;
CALL S$XMT('1');
CALL S$XMT('E');

```

```
CALL XMTSC(H19_PAR.SL1,0,H19_PAR.CPL);  
ELSE  
CALL S*XMTC(CR);  
END;  
END;
```

```
P_XMTP: PROCEDURE;  
DO;  
CALL XMTSC(0,0,H19_PAR.CPL*(H19_PAR.LPS-1));  
END;  
END;
```

```
* ENDIF
```

```
383 1 END;
```

```

00BD B15E MOV CL,SEH
00BF 8A4604 MOV AL,[BP].CHAR
00C2 3AC8 CMP CL,AL
00C4 770F JA @6
00C6 B27F MOV DL,ZFH
00C8 3ACC CMP AL,DL
00CA 7309 JNB @6
; STATEMENT # 215
00CC 2AC1 SUB AL,CL
00CE 02C2 ADD AL,DL
00D0 FED0 INC AL
00D2 50 PUSH AX
; STATEMENT # 216
00D3 EB03 JMP @2
; STATEMENT # 216
00D5 FF7604 @6: PUSH [BP].CHAR; 1
00D8 E30000 @2: CALL D_CRT
; STATEMENT # 218
00DB EB57 @3: JMP @1
00DD A00100 @5: MOV AL,H19_MODE+1H
00E0 D0D8 RCR AL,1
00E2 7307 JNB @7
; STATEMENT # 219
00E4 C606030003 MOV ESCP+3H,3H
; STATEMENT # 220
00E7 EB49 @1: JMP @1
00EB C606030001 @7: MOV ESCP+3H,1H
; STATEMENT # 222
00F0 EB42 @11: JMP @1
00F2 8A4604 @1: MOV AL,[BP].CHAR
; STATEMENT # 223
00F5 A20000 MOV ESCP,AL
; STATEMENT # 224
00F8 50 PUSH AX
; STATEMENT # 225
00F9 EB7F00 DDCC DDCC
; STATEMENT # 226
00FC A20400 MOV ESCP+4H,AL
; STATEMENT # 227
00FE C606050000 MOV ESCP+5H,0H
; STATEMENT # 228
0104 C606030002 MOV ESCP+3H,2H
; STATEMENT # 227
0109 08C0 OR AL,AL
; STATEMENT # 231
010B EB17 @13: JMP @7
; STATEMENT # 232
010D 8A1E0500 MOV BL,ESCP+5H
0111 B700 BH,0H
0113 8A4604 AL,[BP].CHAR
0116 88870600 ESCP[BP+6H],AL
; STATEMENT # 232
011A FE03 INC BL

```


CROSS-REFERENCE LISTING

Address	Hex	Label	Description	Start	End	Count
69	0000H	CSR_OFF	LITERALLY '01#0000B'			
157	0000H	CURSOR	PROCEDURE EXTERNAL(46) STACK=0000H			
2		DC	LITERALLY 'DECLARE'			
			10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40			
			41 42 43 44 45 46 47 48 49 50 51 52			
			53 54 55 56 57 58 59 60 61 62 63 64			
			65 66 67 68 69 70 71 72 73 74 75 76			
			77 78 79 80 81 82 83 84 85 86 87 88			
			89 90 91 92 93 94 95 96 97 98 99 100			
			101 102 103 104 105 106 107 108 109 110 111 112			
			113 114 115 116 117 118 119 120 121 122 123 124			
			125 126 127 128 129 130 131 132 133 134 135 136			
			137 138 139 140 141 142 143 144 145 146 147 148			
			185 186 187 188			
244	0138H	DCA	PROCEDURE PUBLIC STACK=0006H			
79	0000H	DC1	POINTER EXTERNAL(11)			
11	0000H	DEL	LITERALLY '07FH'	214	215	
80	0000H	DFC	POINTER EXTERNAL(12)			
95	0000H	DMAF	BYTE ARRAY(256) EXTERNAL(27)			
255	017BH	DOC	PROCEDURE BYTE STACK=0004H			
77	0000H	DS_SIZE	WORD EXTERNAL(9)	224		
21	0000H	DXMIC	PROCEDURE EXTERNAL(0) STACK=0000H			
159	0000H	O_CRT	PROCEDURE EXTERNAL(47) STACK=0000H			
162	0000H	D_TTY_RES	PROCEDURE EXTERNAL(48) STACK=0000H			
31	0000H	O_XMITC	POINTER EXTERNAL(13)			
82	0000H	EDC	POINTER EXTERNAL(14)	287		
284	0239H	EMEC	PROCEDURE PUBLIC STACK=000EH			
83	0000H	ENABLE_LINES	POINTER EXTERNAL(15)			
163	0000H	EOL	PROCEDURE EXTERNAL(51) STACK=0000H			
12		EOS	LITERALLY '080H'			
13		ESC	LITERALLY '01BH'	212		
14		ESC	STRUCTURE EXTERNAL(38)			
109	0000H	ESCP	BYTE 223* 237* 269 270 271 272 273 275 276 277			
		COMMAND				
		FUNCTION	WORD 270* 272* 274* 276* 278* 279* 280			
		MODE	BYTE 198* 210 219* 220* 226* 268*			
		OPER_COUNT	BYTE 224* 227 233			
		OPER_INDEX	BYTE 225* 232* 232 233			
		OPERAND	BYTE ARRAY(4)	231*		
		ESC_TABLE_1	WORD ARRAY(20) DATA	270		
		ESC_TABLE_2	WORD ARRAY(7) DATA	272		
		ESC_TABLE_3	WORD ARRAY(21) DATA	276		
		FALSE	LITERALLY '000H'	200		
		FF	LITERALLY '00CH'			
		FLAGS	PROCEDURE WORD EXTERNAL(1) STACK=0000H			
		FONT	POINTER EXTERNAL(16)			
		FONT_SIZE	WORD EXTERNAL(25)			
		FOKE	BYTE IN PROC (SCA) PARAMETER	172		
		H19CRT	PROCEDURE STACK=0000H			
		H19_MODE	STRUCTURE EXTERNAL(39)			
		ALTERNATE	BYTE 200*			
		ANSI	BYTE 200* 218			
		AUTO_CR	BYTE			
		AUTO_LF	BYTE			
		AUTO_REPEAT	BYTE			

CROSS-REFERENCE LISTING

Line	Address	Label	Symbol	Start	End	Start	End	Start	End
135	0000H	KY_F12	LITERALLY '0A2H'	11	12	13	14	15	16
133	0000H	KY_HELP	LITERALLY '095H'	42	43	44	45	46	47
142	0000H	KY_HOME	LITERALLY '0A9H'	54	55	56	57	58	59
136	0000H	KY_ID_CHAR	LITERALLY '0A3H'	66	67	68	69	70	71
137	0000H	KY_ID_LINE	LITERALLY '0A4H'	113	114	115	116	117	118
146	0000H	KY_KP_0	LITERALLY '0B0H'	125	126	127	128	129	130
147	0000H	KY_KP_9	LITERALLY '0B9H'	137	138	139	140	141	142
144	0000H	KY_KP_MINUS	LITERALLY '0ADH'	186	187	188	189		
145	0000H	KY_KP_PERIOD	LITERALLY '0AEH'						
141	0000H	KY_LEFT	LITERALLY '0A8H'						
140	0000H	KY_RIGHT	LITERALLY '0A7H'						
148	0000H	KY_SHIFT_OFFSET	LITERALLY '0A5H'						
138	0000H	KY_UP	LITERALLY '00AH'						
17	0004H	LF	BYTE IN PROC (EDL) PARAMETER AUTOMATIC						
285	0000H	LINE	BYTE IN PROC (ENABLE_LINES) PARAMETER						
169	0000H	LINES	BYTE IN PROC (ENABLE_LINES) PARAMETER						
190	0000H	LINE_INDEX	BYTE PUBLIC						
3	0000H	LF	LITERALLY 'LITERALLY'	11	12	13	14	15	16
177	0000H	MASK	POINTER EXTERNAL(17)	177					
85	0000H	MDC	POINTER EXTERNAL(18)						
86	0000H	MDL	LITERALLY '54H'						
74		MTR_ISSUE	LITERALLY '12H'						
73		MTR_VERSION	LITERALLY '3'						
189		M_ANS	LITERALLY '1'						
187		M_ESC	LITERALLY '0'						
186		M_NRM	LITERALLY '2'						
188		M_OPR	BYTE ARRAY(14) DATA						
254	0060H	OPC	POINTER STACK=0004H	260	263				
266	01ADH	PES	POINTER EXTERNAL(19)	228	234				
87	0000H	PSP	BYTE EXTERNAL(32)						
100	0000H	P_CDN	PROCEDURE EXTERNAL(58) STACK=0000H	193					
295	0000H	P_CLF	PROCEDURE EXTERNAL(59) STACK=0000H	193					
297	0000H	P_COLGR	PROCEDURE EXTERNAL(95) STACK=0000H	195					
369	0000H	P_CPLR	PROCEDURE EXTERNAL(62) STACK=0000H	195					
303	0000H	P_CPR	PROCEDURE EXTERNAL(60) STACK=0000H	193					
299	0000H	P_CRT	PROCEDURE EXTERNAL(61) STACK=0000H	193					
301	0000H	P_CUP	PROCEDURE EXTERNAL(74) STACK=0000H	193					
327	0000H	P_DC	PROCEDURE EXTERNAL(63) STACK=0000H	194					
305	0000H	P_DCA	PROCEDURE EXTERNAL(84) STACK=0000H	195					
347	0000H	P_DK	PROCEDURE EXTERNAL(75) STACK=0000H	193					
329	0000H	P_DL	PROCEDURE EXTERNAL(77) STACK=0000H	193					
333	0000H	P_EAKM	PROCEDURE EXTERNAL(79) STACK=0000H	193					
337	0000H	P_EAM	PROCEDURE EXTERNAL(68) STACK=0000H	195					
315	0000H	P_EBOL	PROCEDURE EXTERNAL(70) STACK=0000H	193					
317	0000H	P_EBOP	PROCEDURE EXTERNAL(71) STACK=0000H	193					
319	0000H	P_EEDL	PROCEDURE EXTERNAL(82) STACK=0000H	193					
321	0000H	P_EEOP							
343	0000H	P_EGM							

SERIES--III 8086/8087/8088 MACRO ASSEMBLER V1.0 ASSEMBLY OF MODULE H19_CRT_A86
 OBJECT MODULE PLACED IN :F2:H19A.OBJ
 INVOCATION LINE CONTROLS: PRINT(:TO:) XREF ERRORPRINT(:TO:)

LOC	OBJ	LINE	SOURCE
		1	;; h19crt.a86
		2	;;
		3	;;
		4	;; These routines are optimized PL/M-86 routines.
		5	;; The output of the PL/M-86 compiler has been
		6	;; extensively 'filtered' to produce files which
		7	;; contain optimized code. The basic optimization
		8	;; was to eliminate the procedure prologue/epilogue
		9	;; code for procedures which pass no parameters.
		10	;; This consists of reducing the following:
		11	;;
		12	xxxx PROC NEAR
		13	PUSH BP
		14	MOV BP,SP
		15	:
		16	POP BP
		17	RET
		18	xxxx ENDP
		19	;;
		20	to:
		21	;;
		22	xxxx PROC NEAR
		23	:
		24	:
		25	RET
		26	xxxx ENDP
		27	;;
		28	;; This saves at least four bytes of code for each
		29	;; of the procedures involved.
		30	;;
		31	;;
		32	+1 \$ EJECT

LOC	OBJ	LINE	SOURCE
00003		87	AUTO_LF DB ? ; Auto Line-Feed on Carriage-Return
00004		88	AUTO_REPEAT DB ? ; Auto-Repeat Keyboard
00005		89	BWD DB ? ; Black and White Optimization
00006		90	CURSOR DB ? ; Programmed Cursor Value
00007		91	CURSOR_ON DB ? ; Cursor Enabled
00008		92	EXPAND DB ? ; Expand Key-Board Characters
00009		93	GRAPHIC DB ? ; Graphic Character Mode
0000A		94	INSERT DB ? ; Insert Character Mode
0000B		95	KEY_EN DB ? ; Key-Board Enable
0000C		96	REVERSE DB ? ; Reverse Video
0000E		97	SHIFTED DB ? ; Shifted Key-Pad Mode
0000F		98	STATUS DB ? ; Status-Line Enabled
0010		99	UPDN DB ? ; Key-Board Up/Down Mode
0011		100	WRAP DB ? ; Wrap at End-of-Line
		101	H19_MCODE_STRUC ENDS
		102	
		103	H19_PAR_STRUC STRUC
0000		104	CPL DB ? ; Characters Per Line
0001		105	DSC DB ? ; Displayed Scan Lines per Character
0002		106	LPS DB ? ; Lines Per Screen
0003		107	POVRAM DB ? ; Planes of Video RAM
0004		108	SLI DB ? ; Status Line Index
0005		109	SPC DB ? ; Scan Lines per Character
0006		110	SM401 DB ? ; H19-Switch 401
0007		111	SM402 DB ? ; H19-Switch 402
0008		112	VRAM_SIZE DB ? ; 0-32KBytes, 1-64KBytes
		113	H19_PAR_STRUC ENDS
		114	
		115	XMT_STRUC STRUC
0000		116	BURST DB ? ; Characters to Transmit per VSYNC
0001		117	RCOUNT DW ? ; Remaining Characters in current Burst
0003		118	COUNT DW ? ; Characters left to Transmit
0005		119	COL DB ? ; Horizontal Column to Transmit
0006		120	ROW DB ? ; Vertical Row to Transmit
0007		121	XMT_COLOR DB ? ; Current COLOR State Transmitted
0008		122	XMT_GRAPHIC DB ? ; Current GRAPHIC State Transmitted
0009		123	XMT_REVERSE DB ? ; Current REVERSE State Transmitted
		124	XMT_STRUC ENDS
		125	
		126	
		127	
		128	
		129	
		130	
		131	
		132	
		133	
		134	
		135	
		136	
		137	
		138	

Globals Definitions

```

%IF(%NES(ASTLIB,%SEGMENT_LABEL)) THEN (
  ASTLIB SEGMENT BYTE PUBLIC 'CODE'
  EXTRN VIDEO_INTR_A: FAR
  ENDS
)FI
  
```

```

%IF(%NES(FONTAB,%SEGMENT_LABEL)) THEN (
  FONTAB SEGMENT BYTE PUBLIC 'DATA'
  EXTRN MTR_FONT: BYTE
  ENDS
  
```

LOC	OBJ	LINE	SOURCE
=1			EXTRN DFC:DWORD ; Display Font Character
=1			EXTRN D_XMTC:DWORD ; Dumb Terminal Transmit Character
=1			EXTRN EDC:DWORD ; Erase Display Character
=1			EXTRN EMEC:DWORD ; Extend-Mode Escape Character
=1			EXTRN FONT:DWORD ; Pointer to Font Table
=1			EXTRN MDC:DWORD ; Move Display Character
=1			EXTRN MDL:DWORD ; Move Display Line
=1			EXTRN PROMPT:DWORD ; Display Monitor Prompt
=1			EXTRN RDC:DWORD ; Read Display Character
=1			EXTRN S_XMTC:DWORD ; Smart Terminal Transmit Character
=1			EXTRN UIES:DWORD ; Un-Implemented Escape Sequence
=1			EXTRN XCA:DWORD ; Transmit Character Attributes
=1			EXTRN BOOT_PAR:BOOT_PAR_STRUC
=1			EXTRN COLOR:COLOR_STRUC
=1			EXTRN CRIC_CURSOR:CRIC_STRUC
=1			EXTRN CRIC_DISPLAY:CRIC_STRUC
=1			EXTRN ESCP:ESCP_STRUC
=1			EXTRN H19_MODE:H19_MODE_STRUC
=1			EXTRN H19_PAR:H19_PAR_STRUC
=1			EXTRN XMT:XMT_STRUC
=1			ENDS
		218	DATA
		219)FI
		220	XIF(2NES(VIDEQA,2SEGMENT LABEL)) THEN (
			VIDEQA SEGMENT BYTE PUBLIC 'CODE'
			VIDEQA)FI
			ENDS
		224	
		225	
		226	CGROUP GROUP MTR100, CODE,ASTLIB,VIDEQA
		227	
		228	
		229	\$RESTORE
		230	
		231	\$EJECT

LOC	OBJ	LINE	SOURCE	ENDP	STATEMENT #
0018		287	P_CDN	ENDP	301
		288			
		289	P_CLF	PROC NEAR	
		290		PUBLIC P_CLF	
		291		PUSH BP	
		292		MOV BP,SP	
		293			
0018	A00000	294		MOV AL,HORZ_CHAR	303
001B	0AC0	295		OR AL,AL	
001D	740A	296		JZ @34	
		297			
001F	FF360000	298		PUSH WORD PTR VERT_LINE, 1	304
0023	FEC8	299		DEC AL	
0025	50	300		PUSH AX	
0026	E80000	301		CALL DCA	2
0029		302	@34:		
		303			
		304		POP BP	STATEMENT # 306
0029	C3	305		RET	
		306		ENDP	
		307			
002A		308	P_CRT	PROC NEAR	307
		309		PUBLIC P_CRT	
		310		PUSH BP	
		311		MOV BP,SP	
		312			
002A	FF360000	313		PUSH WORD PTR VERT_LINE, 1	309
002E	A00000	314		MOV AL,HORZ_CHAR	
0031	FEC0	315		INC AL	
0033	50	316		PUSH AX	2
0034	E80000	317		CALL DCA	
		318			
		319		POP BP	STATEMENT # 311
0037	C3	320		RET	
		321		ENDP	
		322			
0038		323	P_CUP	PROC NEAR	312
		324		PUBLIC P_CUP	
		325		PUSH BP	
		326		MOV BP,SP	
		327			
0038	A00000	328		MOV AL,VERT_LINE	314
003B	3A060400	329		CMP AL,H19_PAR_SLI	
003F	730A	330		JNB @35	
		331			
		332			
0041	FEC8	333		DEC AL	STATEMENT # 315
0043	50	334		PUSH AX	
0044	FF360000	335		PUSH WORD PTR HORZ_CHAR, 2	
0048	E80000	336		CALL DCA	
004B		337	@35:		
		338		POP BP	STATEMENT # 317
		339		RET	
		340		ENDP	
		341			STATEMENT # 318

LOC	OBJ	LINE	SOURCE	CODE	COMMENT
0082		397	P_HDM	ENDP	
		398			; STATEMENT # 336
		399	P_RCP	PROC NEAR	
		400		PUBLIC P_RCP	
		401		PUSH BP	
		402		MOV BP,SP	
		403			; STATEMENT # 338
0082	FF360000	404		PUSH	WORD PTR SAVED_VERT_LINE; 1
0086	FF360000	405		PUSH	WORD PTR SAVED_HORZ_CHAR; 2
008A	EB0000	406		CALL	DCA
		407			; STATEMENT # 340
008D	C3	408		POP BP	
		409		RET	
		410	P_RCP	ENDP	
		411			; STATEMENT # 341
008E		412	P_RLF	PROC NEAR	
		413		PUBLIC P_RLF	
		414		PUSH BP	
		415		MOV BP,SP	
		416			; STATEMENT # 343
008E	A00000	417		MOV	AL,VERT_LINE
0091	3A060400	418		CMP	AL,H19_PAR_SLI
0095	7501	419		JNZ	@36
		420			; STATEMENT # 344
0097	C3	421		POP BP	
		422		RET	
		423			; STATEMENT # 345
0098	803E000000	424	@36:	CMPL	VERT_LINE,0H
009D	7405	426		JZ	@38
		427			; STATEMENT # 346
009F	FE0E0000	428		DEC	VERT_LINE
		429			; STATEMENT # 347
00A3	C3	430		POP BP	
00A4		431		RET	
00A4	EB0000	432	@38:	CALL	REV_SCROLL
		433			; STATEMENT # 349
00A7	C3	434		POP BP	
		435		RET	
		436			; STATEMENT # 350
00A8		437	P_RLF	ENDP	
		438			; STATEMENT # 350
00A8		439	P_SCP	PROC NEAR	
		440		PUBLIC P_SCP	
		441		PUSH BP	
		442		MOV BP,SP	
		443			; STATEMENT # 352
00A8	A00000	444		MOV	AL,HORZ_CHAR
00AB	A20000	445		MOV	SAVED_HORZ_CHAR,AL
		446			; STATEMENT # 353
00AE	A00000	447		MOV	AL,VERT_LINE
00B1	A20000	448		MOV	SAVED_VERT_LINE,AL
		449			; STATEMENT # 355
00B4	C3	450		POP BP	
		451		RET	

LOC	OBJ	LINE	SOURCE
00F7	FF360000	507	PUSH BP
00FB	A00000	508	MOV BP,SP
00FE	50	509	;
00FF	A00000	510	PUSH WORD PTR VERT_LINE; 1
0102	2A060000	511	MOV AL,HORZ_CHAR
0106	50	512	PUSH AX
0107	FF1E0000	513	MOV AL,H19_PAR,CPL
		514	SUB AL,HORZ_CHAR
		515	PUSH AX
		516	CALL EDC
		517	;
010B	C3	518	POP BP
		519	RET
		520	ENDP
		521	;
010C		522	PROC NEAR
		523	PUBLIC P_EEOP
		524	PUSH BP
		525	MOV BP,SP
		526	;
		527	CALL P_EEOL
		528	;
		529	MOV AL,VERT_LINE
		530	INC AL
		531	MOV LINE_INDEX,AL
		532	;
		533	MOV AL,H19_PAR,SLI
		534	DEC AL
		535	MOV CL,LINE_INDEX
		536	CL,AL
		537	CMF CL,AL
		538	JA @44
		539	;
		540	PUSH CX
		541	CALL EDI
		542	;
		543	INC LINE_INDEX
		544	JNZ @43
		545	;
		546	POP BP
		547	RET
		548	ENDP
		549	;
012E	C3	550	PROC NEAR
		551	PUBLIC P_ELIN
		552	PUSH BP
		553	MOV BP,SP
		554	;
		555	MOV WORD PTR VERT_LINE; 1
		556	CALL EDI
		557	;
		558	POP BP
		559	RET
		560	ENDP
		561	;

LOC	OBJ	LINE	SOURCE
0181	B400	617	MOV AH,0H
0183	50	618	PUSH AX ; 2
0184	A00000	619	MOV AL,HORZ_CHAR
0187	50	620	PUSH AX ; 3
0188	A00000	621	MOV AL,H19_PAR_CPL
018B	2A060000	622	SUB AL,HORZ_CHAR
018F	FEC8	623	DEC AL
0191	B400	624	MOV AH,0H
0193	50	625	PUSH AX ; 4
0194	FF1E0000	626	CALL MDC
0198	FF360000	627	WORD PTR VERT_LINE; 1 ; STATEMENT # 407
019C	A00000	628	MOV AL,H19_PAR_CPL
019F	FEC8	629	DEC AL
01A1	B400	630	MOV AH,0H
01A3	50	631	PUSH AX ; 2
01A4	B001	632	MOV AL,1H
01A6	50	634	PUSH AX ; 3
01A7	FF1E0000	635	CALL EDC
01AB	C3	636	POP BP ; STATEMENT # 409
		637	RET
		638	ENDP
01AC		639	P_PDC ; STATEMENT # 410
		640	PROC NEAR
		641	P_DL P_DL
		642	PUBLIC P_DL
		643	PUSH BP
		644	MOV BP,SP
		645	MOV AL,VERT_LINE ; STATEMENT # 412
		646	MOV AL,H19_PAR_SLI
		647	MOV AL,H19_PAR_SLI
		648	MOV AL,H19_PAR_SLI
		649	JZ ; STATEMENT # 414
		650	INC AL
		651	MOV LINE_INDEX,AL
		652	MOV AL,H19_PAR_SLI ; STATEMENT # 415
		653	DEC AL
		654	MOV CL,LINE_INDEX
		655	MOV CL,AL
		656	MOV CL,AL
		657	MOV CL,AL
		658	MOV CL,AL
		659	MOV CL,AL
		660	MOV CL,AL
		661	MOV CL,AL
		662	MOV CL,AL
		663	MOV CL,AL
		664	MOV CL,AL
		665	MOV CL,AL
		666	MOV CL,AL
		667	MOV CL,AL
		668	MOV CL,AL
		669	MOV CL,AL
		670	MOV CL,AL
		671	MOV CL,AL

LOC	OBJ	LINE	SOURCE
0229		727	P_EAKM PROC NEAR
		728	PUBLIC P_EAKM
		729	PUSH BP
		730	MOV BP,SP
		731	;
		732	MOV H19_MODE,ALTERNATE,0FFH
		733	;
		734	POP BP
		735	RET
		736	ENDP
		737	;
		738	PROC NEAR
		739	PUBLIC P_XAKM
		740	PUSH BP
		741	MOV BP,SP
		742	;
		743	MOV H19_MODE,ALTERNATE,0H
		744	;
		745	POP BP
		746	RET
		747	ENDP
		748	;
		749	PROC NEAR
		750	PUBLIC P_EAM
		751	PUSH BP
		752	MOV BP,SP
		753	;
		754	MOV H19_MODE,ANG1,0FFH
		755	;
		756	POP BP
		757	RET
		758	ENDP
		759	;
		760	PROC NEAR
		761	PUBLIC P_EICM
		762	PUSH BP
		763	MOV BP,SP
		764	;
		765	MOV H19_MODE,INSERT,0FFH
		766	;
		767	POP BP
		768	RET
		769	ENDP
		770	;
		771	PROC NEAR
		772	PUBLIC P_XICM
		773	PUSH BP
		774	MOV BP,SP
		775	;
		776	MOV H19_MODE,INSERT,0H
		777	;
		778	POP BP
		779	RET
		780	ENDP
		781	;

0241 C6060A0000 E
 0246 C3
 ; STATEMENT # 457
 ; STATEMENT # 459
 ; STATEMENT # 461
 ; STATEMENT # 462

LOC	OBJ	LINE	SOURCE
0268	C6060E00FF	837	MOV BP,SP ; STATEMENT # 486
		838	MOV H19_MODE,SHIFTED,0FFH ; STATEMENT # 488
0270	C3	840	POP BP ; STATEMENT # 488
		841	RET
0271	C3	842	ENDP
		843	PROC NEAR
		844	F_XKPS
		845	PUBLIC F_XKPS
		846	PUSH BP
		847	MOV BP,SP
0271	C6060E0000	849	MOV H19_MODE,SHIFTED,0H ; STATEMENT # 491
		850	POP BP ; STATEMENT # 493
		851	RET
0276	C3	852	ENDP
		853	PROC NEAR
		854	F_XKPS
		855	PUBLIC F_XKPS
0277	C3	856	PROC NEAR
		857	F_ERVM
		858	PUBLIC F_ERVM
		859	PUSH BP
		860	MOV BP,SP
0277	C7060C00FFFF	861	MOV H19_MODE,REVERSE,0FFFFH ; STATEMENT # 496
		862	POP BP ; STATEMENT # 498
		863	RET
027D	C3	864	ENDP
		865	PROC NEAR
		866	F_XRVM
		867	PUBLIC F_XRVM
		868	PUSH BP
		869	MOV BP,SP
027E	C3	871	MOV H19_MODE,REVERSE,0H ; STATEMENT # 501
		872	POP BP ; STATEMENT # 503
		873	RET
0284	C3	874	ENDP
		875	PROC NEAR
		876	F_ENRAP
		877	PUBLIC F_ENRAP
		878	PUSH BP
		879	MOV BP,SP
0285	C6061100FF	881	MOV H19_MODE,WRAP,0FFH ; STATEMENT # 506
		882	POP BP ; STATEMENT # 508
		883	RET
028A	C3	884	ENDP
		885	PROC NEAR
		886	F_XWRAP
		887	PUBLIC F_XWRAP
		888	PUSH BP
028B	C3	889	MOV H19_MODE,WRAP,0FFH ; STATEMENT # 509
		890	POP BP
		891	RET

LOC	OBJ		LINE	SOURCE			
02D1	2903	R	947		MOV		
02D3	2F03	R	948		MOV		
02D5			949	@60:			
			950				
02D5	C6060F0000	E	951		MOV		
			952				
02D6	FF360400	E	953		PUSH		
02D6	E80000	E	954		CALL		
			955				
02E1	FF360400	E	956		PUSH		
02E5	E80000	E	957		CALL		
			958				
			959		POP		
02E8	C3		960		RET		
02E9			961	@61:			
02E9	B003		962		MOV		
02EB	EB4990		963		JMP		
			964				
02EE			965	@63:			
02EE	B0E0		966		MOV		
02F0	50		967		PUSH		
02F1	A00500	E	968		MOV		
02F4	2C03		969		SUB		
02F6	EB2390		970		JMP		
			971	@64:			
			972				
02F9	C6060700FF	E	973		MOV		
			974				
02FE	E80000	E	975		CALL		
			976				
			977		POP		
0301	C3		978		RET		
0302	E86CFF		979	@65:			
			980		CALL		
			981				
0305	C3		982		POP		
0306	EB26FF		983		RET		
			984	@66:			
			985		CALL		
			986				
0309	C3		987		POP		
030A	C606030000	E	988		RET		
			989	@67:			
			990		MOV		
			991				
030F	C3		992		POP		
0310	C606020000	E	993		RET		
			994	@68:			
			995		MOV		
			996				
0315	C3		997		POP		
			998		RET		
			999				
0316	B01F		1000	@70:			
			1001		MOV		

CGROUP:@74
CGROUP:@75

; STATEMENT # 526
H19_MODE,STATUS,0H
; STATEMENT # 527

WORD PTR H19_PAR,SLI; 1
EDL
; STATEMENT # 528

WORD PTR H19_PAR,SLI; 1
ENABLE_LINES
; STATEMENT # 530

BP
; STATEMENT # 532
AL,0EH
; 1

AL,H19_PAR,SPC
AL,3H
@26

; STATEMENT # 534
H19_MODE,CURSUR_ON,0FFH
; STATEMENT # 535

SCP
; STATEMENT # 537
BP
; STATEMENT # 538

P_XKPS
BP
; STATEMENT # 539

P_XAKM
BP
; STATEMENT # 540

H19_MODE,AUTO_LF,0H
BP
; STATEMENT # 541

H19_MODE,AUTO_CR,0H
BP
; STATEMENT # 542

AL,1FH

LOC	OBJ	LINE	SOURCE
0358	7803	1057	@78: DW
0359	7503	1058	CGROUP: @79
035C	CB03	1059	CGROUP: @81
035E	9A03	1060	COROUT: @49
0362	9F03	1061	CGROUP: @83
0364	AC03	1062	CGROUP: @84
0366	B003	1063	CGROUP: @85
0368	B603	1064	CGROUP: @86
036A	CB03	1065	CGROUP: @87
036C	BC03	1066	CGROUP: @88
036E	C603	1067	CGROUP: @49
0370	CB03	1068	COROUT: @90
0372	CB03	1069	CGROUP: @91
0374	CF03	1070	CGROUP: @49
0376	DS03	1071	CGROUP: @49
0378		1072	CGROUP: @94
0378	A00F00	1073	CGROUP: @95
037B	D018	1074	; STATEMENT # 559
037D	7261	1075	AL, H19_MODE, STATUS
037F	C6060F00FF	1076	AL, 1
0384	FF360400	1077	AL, 1
0388	EB0000	1078	AL, 1
038B	A00400	1079	@76 ; STATEMENT # 561
038E	FEC0	1080	H19_MODE, STATUS, @FFH
0390	50	1081	; STATEMENT # 562
0391	EB0000	1082	WORD PTR H19_PAR, SLI; 1
0394	C3	1083	EDL
0395	B004	1084	; STATEMENT # 563
0397	EB4390	1085	AL, H19_PAR, SLI
039A	BE00	1086	AL
039C	EB2090	1087	AX ; 1
039F		1088	ENABLE_LINES
039F	C606070000	1089	; STATEMENT # 566
03A4	EB0000	1090	POP BP
03A7	C3	1091	RET
03A8	EB0000	1092	RET
03A8	EB0000	1093	@81: MOV AL, 4H
03A8	EB0000	1094	JMP @42 ; STATEMENT # 568
03A8	EB0000	1095	
03A8	EB0000	1096	@83: MOV AL, @E0H
03A8	EB0000	1097	JMP @37
03A8	EB0000	1098	
03A8	EB0000	1099	@84: MOV H19_MODE, CURSOR_CN, 0H
03A8	EB0000	1100	CALL ; STATEMENT # 570
03A8	EB0000	1101	CALL ; STATEMENT # 571
03A8	EB0000	1102	CALL ; STATEMENT # 573
03A8	EB0000	1103	CALL ; STATEMENT # 573
03A8	EB0000	1104	CALL ; STATEMENT # 573
03A8	EB0000	1105	CALL ; STATEMENT # 573
03A8	EB0000	1106	CALL ; STATEMENT # 573
03A8	EB0000	1107	CALL ; STATEMENT # 573
03A8	EB0000	1108	CALL ; STATEMENT # 573
03A8	EB0000	1109	CALL ; STATEMENT # 573
03A8	EB0000	1110	CALL ; STATEMENT # 573
03A8	EB0000	1111	CALL ; STATEMENT # 573

LOC	OBJ	LINE	SOURCE	LOC	OBJ	LINE	SOURCE
03E1	A00600	1171	MOV	03E1	A00600	1171	MOV
03E4	B130	1172	MOV	03E4	B130	1172	MOV
03E6	3AC8	1173	CMP	03E6	3AC8	1173	CMP
03E8	7720	1174	JA	03E8	7720	1174	JA
03EA	B237	1175	MOV	03EA	B237	1175	MOV
03EC	3AC2	1176	CMP	03EC	3AC2	1176	CMP
03EE	771A	1177	JA	03EE	771A	1177	JA
03F0	A00700	1178	MOV	03F0	A00700	1178	MOV
03F3	3AC8	1179	CMP	03F3	3AC8	1179	CMP
03F5	7713	1180	JA	03F5	7713	1180	JA
03F7	3AC2	1181	CMP	03F7	3AC2	1181	CMP
03F9	770F	1182	JA	03F9	770F	1182	JA
03FB	A00600	1183	MOV	03FB	A00600	1183	MOV
03FE	2AC1	1184	SUB	03FE	2AC1	1184	SUB
0400	50	1185	PUSH	0400	50	1185	PUSH
0401	A00700	1187	MOV	0401	A00700	1187	MOV
0404	2AC1	1188	SUB	0404	2AC1	1188	SUB
0406	50	1189	PUSH	0406	50	1189	PUSH
0407	E80000	1190	CALL	0407	E80000	1190	CALL
040A		1191		040A		1191	
040A	C3	1192	POP	040A	C3	1192	POP
040A	C3	1193	RET	040A	C3	1193	RET
040A	C3	1194		040A	C3	1194	
040A	C3	1195		040A	C3	1195	
040A	C3	1196		040A	C3	1196	
040B		1197		040B		1197	
040B		1198		040B		1198	
040B		1199		040B		1199	
040B		1200		040B		1200	
040B		1201		040B		1201	
040B		1202		040B		1202	
0410	7521	1203	JNZ	0410	7521	1203	JNZ
0410	7521	1204		0410	7521	1204	
0412	E82F00	1205	CALL	0412	E82F00	1205	CALL
0415	B069	1206	MOV	0415	B069	1206	MOV
0417	50	1207	PUSH	0417	50	1207	PUSH
0418	E80000	1209	CALL	0418	E80000	1209	CALL
041B	B045	1210	MOV	041B	B045	1210	MOV
041B	50	1211	PUSH	041B	50	1211	PUSH
041E	E80000	1212	CALL	041E	E80000	1212	CALL
0421	A00300	1213	MOV	0421	A00300	1213	MOV
0424	0430	1214	ADD	0424	0430	1214	ADD
0426	50	1215	PUSH	0426	50	1215	PUSH
0427	E80000	1217	CALL	0427	E80000	1217	CALL
042A	A00800	1218	MOV	042A	A00800	1218	MOV
042D	0441	1219	ADD	042D	0441	1219	ADD
042D	0441	1220		042D	0441	1220	
042D	0441	1221		042D	0441	1221	